



[Manuals.plus](#) /

› [GlouMod](#) /

› Rustic Farmhouse Dresser User Manual

## GlouMod B0DB66BZPV

# GlouMod Rustic Farmhouse Dresser User Manual

Model: B0DB66BZPV

[Introduction](#)

[Safety Information](#)

[Setup & Assembly](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Warranty &](#)

[Specifications](#)

[Support](#)

## 1. INTRODUCTION

---

Thank you for choosing the GlouMod Rustic Farmhouse Dresser. This versatile furniture piece is designed to enhance your living space with its blend of farmhouse warmth and contemporary design. Featuring a distressed wood finish, four smooth-gliding drawers, and two cabinets with space-saving sliding barn doors, it offers ample storage for various items. This manual provides detailed instructions for assembly, operation, maintenance, and safety to ensure a long-lasting and satisfying experience with your new dresser.



Figure 1.1: The GlouMod Rustic Farmhouse Dresser, showcasing its vintage white finish and barn door design.

## 2. SAFETY INFORMATION

---

Please read all safety warnings and instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Anti-Tip Hardware:** This dresser is equipped with anti-tip hardware for your safety. It is crucial to install this hardware correctly to prevent the dresser from tipping over, especially in households with children or pets. Always secure the dresser to a wall using the provided anti-tip kit.
- **Weight Capacity:** Do not exceed the recommended weight capacity for the top surface (150 lbs) or drawers/shelves. Distribute weight evenly to maintain stability.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten fasteners as needed.
- **Placement:** Place the dresser on a level surface to prevent wobbling and ensure proper function of drawers and sliding doors.
- **Children Safety:** Keep small parts and packaging materials away from children during assembly. Do not allow


children to climb on or play with the dresser.

## Anti-capsize design. protect your family safety



### OUR

With Anti-capsize Devices



### OTHER

Without Anti-capsize Devices




Figure 2.1: Illustration demonstrating the importance of installing the anti-tip device to prevent accidental tipping.

### 3. SETUP & ASSEMBLY

The GlouMod dresser is designed for straightforward assembly. Please follow the step-by-step illustrated instructions included in your package. All components are clearly labeled to assist you.

#### 3.1. Before You Begin

- Unpack all components and verify against the parts list provided in your assembly manual.
- Ensure you have the necessary tools (e.g., screwdriver, hammer) as specified in the assembly manual.
- Clear a spacious, clean, and soft area for assembly to prevent damage to the furniture.

#### 3.2. Assembly Steps (General Overview)

1. Attach the base and side panels.
2. Install the drawer slides onto the side panels.

3. Assemble the drawers and insert them into the slides.
4. Attach the top panel.
5. Install the barn door tracks and sliding doors.
6. Secure the anti-tip hardware to the dresser and wall.

For detailed visual guidance, refer to the online video support mentioned in your product documentation. This can be particularly helpful for complex steps like installing the sliding barn doors or drawer mechanisms.



Figure 3.1: Detailed views of the barn door sliding mechanism and drawer slides, illustrating key assembly points.

## 4. OPERATION

---

Your GlouMod dresser is designed for versatile use and easy access to your belongings.

### 4.1. Using the Drawers

The dresser features four smooth-gliding drawers. To open, gently pull the handle. To close, push the drawer firmly until it is fully recessed. Avoid forcing drawers if they feel stuck; check for obstructions.

# Maintain a Clean and Tidy Space



Figure 4.1: The dresser with its four drawers open, demonstrating ample storage space for various items.

## 4.2. Operating the Sliding Barn Doors

The two cabinet sections are equipped with barn-style sliding doors. These doors can be moved left or right along the top track to reveal either the central drawers or the adjustable shelves within the cabinets. Gently slide the door handles to move them. The design allows for flexible access to different compartments.



## Sleek and Silent Barn-Style Sliding Doors for a High-Quality Living Experience



Door-Left



Door-Medium



Door-Right

Figure 4.2: The dresser illustrating the three possible positions of the sliding barn doors: left, center, and right, allowing access to different storage areas.

### 4.3. Adjusting Shelves

The cabinets behind the sliding doors contain adjustable and removable shelves. To adjust a shelf, carefully lift it from its current pegs and reposition it to a desired height using the available peg holes. Ensure the shelf is level and securely seated on all four pegs before placing items on it.



Figure 4.3: A close-up view of the adjustable shelf within the cabinet, showing the peg holes for height customization.

### 4.4. Versatile Placement

This dresser's design allows it to function effectively in various rooms. It can serve as a traditional dresser in a bedroom, a TV stand in a living room, or a buffet cabinet in a kitchen or dining area.

## VERSATILE AND CAN BE USED IN VARIOUS LIVING SPACES

It can serve as a dresser in your bedroom, a tv stand in the living room or buffet cabinet in the kitchen/dinning room.



Figure 4.4: Examples of the dresser's versatile use in different home environments, including bedroom, living room, and kitchen/dining room.

## 5. MAINTENANCE

Proper care will help maintain the appearance and longevity of your GlouMod dresser.

- **Cleaning:** Wipe the surface with a damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Heat and Moisture:** Keep the dresser away from direct heat sources and areas of high humidity to prevent warping or cracking.
- **Hardware Check:** Periodically check all screws, bolts, and fasteners to ensure they are tight. Re-tighten as necessary to maintain stability.

## 6. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the common problems and solutions below.

Problem	Possible Cause	Solution
Drawers are difficult to open or close.	<ul style="list-style-type: none"><li>◦ Obstruction in the drawer slide.</li><li>◦ Loose screws on drawer slides or drawer box.</li><li>◦ Dresser is not on a level surface.</li></ul>	<ul style="list-style-type: none"><li>◦ Remove any items obstructing the slide.</li><li>◦ Tighten all screws on the drawer slides and drawer box.</li><li>◦ Adjust the dresser's position to a level surface.</li></ul>
Sliding barn doors are stiff or not moving smoothly.	<ul style="list-style-type: none"><li>◦ Debris on the track.</li><li>◦ Loose track hardware.</li><li>◦ Dresser is not level.</li></ul>	<ul style="list-style-type: none"><li>◦ Clean the track thoroughly.</li><li>◦ Check and tighten all screws securing the track.</li><li>◦ Ensure the dresser is on a level surface.</li></ul>
Dresser wobbles or feels unstable.	<ul style="list-style-type: none"><li>◦ Not on a level surface.</li><li>◦ Loose assembly fasteners.</li><li>◦ Anti-tip hardware not installed or improperly installed.</li></ul>	<ul style="list-style-type: none"><li>◦ Move the dresser to a level surface or use shims.</li><li>◦ Re-tighten all assembly screws and bolts.</li><li>◦ Install or re-install the anti-tip hardware securely to a wall stud.</li></ul>

If the problem persists after attempting these solutions, please contact GlouMod customer service for further assistance.

## 7. SPECIFICATIONS

Feature	Detail
Brand	GlouMod
Model Number	B0DB66BZPV
Product Dimensions	15.75"D x 59.84"W x 31.5"H
Color	Vintage White
Mounting Type	Floor Mount
Room Type	Living Room (Versatile for Bedroom, Kitchen, Hallway)
Special Feature	4 drawers, Sliding Barn Doors, Adjustable Shelves, Anti-tip Hardware
Product Care Instructions	Wipe with Damp Cloth
Assembly Required	Yes

Feature	Detail
Number of Pieces	1
Recommended Uses	Clothes, General Storage, TV Stand, Buffet Cabinet
UPC	027685948526



Figure 7.1: Diagram illustrating the key dimensions of the GlouMod Rustic Farmhouse Dresser.

## 8. WARRANTY & SUPPORT

### 8.1. Warranty Information

GlouMod stands behind the quality of its products. For specific warranty terms and conditions applicable to your Rustic Farmhouse Dresser, please refer to the warranty card included with your purchase or visit the official GlouMod website. Keep your proof of purchase for any warranty claims.

### 8.2. Customer Support

If you have any questions, require assistance with assembly, or need to report a damaged part, our dedicated customer service team is ready to help. Please have your model number (B0DB66BZPV) and purchase information ready when contacting support.

**Contact Information:**

**Website:** [Visit the GlouMod Store on Amazon](#) (for general inquiries and product information)

**Email:** Refer to your product packaging or included documentation for direct customer service email.

**Phone:** Refer to your product packaging or included documentation for direct customer service phone number.

We are committed to ensuring your satisfaction with your GlouMod product.