

[Manuals.plus](#) /

> [XDOBO](#) /

> XDOBO Beast 1982 Portable Wireless Speaker User Manual

## XDOBO Beast 1982

# XDOBO Beast 1982 Portable Wireless Speaker User Manual

Model: Beast 1982

### PRODUCT OVERVIEW

The XDOBO Beast 1982 is a high-power portable wireless speaker designed to deliver immersive and clear audio. Featuring Bluetooth 5.3 connectivity, 120W output, and a wide frequency response, it is suitable for various audio playback needs.



Figure 1: XDOBO Beast 1982 Portable Wireless Speaker with its accompanying microphone.

### PACKAGE CONTENTS

- XDOBO Beast 1982 Portable Wireless Speaker
- Microphone
- Charging Cable (USB-C)
- User Manual

## SETUP

---

### Charging the Speaker

Before first use, fully charge the speaker. Connect the charging cable to the speaker's charging port and to a compatible USB power adapter. The charging indicator light will show the charging status. A full charge takes approximately 5 hours.

### Powering On/Off

Press and hold the power button located on the top panel of the speaker for 3 seconds to power on or power off the device.

## OPERATING INSTRUCTIONS

---

### Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. The Bluetooth indicator light will flash.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "XDOBO Beast 1982" from the list of devices.
4. Once connected, the Bluetooth indicator light will become solid, and you will hear a confirmation tone.

Beast 1982

# Bluetooth 5.3 upgrade version 120W deep bass

HIFI Stereo | DSP 4 horn



Figure 2: The speaker features Bluetooth 5.3 for stable wireless connections and delivers 120W of deep bass.

## Playback Modes

The XDOBO Beast 1982 supports multiple playback options:

- **Bluetooth 5.3:** Wireless audio streaming from compatible devices.
- **U Disk (USB Drive):** Play audio files directly from a USB flash drive.
- **AUX Audio:** Connect external audio sources via a 3.5mm audio cable.
- **TWS Interconnection:** Pair two Beast 1982 speakers for true wireless stereo sound.

# CD-level shocking sound quality

4 playback modes · get rid of shackles · intimate companion



Bluetooth 5.3



U disk



AUX audio



TWS interconnection



Black gray

**Beast 1982**

Figure 3: The speaker supports various playback modes including Bluetooth, USB drive, AUX input, and True Wireless Stereo (TWS).

## Using the Microphone

The included microphone can be used for karaoke or public speaking. Simply plug the microphone into the designated microphone input port on the speaker. Adjust the microphone volume using the dedicated controls on the speaker.




Figure 4: The included microphone allows for vocal input, ideal for karaoke or announcements.

## MAINTENANCE

---

### Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents. Ensure the charging port and other openings are free of dust and debris.

### Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to approximately 50% every few months to maintain battery health.

### Water Resistance

The XDOBO Beast 1982 features a degree of water resistance, making it suitable for outdoor use. However, it is not designed for submersion. Avoid exposing the speaker to heavy rain or direct water jets for prolonged periods.



Figure 5: The speaker is designed with water resistance for outdoor environments, capable of withstanding splashes.

## TROUBLESHOOTING

---

- **No Power:** Ensure the speaker is fully charged. Press and hold the power button for 3-5 seconds.
- **No Sound:** Check the volume levels on both the speaker and your connected device. Ensure the correct input mode (Bluetooth, AUX, USB) is selected.
- **Bluetooth Disconnection:** Move the speaker closer to your device. Ensure no obstacles are blocking the signal. Try unpairing and re-pairing the device.
- **Poor Sound Quality:** Check the audio source. Ensure the speaker is not placed near interference sources. For Bluetooth, ensure the device is within range.
- **Microphone Not Working:** Ensure the microphone is securely plugged in. Check the microphone volume control on the speaker.

## SPECIFICATIONS

| Feature                 | Detail                                  |
|-------------------------|-----------------------------------------|
| Model Name              | Beast 1982                              |
| Speaker Type            | Subwoofer                               |
| Connectivity Technology | Bluetooth 5.3                           |
| Max Output Power        | 120 Watts                               |
| Frequency Response      | 20Hz-20kHz                              |
| Signal-to-Noise Ratio   | 100 dB                                  |
| Battery Life            | Up to 10 Hours                          |
| Charging Time           | Approx. 5 Hours                         |
| Battery Type            | Lithium Ion (1 included)                |
| Included Components     | Speaker, Microphone                     |
| Product Dimensions      | 41.5 cm (D) x 15.7 cm (W) x 22.5 cm (H) |
| Audio Output Mode       | Stereo                                  |




Figure 6: The speaker is equipped with a Bluetooth V5.3 chip for advanced wireless performance.

## WARRANTY AND SUPPORT

---

The XDOBO Beast 1982 comes with a limited warranty. For warranty claims or technical support, please refer to the contact information provided on the product packaging or the official XDOBO website. Keep your proof of purchase for warranty validation.

*Note: The specific terms and duration of the limited warranty may vary by region.*

## IMPORTANT SAFETY INFORMATION

---

- Do not expose the speaker to extreme temperatures or direct sunlight for prolonged periods.
- Do not disassemble, repair, or modify the speaker yourself. This may void the warranty and pose safety risks.
- Keep the speaker away from water and liquids, except for the intended water-resistant use.
- Use only the recommended charging cable and power adapter.

- Avoid listening at high volume levels for extended periods to prevent hearing damage.

© 2025 XDOBO. All rights reserved.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0DB6BQ9P8>

More documents and user manuals: <https://manuals.plus/>