

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Juskys](#) /
- › [Juskys IceOracle Ice Maker Instruction Manual](#)

Juskys IceOracle

Juskys IceOracle Ice Maker Instruction Manual

Model: IceOracle

INTRODUCTION

Thank you for choosing the Juskys IceOracle Ice Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and keep them for future reference.

STYLISCHE EISWÜRFELMASCHINE

Eiswürfel schnell
und einfach selbst
produzieren



Image: The Juskys IceOracle Ice Maker, a compact appliance designed for home use, shown on a kitchen counter.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances. This includes:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plug, or any part of the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

SETUP AND FIRST USE

1. **Unpacking:** Carefully remove the ice maker from its packaging. Retain packaging materials for future transport or storage.
2. **Placement:** Place the ice maker on a stable, level surface away from direct sunlight and heat sources. Ensure adequate ventilation around the unit. The appliance requires no permanent water connection.
3. **Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance and Cleaning" section for detailed instructions.
4. **Power Connection:** Ensure the power cord is securely plugged into a grounded electrical outlet.
5. **Water Filling:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill. The water tank capacity is 1.2 liters.



Image: The Juskys IceOracle Ice Maker with its dimensions (29D x 22W x 29H cm) and 1.2-liter water tank capacity highlighted.

OPERATING INSTRUCTIONS

The Juskys IceOracle Ice Maker is designed for easy operation with intuitive controls.

1. **Power On:** Press the "ON/OFF" button to start the ice maker.
2. **Select Ice Cube Size:** Use the "SELECT" button to choose between two ice cube sizes: Small (S) or Large (L). The selected size will be indicated by an illuminated LED.
3. **Ice Production:** The machine will begin the ice-making cycle. The first batch of 9 ice cubes will be ready in approximately 6-13 minutes, depending on the selected size and ambient temperature.
4. **Monitoring:** You can monitor the ice production through the transparent viewing window on the lid.
5. **Ice Collection:** Once ice cubes are formed, they will drop into the removable ice basket. The basket has a capacity of 0.7 kg.
6. **Water Refill Indicator:** If the water level in the reservoir is too low, the "ADD WATER" indicator light will illuminate. Refill the water reservoir as described in the "Setup" section.
7. **Ice Full Indicator:** When the ice basket is full, the "ICE FULL" indicator light will illuminate, and the machine will pause ice production. Remove ice from the basket to resume operation.
8. **Power Off:** To stop the ice maker, press the "ON/OFF" button again.

EINFACHE BEDIENUNG



Intuitives Display
mit Kontrollleuchten

Sichtfenster
Produktion stets im Blick

Image: A detailed view of the Juskys IceOracle's control panel with indicator lights and the transparent lid, showing ice cubes inside.

SCHNELL & EINFACH

Besonders effizient

Bis zu 12 kg am Tag

Fertig in 6-13 min

9 Eiswürfel pro Zyklus

2 Größen wählbar



Image: The Juskys IceOracle Ice Maker highlighting its ability to produce up to 12 kg of ice per day and the option to select between small and large ice cube sizes.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance ensure optimal performance and longevity of your ice maker.

Self-Cleaning Function:

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the "CLEAN" button on the control panel to activate the self-cleaning cycle.
3. The machine will perform a cleaning cycle, circulating water through its internal components.
4. Once the cycle is complete, drain the water from the reservoir and dry the interior.

Manual Cleaning:

- **Daily Cleaning:** After each use, remove the ice basket and wipe the interior with a soft, damp cloth.
- **Weekly Cleaning:** For a more thorough cleaning, unplug the unit. Remove the ice basket. Drain any remaining water from the reservoir. Clean the interior with a mild detergent solution and a soft cloth. Rinse thoroughly with clean water.
- **Exterior Cleaning:** Wipe the exterior of the ice maker with a soft, damp cloth. Do not use abrasive

cleaners or solvents.

- **Storage:** If storing the ice maker for an extended period, ensure it is completely dry. Store in a cool, dry place.



Image: The Juskys IceOracle Ice Maker with its removable ice basket and included ice scoop, illustrating features for hygienic use and cleaning.

TROUBLESHOOTING

Before contacting customer support, please refer to the following troubleshooting guide for common issues:

Problem	Possible Cause	Solution
Ice maker does not turn on.	No power supply.	Check if the power cord is securely plugged into a working outlet. Check circuit breaker.
"ADD WATER" indicator is on.	Water reservoir is empty or low.	Fill the water reservoir with potable water up to the MAX fill line.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice cubes from the basket. The machine will resume operation automatically.

Problem	Possible Cause	Solution
Ice cubes are too small or production is slow.	Ambient temperature is too high; water temperature is too high; air vent is blocked.	Ensure the ice maker is in a cool environment. Use cold water. Ensure proper ventilation around the unit. Select larger ice cube size.
Unusual noise during operation.	Normal operation sounds (compressor, water pump); unit not level.	Ensure the unit is on a stable, level surface. If noise is excessive or unusual, contact customer support.

SPECIFICATIONS

Brand:	Juskys
Model Name:	IceOracle
Product Dimensions (D x W x H):	29 cm x 22 cm x 29 cm
Water Tank Capacity:	1.2 Liters
Ice Production Capacity:	Up to 12 kg per day
First Ice Batch Time:	6-13 minutes (9 cubes)
Ice Basket Capacity:	0.7 kg
Power:	12 Watts

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Juskys website. Keep your proof of purchase for any warranty claims.

Seller: Juskys Gruppe GmbH

Return Policy: 14 days (refund/replacement)