

BoyKeep K11

BoyKeep Ease Life K11 Indoor Security Camera User Manual

MODEL: K11

1. Introduction

Thank you for choosing the BoyKeep Ease Life K11 Indoor Security Camera. This manual provides detailed instructions for setting up, operating, and maintaining your camera to ensure optimal performance and security for your home. This camera is designed for indoor use, offering high-resolution video, two-way audio, and smart detection features.



Image: The BoyKeep Ease Life K11 Indoor Security Camera shown next to a smartphone displaying the live feed from the camera, demonstrating its remote monitoring capability.

2. What's in the Box

- BoyKeep Ease Life K11 Indoor Security Camera
- USB to USB-C Cable (approx. 6 feet)
- Instruction Manual

Note: A power adapter is **not** included with this version of the camera. Please use a 5V/1A USB power adapter (not supplied) to power the device.

3. Product Features

- **High-Resolution & Night Vision:** Enjoy clear and vivid 1080P HD resolution. The camera features enhanced night vision for monitoring in low-light conditions.

2MP resolution, clear visuals anytime



1080P Resolution

1080P

720P




Image: A visual comparison demonstrating the superior clarity of 1080P resolution compared to 720P, illustrated with images of cats.

- **Motion Tracking & Alerts:** The camera records alert videos and sends notifications to your phone upon detecting motion or sound. Customizable monitoring zones, schedules, and sensitivity settings help minimize false alarms. An integrated alarm feature can deter intruders.

Clear sight, day and night



Motion
Detection



Sound
Detection




Image: A smartphone displaying a real-time notification for detected motion, illustrating the camera's alert capabilities.

- **Two-Way Communication:** Equipped with a built-in microphone and speaker, the camera enables seamless two-way audio communication, allowing you to hear and speak through the camera via the app.




Image: A visual representation of the two-way audio feature, showing a dog and a person communicating through the camera.

- **Multi-Device Viewing & Sharing:** Add multiple cameras to the Ease Life App and view up to four real-time video feeds simultaneously. Share access with up to 10 family members for collective monitoring.

Multiple setups, seamless viewing



Image: Multiple camera setups in a home environment, showcasing the flexibility for seamless viewing from various angles.

- **Flexible Recording Options:** Supports local storage via a Micro SD card (up to 128GB, not included) for 24/7 continuous or motion-triggered recording. Optional cloud storage plans are available for additional backup and security.

Record every sight from day to night



Cloud Storage



Memory Card



Image: A smartphone screen showing a timeline of recorded video, with icons representing cloud storage and memory card options.

- **Connectivity:** Supports 2.4G Wi-Fi and Bluetooth for easy connection.



Image: The camera's connectivity features highlighted, showing support for 2.4G WiFi and Bluetooth, along with a 130-degree viewing angle.

4. Setup Guide

1. **Power On:** Connect the camera to a 5V/1A USB power adapter (not included) using the provided USB to USB-C cable. The camera will power on and indicate readiness for setup.
2. **Download the App:** Search for and download the "Ease Life" app from your smartphone's app store (available for Android and iOS).
3. **Register/Log In:** Open the Ease Life app and create a new account or log in if you already have one.
4. **Add Device:** Tap the "+" icon in the app to add a new device. Select your camera model (K11) from the list.
5. **Connect to Wi-Fi:** Follow the in-app instructions to connect the camera to your 2.4G Wi-Fi network. Ensure your phone is also connected to the same 2.4G Wi-Fi network during setup. The app may guide you to scan a QR code displayed on your phone with the camera lens.
6. **Pairing Complete:** Once connected, the camera will indicate successful pairing, and you can begin live viewing.

5. Operating Instructions

- **Live View:** Open the Ease Life app and select your camera to view the live feed.
- **Two-Way Audio:** On the live view screen, tap the microphone icon to speak through the camera. Tap the speaker icon to listen to audio from the camera's location.
- **Motion/Sound Detection:** Access camera settings in the app to enable or disable motion and sound detection. Adjust sensitivity levels and set specific monitoring zones or schedules as needed.
- **Recording & Playback:**
 - **Micro SD Card:** Insert a Micro SD card (not included) into the TF slot on the camera (refer to the bottom of the camera for the slot). The camera will automatically begin recording based on your settings (continuous or motion-triggered). To view recordings, access the playback feature in the app.
 - **Cloud Storage:** If you opt for cloud storage, follow the in-app instructions to subscribe and activate the service. Recordings will be securely stored in the cloud.
- **Sharing Device:** In the app, navigate to the camera settings and find the 'Share Device' option to invite family members to view the camera feed.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid using harsh chemicals or abrasive cleaners.
- **Placement:** Ensure the camera is placed in a stable, dry indoor environment, away from direct sunlight, heat sources, and excessive moisture.

- **Firmware Updates:** Regularly check the Ease Life app for available firmware updates to ensure your camera has the latest features and security enhancements.

7. Troubleshooting

Problem	Possible Solution
Camera won't connect to Wi-Fi.	Ensure you are connecting to a 2.4G Wi-Fi network. 5G networks are not supported. Check your Wi-Fi password for accuracy. Move the camera closer to your Wi-Fi router. Reset the camera using the reset button (refer to the bottom of the camera) and try setup again.
Poor image quality.	Ensure your Wi-Fi signal is strong. Clean the camera lens with a soft cloth. Check app settings for resolution options (ensure it's set to 1080P if available).
Two-way audio has static or is unclear.	Ensure there is no obstruction near the microphone or speaker. Check your internet connection stability. Reduce background noise in the camera's environment.
Camera is not recording.	Ensure a Micro SD card is properly inserted and formatted (if using local storage). Check if the SD card is full. Verify recording settings in the app (e.g., continuous recording, motion-triggered). Confirm your cloud storage subscription is active (if using cloud storage).

8. Specifications

Feature	Detail
Model Name	K11
Indoor/Outdoor Usage	Indoor
Video Capture Resolution	1080P HD
Connectivity Technology	Wireless (2.4G Wi-Fi, Bluetooth)
Power Source	Corded Electric (DC 5V/1A, adapter not included)

Feature	Detail
Compatible Devices	Tablet, Smartphone (Android)
Special Features	2-Way Audio, Motion Detection, Night Vision, Cloud/SD Storage
Mounting Type	Wall Mount (with included base)
Color	White
Product Dimensions	4.72 x 2.8 x 2.8 inches
Item Weight	3.84 ounces

9. Warranty Information

BoyKeep products are covered by a limited warranty from the date of purchase. Please retain your proof of purchase for warranty claims. For specific warranty terms and conditions, refer to the warranty card included with your product or visit the official BoyKeep website.

10. Customer Support



If you encounter any issues or have questions regarding your BoyKeep Ease Life K11 Indoor Security Camera, please contact our customer support team:





- **Email:** support@boykeep.com (example email, replace with actual if available)
- **Website:** [Visit the BoyKeep Store on Amazon](#)

Our support team is available to assist you with technical issues, setup guidance, and general inquiries.

© 2025 BoyKeep. All rights reserved.

Related Documents - K11

	BoyKeep Smart Wi-Fi Camera User Manual A comprehensive user manual for the BoyKeep Smart Wi-Fi Camera, detailing setup, connection, features, FAQs, and important notes for optimal usage.
	BoyKeep Wi-Fi Smart Camera Manual Guide A comprehensive manual guide for the BoyKeep Wi-Fi Smart Camera, covering app download, account login, device setup via scanning code and AP hotspot, features, FAQs, and important notes.

<div><p>取扱説明書 K30 ペットカメラ</p><p>Email: support@boykeep.com Website: www.boykeep.com</p><p>この取扱説明書をお読みください。製品を安全に使用するためには、 ご使用前にこの取扱説明書を必ずお読みください。また、ご不明な点が ある場合にはお問い合わせください。</p></div>	<p>Boykeep K30 Pet Camera: Instruction Manual and Setup Guide</p> <p>Comprehensive instruction manual for the Boykeep K30 Pet Camera. Learn how to download the BoyKeep app, log in, add your device via QR code or Bluetooth, use live view features, understand reset procedures, safety precautions, FAQs, and warranty information.</p>
<div></div>	<p>BoyKeep K30 Pet Camera User Manual</p> <p>User manual for the BoyKeep K30 Pet Camera, detailing app download, device setup via Wi-Fi hotspot or QR code scanning, features, troubleshooting, and important notes.</p>
<div><p> User Manual K30 Pet Camera</p><p>Email: support@boykeep.com Website: www.boykeep.com V1-2311</p></div>	<p>Boykeep K30 Pet Camera User Manual</p> <p>User manual for the Boykeep K30 Pet Camera, detailing setup, features, and troubleshooting for this indoor security camera. Learn how to connect and use your Boykeep K30.</p>
<div><p>Hangzhou Kua Shi Technology Co., Ltd.</p><p>Model Differences</p><p>Date: 2023.11.02</p><p>Product description: Smart Home Camera</p><p>Model: K11, K11A, K11B, K11C, K11D, K11E, K11F, K11G, K11H, K11I, K11J, K11K, K11L, K11M, K11N, K11O, K11P, K11Q, K11R, K11S, K11T, K11U, K11V, K11W, K11X, K11Y, K11Z, K12, K13, K14, K15, K16, K17, K18, K19, K20, K21, K22, K23, K24, K25, K26, K27, K28, K29, K30, K31, K32, K33, K34, K35, K36, K37, K38, K39, K40, K41, K42, K43, K44, K45, K46, K47, K48, K49, K50, K51, K52, K53, K54, K55, K56, K57, K58, K59, K60, K61, K62, K63, K64, K65, K66, K67, K68, K69, K70, K71, K72, K73, K74, K75, K76, K77, K78, K79, K80, K81, K82, K83, K84, K85, K86, K87, K88, K89, K90, K91, K92, K93, K94, K95, K96, K97, K98, K99, K100, K101, K102, K103, K104, K105, K106, K107, K108, K109, K110, K111, K112, K113, K114, K115, K116, K117, K118, K119, K120, K121, K122, K123, K124, K125, K126, K127, K128, K129, K130, K131, K132, K133, K134, K135, K136, K137, K138, K139, K140, K141, K142, K143, K144, K145, K146, K147, K148, K149, K150, K151, K152, K153, K154, K155, K156, K157, K158, K159, K160, K161, K162, K163, K164, K165, K166, K167, K168, K169, K170, K171, K172, K173, K174, K175, K176, K177, K178, K179, K180, K181, K182, K183, K184, K185, K186, K187, K188, K189, K190, K191, K192, K193, K194, K195, K196, K197, K198, K199, K200, K201, K202, K203, K204, K205, K206, K207, K208, K209, K210, K211, K212, K213, K214, K215, K216, K217, K218, K219, K220, K221, K222, K223, K224, K225, K226, K227, K228, K229, K230, K231, K232, K233, K234, K235, K236, K237, K238, K239, K240, K241, K242, K243, K244, K245, K246, K247, K248, K249, K250, K251, K252, K253, K254, K255, K256, K257, K258, K259, K260, K261, K262, K263, K264, K265, K266, K267, K268, K269, K270, K271, K272, K273, K274, K275, K276, K277, K278, K279, K280, K281, K282, K283, K284, K285, K286, K287, K288, K289, K290, K291, K292, K293, K294, K295, K296, K297, K298, K299, K300, K301, K302, K303, K304, K305, K306, K307, K308, K309, K310, K311, K312, K313, K314, K315, K316, K317, K318, K319, K320, K321, K322, K323, K324, K325, K326, K327, K328, K329, K330, K331, K332, K333, K334, K335, K336, K337, K338, K339, K340, K341, K342, K343, K344, K345, K346, K347, K348, K349, K350, K351, K352, K353, K354, K355, K356, K357, K358, K359, K360, K361, K362, K363, K364, K365, K366, K367, K368, K369, K370, K371, K372, K373, K374, K375, K376, K377, K378, K379, K380, K381, K382, K383, K384, K385, K386, K387, K388, K389, K390, K391, K392, K393, K394, K395, K396, K397, K398, K399, K400, K401, K402, K403, K404, K405, K406, K407, K408, K409, K410, K411, K412, K413, K414, K415, K416, K417, K418, K419, K420, K421, K422, K423, K424, K425, K426, K427, K428, K429, K430, K431, K432, K433, K434, K435, K436, K437, K438, K439, K440, K441, K442, K443, K444, K445, K446, K447, K448, K449, K450, K451, K452, K453, K454, K455, K456, K457, K458, K459, K460, K461, K462, K463, K464, K465, K466, K467, K468, K469, K470, K471, K472, K473, K474, K475, K476, K477, K478, K479, K480, K481, K482, K483, K484, K485, K486, K487, K488, K489, K490, K491, K492, K493, K494, K495, K496, K497, K498, K499, K500, K501, K502, K503, K504, K505, K506, K507, K508, K509, K510, K511, K512, K513, K514, K515, K516, K517, K518, K519, K520, K521, K522, K523, K524, K525, K526, K527, K528, K529, K530, K531, K532, K533, K534, K535, K536, K537, K538, K539, K540, K541, K542, K543, K544, K545, K546, K547, K548, K549, K550, K551, K552, K553, K554, K555, K556, K557, K558, K559, K560, K561, K562, K563, K564, K565, K566, K567, K568, K569, K570, K571, K572, K573, K574, K575, K576, K577, K578, K579, K580, K581, K582, K583, K584, K585, K586, K587, K588, K589, K590, K591, K592, K593, K594, K595, K596, K597, K598, K599, K600, K601, K602, K603, K604, K605, K606, K607, K608, K609, K610, K611, K612, K613, K614, K615, K616, K617, K618, K619, K620, K621, K622, K623, K624, K625, K626, K627, K628, K629, K630, K631, K632, K633, K634, K635, K636, K637, K638, K639, K640, K641, K642, K643, K644, K645, K646, K647, K648, K649, K650, K651, K652, K653, K654, K655, K656, K657, K658, K659, K660, K661, K662, K663, K664, K665, K666, K667, K668, K669, K670, K671, K672, K673, K674, K675, K676, K677, K678, K679, K680, K681, K682, K683, K684, K685, K686, K687, K688, K689, K690, K691, K692, K693, K694, K695, K696, K697, K698, K699, K700, K701, K702, K703, K704, K705, K706, K707, K708, K709, K710, K711, K712, K713, K714, K715, K716, K717, K718, K719, K720, K721, K722, K723, K724, K725, K726, K727, K728, K729, K730, K731, K732, K733, K734, K735, K736, K737, K738, K739, K740, K741, K742, K743, K744, K745, K746, K747, K748, K749, K750, K751, K752, K753, K754, K755, K756, K757, K758, K759, K760, K761, K762, K763, K764, K765, K766, K767, K768, K769, K770, K771, K772, K773, K774, K775, K776, K777, K778, K779, K780, K781, K782, K783, K784, K785, K786, K787, K788, K789, K790, K791, K792, K793, K794, K795, K796, K797, K798, K799, K800, K801, K802, K803, K804, K805, K806, K807, K808, K809, K810, K811, K812, K813, K814, K815, K816, K817, K818, K819, K820, K821, K822, K823, K824, K825, K826, K827, K828, K829, K830, K831, K832, K833, K834, K835, K836, K837, K838, K839, K840, K841, K842, K843, K844, K845, K846, K847, K848, K849, K850, K851, K852, K853, K854, K855, K856, K857, K858, K859, K860, K861, K862, K863, K864, K865, K866, K867, K868, K869, K870, K871, K872, K873, K874, K875, K876, K877, K878, K879, K880, K881, K882, K883, K884, K885, K886, K887, K888, K889, K890, K891, K892, K893, K894, K895, K896, K897, K898, K899, K900, K901, K902, K903, K904, K905, K906, K907, K908, K909, K910, K911, K912, K913, K914, K915, K916, K917, K918, K919, K920, K921, K922, K923, K924, K925, K926, K927, K928, K929, K930, K931, K932, K933, K934, K935, K936, K937, K938, K939, K940, K941, K942, K943, K944, K945, K946, K947, K948, K949, K950, K951, K952, K953, K954, K955, K956, K957, K958, K959, K960, K961, K962, K963, K964, K965, K966, K967, K968, K969, K970, K971, K972, K973, K974, K975, K976, K977, K978, K979, K980, K981, K982, K983, K984, K985, K986, K987, K988, K989, K990, K991, K992, K993, K994, K995, K996, K997, K998, K999, K1000, K1001, K1002, K1003, K1004, K1005, K1006, K1007, K1008, K1009, K1010, K1011, K1012, K1013, K1014, K1015, K1016, K1017, K1018, K1019, K1020, K1021, K1022, K1023, K1024, K1025, K1026, K1027, K1028, K1029, K1030, K1031, K1032, K1033, K1034, K1035, K1036, K1037, K1038, K1039, K1040, K1041, K1042, K1043, K1044, K1045, K1046, K1047, K1048, K1049, K1050, K1051, K1052, K1053, K1054, K1055, K1056, K1057, K1058, K1059, K1060, K1061, K1062, K1063, K1064, K1065, K1066, K1067, K1068, K1069, K1070, K1071, K1072, K1073, K1074, K1075, K1076, K1077, K1078, K1079, K1080, K1081, K1082, K1083, K1084, K1085, K1086, K1087, K1088, K1089, K1090, K1091, K1092, K1093, K1094, K1095, K1096, K1097, K1098, K1099, K1100, K1101, K1102, K1103, K1104, K1105, K1106, K1107, K1108, K1109, K1110, K1111, K1112, K1113, K1114, K1115, K1116, K1117, K1118, K1119, K1120, K1121, K1122, K1123, K1124, K1125, K1126, K1127, K1128, K1129, K1130, K1131, K1132, K1133, K1134, K1135, K1136, K1137, K1138, K1139, K1140, K1141, K1142, K1143, K1144, K1145, K1146, K1147, K1148, K1149, K1150, K1151, K1152, K1153, K1154, K1155, K1156, K1157, K1158, K1159, K1160, K1161, K1162, K1163, K1164, K1165, K1166, K1167, K1168, K1169, K1170, K1171, K1172, K1173, K1174, K1175, K1176, K1177, K1178, K1179, K1180, K1181, K1182, K1183, K1184, K1185, K1186, K1187, K1188, K1189, K1190, K1191, K1192, K1193, K1194, K1195, K1196, K1197, K1198, K1199, K1200, K1201, K1202, K1203, K1204, K1205, K1206, K1207, K1208, K1209, K1210, K1211, K1212, K1213, K1214, K1215, K1216, K1217, K1218, K1219, K1220, K1221, K1222, K1223, K1224, K1225, K1226, K1227, K1228, K1229, K1230, K1231, K1232, K1233, K1234, K1235, K1236, K1237, K1238, K1239, K1240, K1241, K1242, K1243, K1244, K1245, K1246, K1247, K1248, K1249, K1250, K1251, K1252, K1253, K1254, K1255, K1256, K1257, K1258, K1259, K1260, K1261, K1262, K1263, K1264, K1265, K1266, K1267, K1268, K1269, K1270, K1271, K1272, K1273, K1274, K1275, K1276, K1277, K1278, K1279, K1280, K1281, K1282, K1283, K1284, K1285, K1286, K1287, K1288, K1289, K1290, K1291, K1292, K1293, K1294, K1295, K1296, K1297, K1298, K1299, K1300, K1301, K1302, K1303, K1304, K1305, K1306, K1307, K1308, K1309, K1310, K1311, K1312, K1313, K1314, K1315, K1316, K1317, K1318, K1319, K1320, K1321, K1322, K1323, K1324, K1325, K1326, K1327, K1328, K1329, K1330, K1331, K1332, K1333, K1334, K1335, K1336, K1337, K1338, K1339, K1340, K1341, K1342, K1343, K1344, K1345, K1346, K1347, K1348, K1349, K1350, K1351, K1352, K1353, K1354, K1355, K1356, K1357, K1358, K1359, K1360, K1361, K1362, K1363, K1364, K1365, K1366, K1367, K1368, K1369, K1370, K1371, K1372, K1373, K1374, K1375, K1376, K1377, K1378, K1379, K1380, K1381, K1382, K1383, K1384, K1385, K1386, K1387, K1388, K1389, K1390, K1391, K1392, K1393, K1394, K1395, K1396, K1397, K1398, K1399, K1400, K1401, K1402, K1403, K1404, K1405, K1406, K1407, K1408, K1409, K1410, K1411, K1412, K1413, K1414, K1415, K1416, K1417, K1418, K1419, K1420, K1421, K1422, K1423, K1424, K1425, K1426, K1427, K1428, K1429, K1430, K1431, K1432, K1433, K1434, K1435, K1436, K1437, K1438, K1439, K1440, K1441, K1442, K1443, K1444, K1445, K1446, K1447, K1448, K1449, K1450, K1451, K1452, K1453, K1454, K1455, K1456, K1457, K1458, K1459, K1460, K1461, K1462, K1463, K1464, K1465, K1466, K1467, K1468, K1469, K1470, K1471, K1472, K1473, K1474, K1475, K1476, K1477, K1478, K1479, K1480, K1481, K1482, K1483, K1484, K1485, K1486, K1487, K1488, K1489, K1490, K1491, K1492, K1493, K1494, K1495, K1496, K1497, K1498, K1499, K1500, K1501, K1502, K1503, K1504, K1505, K1506, K1507, K1508, K1509, K1510, K1511, K1512, K1513, K1514, K1515, K1516, K1517, K1518, K1519, K1520, K1521, K1522, K1523, K1524, K1525, K1526, K1527, K1528, K1529, K1530, K1531, K1532, K1533, K1534, K1535, K1536, K1537, K1538, K1539, K1540, K1541, K1542, K1543, K1544, K1545, K1546, K1547, K1548, K1549, K1550, K1551, K1552, K1553, K1554, K1555, K1556, K1557, K1558, K1559, K1560, K1561, K1562, K1563, K1564, K1565, K1566, K1567, K1568, K1569, K1570, K1571, K1572, K1573, K1574, K1575, K1576, K1577, K1578, K1579, K1580, K1581, K1582, K1583, K1584, K1585, K1586, K1587, K1588, K1589, K1590, K1591, K1592, K1593, K1594, K1595, K1596, K1597, K1598, K1599, K1600, K1601, K1602, K1603, K1604, K1605, K1606, K1607, K1608, K1609, K1610, K1611, K1612, K1613, K1614, K1615, K1616, K1617, K1618, K1619, K1620, K1621, K1622, K1623, K1624, K1625, K1626, K1627, K1628, K1629, K1630, K1631, K1632, K1633, K1634, K1635, K1636, K1637, K1638, K1639, K1640, K1641, K1642, K1643, K1644, K1645, K1646, K1647, K1648, K1649, K1650, K1651, K1652, K1653, K1654, K1655, K1656, K1657, K1658, K1659, K1660, K1661, K1662, K1663, K1664, K1665, K1666, K1667, K1668, K1669, K1670, K1671, K1672, K1673, K1674, K1675, K1676, K1677, K1678, K1679, K1680, K1681, K1682, K1683, K1684, K1685, K1686, K1687, K1688, K1689, K1690, K1691, K1692, K1693, K1694, K1695, K1696, K1697, K1698, K1699, K1700, K1701, K1702, K1703, K1704, K1705, K1706, K1707, K1708, K1709, K1710, K1711, K1712, K1713, K1714, K1715, K1716, K1717, K1718, K1719, K1720, K1721, K1722, K1723, K1724, K1725, K1726, K1727, K1728, K1729, K1730, K1731, K1732, K1733, K1734, K1735, K1736, K1737, K1738, K1739, K1740, K1741, K1742, K1743, K1744, K1745, K1746, K1747, K1748, K1749, K1750, K1751, K1752, K1753, K1754, K1755, K1756, K1757, K1758, K1759, K1760, K1761, K1762, K1763, K1764, K1765, K1766, K1767, K1768, K1769, K1770, K1771, K1772, K1773, K1774, K1775, K1776, K1777, K1778, K1779, K1780, K1781, K1782, K1783, K1784, K1785, K1786, K1787, K1788, K1789, K1790, K1791, K1792, K1793, K1794, K1795, K1796, K1797, K1798, K1799, K1800, K1801, K1802, K1803, K1804, K1805, K1806, K1807, K1808, K1809, K1810, K1811, K1812, K1813, K1814, K1815, K1816, K1817, K1818, K1819, K1820, K1821, K1822, K1823, K1824, K1825, K1826, K1827, K1828, K1829, K1830, K1831, K1832, K1833, K1834, K1835, K1836, K1837, K1838, K1839, K1840, K1841, K1842, K1843, K1844, K1845, K1846, K1847, K1848, K1849, K1850, K1851, K1852, K1853, K1854, K1855, K1856, K1857, K1858, K1859, K1860, K1861, K1862, K1863, K1864, K1865, K1866, K1867, K1868, K1869, K1870, K1871, K1872, K1873, K1874, K1875, K1876, K1877, K1878, K1879, K1880, K1881, K1882, K1883, K1884, K1885, K1886, K1887, K1888, K1889, K1890, K1891, K1892, K1893, K1894, K1895, K1896, K1897, K1898, K1899, K1900, K1901, K1902, K1903, K1904, K1905, K1906, K1907, K1908, K1909, K1910, K1911, K1912, K1913, K1914, K1915, K1916, K1917, K1918, K1919, K1920, K1921, K1922, K1923, K1924, K1925, K1926, K1927, K1928, K1929, K1930, K1931, K1932, K1933, K1934, K1935, K1936, K1937, K1938, K1939, K1940, K1941, K1942, K1943, K1944, K1945, K1946, K1947, K1948, K1949, K1950, K1951, K1952, K1953, K1954, K1955, K1956, K1957, K1958, K1959, K1960, K1961, K1962, K1963, K1964, K1965, K1966, K1967, K1968, K1969, K1970, K1971, K1972, K1973, K1974, K1975, K1976, K1977, K1978, K1979, K1980, K1981, K1982, K1983, K1984, K1985, K1986, K1987, K1988, K1989, K1990, K1991, K1992, K1993, K1994, K1995, K1996, K1997, K1998, K1999, K2000, K2001, K2002, K2003, K2004, K2005, K2006, K2007, K2008, K2009, K2010, K2011, K2012, K2013, K2014, K2015, K2016, K2017, K2018, K2019, K2020, K2021, K2022, K2023, K2024, K2025, K2026, K2027, K2028, K2029, K2030, K2031, K2032, K2033, K2034, K2035, K2036, K2037, K2038, K2039, K2040, K2041, K2042, K2043, K2044, K2045, K2046, K2047, K2048, K2049, K2050, K2051, K2052, K2053, K2054, K2055, K2056, K2057, K2058, K2059, K2060, K2061, K2062, K2063, K2064, K2065, K2066, K2067, K2068, K2069, K2070, K2071, K2072, K2073, K2074, K2075, K2076, K2077, K2078, K2079, K2080, K2081, K2082, K2083, K2084, K2085, K2086, K2087, K2088, K2089, K2090, K2091, K2092, K2093, K2094, K2095, K2096, K2097, K2098, K2099, K2100, K2101, K2102, K2103, K2104, K2105, K2106, K2107, K2108, K2109, K2110, K2111, K2112, K2113, K2</p></div>	