

pangshi C12

pangshi C12 Auto Face Tracking Selfie Stick Tripod User Manual

Model: C12

1. INTRODUCTION

Thank you for choosing the pangshi C12 Auto Face Tracking Selfie Stick Tripod. This device combines the functionality of a selfie stick and a tripod with advanced AI-powered face tracking, designed to enhance your content creation, video calls, and live streaming experiences. Please read this manual carefully to ensure proper use and optimal performance.

2. WHAT'S INCLUDED

- 1 x C12 Auto Tracking Selfie Stick Tripod
- 1 x Wireless Remote Control
- 1 x USB Charging Cable
- 1 x User Manual (this document)

3. PRODUCT OVERVIEW

The pangshi C12 is a versatile 2-in-1 device that functions as both an extendable selfie stick and a stable tripod. It features an integrated AI camera for automatic face tracking and a detachable wireless remote control for convenient operation.



Image: The pangshi C12 device shown as a compact unit, extended as a tripod, and extended as a selfie stick, alongside its wireless remote control.

Key Features:

- **AI Face Tracking:** Built-in AI camera for real-time face tracking without requiring an app.
- **Versatile Design:** Functions as a selfie stick (up to 70.9 inches) and a stable tripod.
- **360° Rotation:** Horizontal 360° and vertical 270° rotation for flexible shooting angles.
- **Gesture Control:** Activate tracking with an 'OK' gesture and pause with a 'Palm' gesture.
- **Wireless Remote:** Detachable remote control for convenient operation up to 10 meters.
- **Universal Compatibility:** Adjustable phone holder (2.35" to 3.75") and standard 1/4" screw mount for various devices.
- **Portable:** Folds to 12.6 inches and weighs 542g for easy transport.

All-in-one Phone Tripod & Selfie Stick



Image: Illustrations of the pangshi C12 used as a floor tripod, a desk tripod, and an extended selfie stick, demonstrating its multi-functional design.

4. SETUP

4.1 Unfolding the Tripod

1. Hold the main body of the tripod.
2. Press the button located at the base to release and automatically extend the tripod legs. Ensure the legs are fully spread for maximum stability.

360° Rotating Balance Handle for Stable Shooting



Image: A detailed view of the tripod's base, highlighting the one-button mechanism for opening the legs and the four metal keels designed for enhanced stability.

4.2 Mounting Your Device

1. **For Smartphones:** Extend the phone holder clamp and securely place your smartphone. The holder accommodates devices from 2.35" to 3.75" wide.
2. **For Cameras/Other Devices:** The top features a standard 1/4" screw mount. Attach compatible digital cameras, action cameras, webcams, or camcorders.

4.3 Charging the Device

Connect the provided USB charging cable to the charging port on the tripod and a suitable USB power source. The device uses 2 Lithium Metal batteries (included).

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **Power On:** Press and hold the power button on the device until the indicator light illuminates.
- **Power Off:** Press and hold the power button again until the indicator light turns off.

5.2 Pairing the Wireless Remote Control

The remote control is designed for quick and hassle-free pairing with both iOS and Android devices.

1. Ensure the remote control is charged and powered on.
2. On your smartphone, enable Bluetooth and search for available devices.
3. Select the device named 'pangshi Remote' (or similar) to pair.
4. Once paired, you can use the remote to trigger your phone's camera shutter from up to 10 meters away.

5.3 Using Auto Face Tracking

The C12 features an intelligent AI camera that tracks your face automatically without the need for any external applications.



Image: A visual representation of the 360-degree auto face tracking feature, demonstrating how the device keeps a person centered in the frame, along with icons for 'Palm Gesture' to start tracking and 'OK Gesture' to stop tracking.

- **Activate Tracking:** Make an 'OK' gesture with your hand in front of the device's camera. The device will begin tracking your face.
- **Pause Tracking:** Make a 'Palm' gesture with your hand in front of the device's camera. Tracking will pause.

5.4 Adjusting Angles and Height

The tripod offers extensive adjustability for various shooting requirements.



Image: A diagram illustrating the multi-angle rotation capabilities of the phone tripod, including 360-degree horizontal rotation, 270-degree vertical rotation, and adjustable height from 12.6 inches to 70.9 inches. It also shows examples of horizontal, vertical, and side shots.

- **Horizontal Rotation:** The device can rotate 360° horizontally to follow movement.
- **Vertical Rotation:** The phone holder can be adjusted up to 270° vertically.
- **Height Adjustment:** Extend the telescopic pole to adjust the height from a minimum of 12.6 inches to a maximum of 70.9 inches. Secure the pole at the desired height.
- **Orientation:** Easily switch between portrait and landscape orientations by rotating your phone within the holder.

6. MAINTENANCE

- Clean the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the tripod in a cool, dry place when not in use.
- Ensure the charging port is free from dust and debris.

7. TROUBLESHOOTING

- **Device not powering on:** Ensure the device is fully charged. Connect it to a power source using the USB cable.
- **Face tracking not working:** Ensure there is sufficient lighting. Make sure your face is clearly visible to the AI camera. Try recalibrating by making the 'OK' gesture again.
- **Remote control not connecting:** Check if Bluetooth is enabled on your phone and the remote is powered on. Re-pair the remote if necessary.
- **Unstable footage:** Ensure the tripod legs are fully extended and placed on a flat, stable surface. For selfie stick mode, hold the device firmly.
- **Motor sound during tracking:** Some users may notice a slight motor sound during rotation. This is normal operation for the tracking mechanism.

8. SPECIFICATIONS

Feature	Specification
Model Number	pangshi C12
Product Dimensions (Folded)	1.3"D x 2.8"W x 12.5"H
Minimum Height	12.6 Inches
Maximum Height	70.9 Inches
Item Weight	1.15 pounds (520 Grams)
Material	Acrylonitrile Butadiene Styrene (ABS), Aluminum
Compatible Devices	Smartphone, Camera, Camcorder, Projector, Telescope
Special Features	Telescopic, Remote Control, Foldable, Pan-handle, Auto Face Tracking
Batteries	2 Lithium Metal batteries (included)

9. WARRANTY AND SUPPORT

For any questions, technical assistance, or support regarding your pangshi C12 Auto Face Tracking Selfie Stick Tripod, please refer to the contact information provided with your purchase or visit the official pangshi website. We are committed to providing reliable products and customer satisfaction.