HMHAMA 4 Filter

HMHAMA Replacement Filter Kit

For Vactidy Nimble T8/T7 Robotic Vacuum Cleaners

Introduction

This manual provides instructions for the installation, maintenance, and troubleshooting of the HMHAMA Replacement Filter Kit for Vactidy Nimble T8 and T7 robotic vacuum cleaners. Regular replacement of filters ensures optimal cleaning performance and maintains air quality.

Compatible Models

This replacement filter kit is compatible with the following robotic vacuum cleaner models:

- Vactidy Nimble T8
- Vactidy Nimble T7

Please verify your vacuum cleaner model before proceeding with installation.

Setup and Installation

Follow these steps to replace the filter in your Vactidy Nimble T8 or T7 robotic vacuum cleaner.

1. **Power Off:** Ensure your robotic vacuum cleaner is powered off and disconnected from its charging base before beginning any maintenance.
2. **Locate Dust Bin:** Open the top cover of your vacuum cleaner and locate the dust bin. Refer to your vacuum's original manual if you have difficulty locating it.
3. **Remove Dust Bin:** Carefully remove the dust bin from the vacuum cleaner.
4. **Remove Old Filter:** Open the dust bin cover and remove the old filter. Dispose of the old filter responsibly.
5. **Insert New Filter:** Take a new HMHAMA replacement filter. Ensure the filter is oriented correctly and gently press it into the designated slot within the dust bin until it is securely in place.
6. **Close Dust Bin:** Close the dust bin cover and reinsert the dust bin into the vacuum cleaner.
7. **Power On:** Close the vacuum's top cover and power on the device.






Image: A single HMHAMA replacement filter, ready for installation. This filter is designed to capture fine dust and allergens.

Maintenance

Regular maintenance of your filters is crucial for maintaining the cleaning efficiency of your robotic vacuum.

- **Cleaning Frequency:** It is recommended to clean the filter every 1-2 weeks, depending on usage and household dust levels.
- **Cleaning Method:** Gently tap the filter against a trash can to remove loose dust and debris. A small brush (often included with vacuum cleaners) can be used to brush away stubborn particles. **Do not wash the filter with water**, as this can damage the filter material and reduce its effectiveness.
- **Replacement Frequency:** For optimal performance, replace the filter every 3-6 months. The HMHAMA kit provides multiple filters to meet this requirement.




Image: Two HMHAMA replacement filters, illustrating the quantity provided in some kits for regular replacement.

Troubleshooting

If you encounter issues related to the replacement parts, consider the following:

- **Reduced Suction Power:** A clogged or improperly installed filter can lead to reduced suction. Ensure the filter is clean and correctly seated in the dust bin. If the filter is old, replace it with a new one.
- **Unusual Noises:** If you hear unusual noises after replacing parts, double-check that all components, including the filter, are installed correctly and securely.
- **Bent Side Brush (if applicable):** While this kit is for filters, other HMHAMA kits may include side brushes. If a side brush appears bent or curled upon arrival, soak it in warm water for a few minutes. This will help it regain its original shape without affecting its quality or performance.

Specifications

Feature	Detail
Compatible Devices	Vactidy Nimble T7, Vactidy Nimble T8
Material	Plastic
Reusability	Reusable (with proper cleaning)
Number of Pieces (in 4 Filter kit)	4 Filters
Item Weight (per filter)	Approximately 0.96 ounces (27 grams)
Package Dimensions	7.87 x 5.51 x 1.57 inches




Image: Diagram showing the dimensions of various replacement parts, including the filter (bottom right, 110mm x 48mm).

Warranty and Support

HMHAMA is committed to customer satisfaction. If you encounter any issues or have questions regarding your purchase, please contact our after-sales team.

- **Satisfaction Guarantee:** We offer a satisfaction guarantee. If you have problems before or after your purchase, please contact us promptly via email.
- **Response Time:** Our after-sales team aims to reply and resolve your problem within 24 hours.

For support, please refer to the contact information provided with your purchase or on the product packaging.

© 2023 HMHAMA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question