Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TAKARA TOMY B0DB7CL4TY

TAKARA TOMY Transformers One Optimus Prime Action Figure Instruction Manual

Model: B0DB7CL4TY

Introduction

This manual provides instructions for the TAKARA TOMY Transformers One 8-inch Leader Class Optimus Prime action figure. This figure is a detailed reproduction of the "Brave Commander Optimus Prime" from the 3DCG animated film "Transformers ONE". It transforms between robot mode and truck vehicle mode, featuring poseable joints and various accessories.

Safety Information

- Recommended for ages 6 years and up.
- Keep small parts away from young children to prevent choking hazards.
- Do not force joints or transformation steps, as this may cause damage.
- This product does not use batteries.

Package Contents

Verify that all items are present in the package:

- Optimus Prime Main Unit (1)
- Energy Axe (1)
- Matrix (1)
- Instruction Manual (1)



Image: The Energy Axe and Matrix accessories included with the Optimus Prime figure.

Setup

No assembly is required for the main unit. Remove the figure and accessories from the packaging carefully.

1. Unpack the Optimus Prime figure and all accessories.
2. Inspect the figure for any damage. If damaged, contact customer support.

Operating the Figure

Transformation: Robot Mode to Vehicle Mode

The Optimus Prime figure transforms from robot mode to truck vehicle mode. Follow the steps outlined in the included instruction manual for detailed transformation sequences. Ensure all joints are properly aligned during transformation to avoid damage.



Image: Optimus Prime in robot mode (left) and partially transformed into vehicle mode (right), illustrating the transformation capability.



Image: Optimus Prime figure fully transformed into its truck vehicle mode.

Robot Mode Features

- **Poseability:** The figure is fully poseable, allowing for dynamic display and recreation of movie scenes.
- **Face Options:** You can choose between two types of faces in robot mode: with the mask on or with the mask off.



Image: Close-up of Optimus Prime's head, demonstrating the interchangeable face options (masked and unmasked).

- **Energy Cannons:** Both shoulders feature energy cannons that can be deployed in both robot and vehicle modes.
- **Matrix of Leadership:** The chest can store the Matrix. The Matrix can be removed and held in both hands by the figure.



Image: Optimus Prime figure with its chest compartment open, showing the Matrix of Leadership stored inside.



Image: Optimus Prime figure holding the Matrix of Leadership with both hands, demonstrating its ability to interact with the accessory.

- **Energy Axe:** The included Energy Axe weapon can be attached to the figure's fist.

Maintenance

- **Cleaning:** Wipe the figure with a soft, dry cloth to remove dust. For stubborn dirt, use a slightly damp cloth and dry immediately. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure away from direct sunlight and extreme temperatures to prevent discoloration or material degradation.
- **Handling:** Handle the figure with care, especially during transformation, to avoid stressing joints or breaking small parts.

Troubleshooting

- **Difficulty Transforming:** Refer to the detailed transformation steps in the included instruction manual. Ensure all parts are correctly aligned before attempting to move them. Do not force parts.
- **Loose Joints:** Over time, joints may become slightly loose with repeated use. This is normal wear and tear.
- **Missing Parts:** If any parts were missing from the original package, contact customer support immediately.

Specifications

Attribute	Detail
Product Name	Transformers One Brave Commander Optimus Prime
Model Number (ASIN)	B0DB7CL4TY
Brand	TAKARA TOMY
Product Dimensions	2.76 x 4.72 x 7.87 inches
Product Weight	1.34 pounds
Recommended Age	6 years and up
Power Source	Does not use batteries

Warranty and Support

For warranty information or customer support, please refer to the contact details provided in the original product packaging or visit the official TAKARA TOMY website. Keep your purchase receipt as proof of purchase.

© 2024 TAKARA TOMY. All rights reserved. Transformers and all related characters are trademarks of Hasbro.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DB7CL4TY

More documents and user manuals: **https://manuals.plus/**