



Manuals.plus /

- › VEVOR /
- › VEVOR C75 Portable Refrigerator Freezer User Manual

VEVOR C75

VEVOR C75 Portable Refrigerator Freezer User Manual

Model: C75

INTRODUCTION

Thank you for choosing the VEVOR C75 Portable Refrigerator Freezer. This versatile appliance is designed to keep your food and beverages chilled or frozen, making it ideal for outdoor adventures, camping, RV trips, and long drives. With its robust compressor cooling technology and dual power options (12/24V DC and 100-240V AC), the C75 offers reliable performance and convenience wherever you go. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure you get the most out of your new portable freezer.



Image: The VEVOR C75 portable refrigerator freezer, showcasing its interior capacity filled with various items like bottles and fruits. A smartphone displaying the control app is also visible, highlighting its smart features.

SAFETY INFORMATION

Please read all safety warnings and instructions carefully before using the appliance to prevent injury or damage. Keep this manual for future reference.

- Ensure the power supply voltage matches the appliance's requirements (12/24V DC or 100-240V AC).
- Do not operate the appliance if the power cord is damaged.
- Keep the ventilation openings clear of obstructions.
- Do not use electrical appliances inside the storage compartment unless they are of the type recommended by the manufacturer.

- Avoid touching cold surfaces with bare hands when the appliance is operating at freezing temperatures to prevent frostbite.
- Do not immerse the appliance in water or expose it to heavy rain.
- Always disconnect the power supply before cleaning or performing maintenance.

WHAT'S IN THE BOX

- 1 x Portable Car Refrigerator
- 1 x User Manual
- 1 x AC Power Cord
- 1 x Cigarette Lighter Cord (DC)
- 1 x Adapter

SETUP

Initial Placement and Power Connection

Before first use, ensure the refrigerator is placed on a stable, level surface. Allow it to stand upright for at least 6 hours if it has been transported horizontally, to allow the compressor oil to settle. Connect the appropriate power cord (AC for home use, DC for vehicle use) to the power input port on the unit.



SPECIFICATIONS

Item Model Number:
C75

Voltage:
AC100-240V--DC 12/24V

Power:
80W

Temperature Adjustable Range:
- 20 ~ 20 °C / -4 ~ 68 °F

Capacity:
70 L / 74 qt

Net Weight:
16.5 kg / 36.4 lbs

Noise:
≤ 45dB

Inner Liner Material:
Vacuum-formed HIPS

Outer Shell Material:
ABS + Pre-coated Board

Image: The VEVOR C75 portable refrigerator freezer with its AC power adapter and DC car cigarette lighter cord, illustrating the dual power options for home and vehicle use.

Bluetooth App Setup

The VEVOR C75 features Bluetooth connectivity for remote control via a mobile application. Download the official VEVOR app from your smartphone's app store. Once installed, open the app and follow the on-screen instructions to pair with your refrigerator. This allows you to monitor and adjust settings conveniently from your device.

2 CONTROL MODES

Multiple mode settings, real-time monitoring



LED Control Panel

Smartphone Bluetooth App Control

Image: The VEVOR C75's LED control panel and a smartphone interface demonstrating the Bluetooth app control for temperature and mode adjustments.

OPERATING INSTRUCTIONS

Powering On/Off

Press and hold the power button on the control panel to turn the unit on or off. The LED display will illuminate, showing the current internal temperature.

Temperature Control

Use the '+' and '-' buttons on the control panel or the slider in the mobile app to adjust the desired temperature. The adjustable range is from -20°C to 20°C (-4°F to 68°F). The unit will automatically cool or heat to maintain the set temperature.

ECO and Max Modes

The C75 offers two operating modes: ECO and Max. Long press the settings button on the control panel or select via the app to switch between modes.

- **ECO Mode:** Energy-saving mode, ideal for prolonged use with lower power consumption (less than 38W).
- **Max Mode:** Provides rapid cooling for quicker temperature changes (up to 43W).




Image: A visual representation of the ECO (38W) and MAX (43W) power consumption modes available on the VEVOR C75, indicating their respective energy usage.

Battery Protection

The unit features a battery protection system with Low, Medium, and High settings to prevent your vehicle's battery from draining. Adjust this setting via the mobile app or control panel based on your battery type and usage needs. The refrigerator will automatically shut off if the battery voltage drops below the set protection level.

Capacity and Usage

The 70L (74qt) single compartment offers ample space for various items. It can function as both a refrigerator and a freezer. Ensure items are placed to allow for proper air circulation.

VEVOR®

70 L / 74 QT SINGLE ZONE
Large capacity suitable for long trip



Image: The VEVOR C75 portable refrigerator freezer displayed in an outdoor setting, highlighting its large 70L/74QT capacity, capable of holding numerous bottles of water or cans of cola.

REFRIGERATION & PRESERVATION 2 STORAGE MODES

Adjustable Temperature Range: -20 ~ 20 °C / -4 ~ 68 °F



Beverages



Water



Meat



Ice Cream



Seafood



Fruits

Image: An overhead view of the VEVOR C75's interior, showcasing its versatility for storing various items like beverages, water, meat, ice cream, seafood, and fruits within its adjustable temperature range.

MAINTENANCE

Cleaning

Regularly clean the interior and exterior of the refrigerator with a damp cloth and mild detergent. Do not use abrasive cleaners or harsh chemicals. Ensure the unit is unplugged before cleaning. For stubborn stains, a small amount of baking soda mixed with water can be used.

Defrosting

The C75 features a frost-free defrost system. However, if ice buildup occurs, turn off the unit and allow the ice to melt naturally. Do not use sharp objects to remove ice, as this can damage the internal components.

Storage

When storing the refrigerator for extended periods, ensure it is clean and dry. Leave the lid slightly ajar to prevent odors and mildew. Store in a cool, dry place away from direct sunlight.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit not powering on	No power supply; damaged cable; low battery voltage (in DC mode).	Check power connection; replace damaged cable; charge vehicle battery or adjust battery protection setting.
Not cooling effectively	Blocked ventilation; excessive items inside; lid not sealed properly; ambient temperature too high.	Clear vents; ensure proper air circulation; check lid seal; move to a cooler environment if possible.
Unusual noise	Unit not level; internal components vibrating.	Ensure unit is on a stable, level surface. If noise persists, contact support.
Bluetooth connection issues	App not updated; Bluetooth off on phone/unit; interference.	Update app; ensure Bluetooth is enabled; restart unit and phone; try pairing again.

SPECIFICATIONS

Feature	Detail
Model Number	C75
Capacity	70 Liters / 74 Quarts
Temperature Range	-20°C to 20°C (-4°F to 68°F)
Voltage	12/24V DC, 100-240V AC
Power (ECO/Max)	~38W (ECO), ~43W (Max)
Noise Level	≤ 45dB
Item Weight	36.4 Pounds
Product Dimensions	25.59 x 26.46 x 14.76 inches (D x W x H)
Defrost System	Frost Free
Included Components	Portable Car Refrigerator, User Manual, AC Power Cord, Cigarette Lighter Cord, Adapter

WARRANTY AND SUPPORT

VEVOR products are designed for durability and performance. For specific warranty details and support, please refer to the warranty card included with your product or visit the official VEVOR website. Our customer service team is available to assist with any questions or issues you may encounter.

For further assistance, please contact VEVOR customer support through their official channels.

