Xgody X60

Xgody X60 4G Unlocked Cell Phone User Manual

Model: X60

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Xgody X60 4G Unlocked Cell Phone. Please read this guide thoroughly to ensure proper use and to maximize the performance of your device.

Image: Overview of Xgody X60 key features.

PACKAGE CONTENTS

Verify that all items are present in your product package:

- Xgody X60 Cell Phone
- HD Screen Protector
- Tempered Film
- Phone Case
- USB Cable
- User Manual (this document)
- Packing Box

Image: Xgody X60 package contents.

SETUP

1. Installing SIM and MicroSD Cards

The Xgody X60 supports dual SIM cards (1 Nano SIM, 1 Micro SIM) and one MicroSD card for expandable storage up to 256GB. Follow these steps to install them:

1. Carefully remove the back cover of the phone.

2. Locate the SIM card slots and MicroSD card slot.

3. Insert the Nano SIM card into the designated slot.

4. Insert the Micro SIM card into its designated slot.

5. Insert the MicroSD card (if applicable) into the MicroSD card slot.

6. Ensure all cards are seated correctly.

7. Replace the back cover securely.

Image: SIM and MicroSD card installation steps.

2. Battery Installation

The Xgody X60 uses a removable 3000mAh Lithium-Ion battery. After installing SIM/MicroSD cards, insert the battery:

1. Align the battery contacts with the phone's contacts.

2. Gently press the battery into its compartment until it is secure.

3. Replace the back cover.

3. Initial Power On and Face Unlock Setup

To power on your device for the first time:

1. Press and hold the power button until the Xgody logo appears.

2. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

3. During setup, you will have the option to configure Face Unlock. This feature allows you to unlock your phone using facial recognition. Follow the instructions to register your face.


Image: Face Unlock feature for privacy protection.

## OPERATING YOUR XGODY X60

Basic Functions

The Xgody X60 runs on Android 9.0 OS, providing a user-friendly interface for calls, messaging, and internet browsing. The 6.0-inch QHD display offers a clear visual experience.

Most Comfortable Grip Size
The ergonomically designed size makes it easy to hold.

480*960
High Resolution

18:9
Aspect Ratio

6"
6"
HQD Display

Image: Xgody X60 in hand, demonstrating comfortable grip and display size.

Camera Usage

The Xgody X60 is equipped with a 5MP front camera and a 5MP rear camera. These cameras support various shooting modes, including panorama and time-lapse, allowing you to capture photos and videos.

- **Front Camera:** 5 MP for selfies and video calls.
- **Rear Camera:** 5 MP for general photography.
- **Shooting Modes:** Program, Panorama, Time-lapse.

See The World Through HD Camera

5MP
Front camera

5MP
Rear camera

Panorama

Time lapse

Image: Xgody X60 camera features and sample photos.

Memory and Storage

The device comes with 2GB RAM and 16GB internal storage. Storage can be expanded up to 256GB using a MicroSD card (not included).

Image: Xgody X60 with various applications, demonstrating memory capabilities.

Dual SIM Functionality

The Xgody X60 supports Dual SIM Dual Standby, allowing you to use two different SIM cards simultaneously. This is useful for managing personal and work contacts or for international travel.

Image: Dual SIM and expandable storage features.

Maintenance

Battery Care

The Xgody X60 is powered by a 3000mAh battery, designed to provide extended usage. To maintain optimal battery life:

- Charge the phone using the provided USB cable.
- Avoid extreme temperatures, as they can degrade battery performance.
- For prolonged storage, charge the battery to about 50% and store in a cool, dry place.

Image: Battery charging and estimated usage times.

Cleaning and Protection

To keep your phone in good condition:

- Wipe the screen and body with a soft, lint-free cloth.
- Avoid using harsh chemicals or abrasive materials.
- The phone has a water-resistant level; however, it is not waterproof. Avoid submerging it in water.
- Use the provided phone case and screen protectors to guard against scratches and minor impacts.

TROUBLESHOOTING

Network Connectivity Issues

If you experience issues with network connectivity (calls, data), consider the following:

- Ensure your SIM card is correctly inserted and activated with your carrier.

- Check your phone's network settings to confirm it is configured for the correct network type (4G LTE, 3G, 2G).
- Verify that your carrier supports the network bands of the Xgody X60. The phone is compatible with T-Mobile networks and their MVNOs (excluding AT&T/Cricket, Verizon, or CDMA networks like Sprint and Boost Mobile).
- Restart your phone.

Xgody X60 Network Compatibility

Carrier	Supported Network Band (Carrier)	X60 Band	2G Supported	3G Supported	4G Supported
Asrruance Wireless	4G LTE 700/850/1700/1900 MHz 3G HSPA+/WCDMA: Band 2 (1900MHz), Band 5 (850MHz) 2G (GSM): Band 2 (1900MHz), Band 5 (850MHz)	4G LTE: Band 2 (1900MHz) 3G (WCDMA): Band 2 (1900MHz), Band 5 (850MHz) 2G (GSM): Band 2 (1900MHz), Band 5 (850MHz)	✓	✓	✓
T-Mobile	4G LTE 700/1700/2100 MHz 3G HSPA+/WCDMA: Band 4 (1700/2100MHz), Band 2 (1900MHz) 2G (GSM): Band 2 (1900MHz), Band 5 (850MHz)	4G LTE: Band 2 (1900MHz), Band 4 (1700MHz), Band 5 (850MHz), Band 7 (2600MHz), Band 28A (700MHz) 3G (WCDMA): Band 2 (1900MHz), Band 5 (850MHz) 2G (GSM): Band 2 (1900MHz), Band 5 (850MHz)	✓	✗	✓
Verizon	3G (CDMA EVDO/CDMA 2000); Band 4 (1700 / 2100MHz), Band 2 (1900MHz) 2G (CDMA): Band 2 (1900MHz), Band 5 (850MHz)	4G LTE: Band 2 (1900MHz) 3G (WCDMA): Band 2 (1900MHz), Band 5 (850MHz) 2G (GSM): Band 2 (1900MHz), Band 5 (850MHz)	✗	✗	✗
Sprint	4G LTE 800/1900/2500 MHz 3G CDMA EVDO/CDMA2000) Band 2 (1900MHz) 2G (CDMA): Band 2 (1900MHz), Band 10 (800MHz)	4G LTE: Band 2 (1900MHz) 3G (WCDMA): Band 2 (1900MHz), Band 5 (850MHz) 2G (GSM): Band 2 (1900MHz), Band 5 (850MHz)	✗	✗	✗

Image: Network compatibility table for Xgody X60.

Performance Issues

If your phone is slow or experiencing glitches:

- Close unnecessary background applications.

- Clear cache and data for apps that are causing issues.
- Ensure you have sufficient free storage space.
- Perform a factory reset as a last resort (back up your data first).

SPECIFICATIONS

Feature	Detail
Brand	Xgody
Model Name	X60
Operating System	Android 9.0
RAM Memory Installed Size	2 GB
Memory Storage Capacity	16 GB
Flash Memory Supported Size Maximum	256 GB (MicroSD)
CPU Model	MediaTek MT6737 (Quad-Core)
CPU Speed	2 GHz
Screen Size	6 Inches
Display Resolution Maximum	480 x 960 (QHD)
Display Type	LCD
Front Photo Sensor Resolution	5 MP
Rear Camera Resolution	5 MP
Video Capture Resolution	720p
Battery Capacity	3000 mAh (Lithium-Ion)
SIM Card Slot Count	Dual SIM (1 Nano, 1 Micro)
Biometric Security Feature	Face Recognition
Connectivity Technology	Bluetooth, USB, Wi-Fi
Cellular Technology	4G (LTE), 3G (WCDMA), 2G (GSM)
Wireless Carrier Compatibility	T-Mobile (and MVNOs)
Connector Type	Micro USB
Headphones Jack	3.5 mm
Water Resistance Level	Water Resistant
Item Weight	15 Grams

WARRANTY INFORMATION

The Xgody X60 comes with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you encounter any challenges while using your Xgody X60, our professional after-sales team is available to assist you. Please reach out to us with your concerns. We are committed to reviewing your inquiries promptly and providing a solution.

- Concerns reviewed within 12 hours.
- Solutions provided within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official Xgody website.