

[Manuals.plus](#) /

› [LITFAD](#) /

› LITFAD Floating TV Stand Instruction Manual (Model LT1266293W)

LITFAD LT1266293W

LITFAD Floating TV Stand Instruction Manual

Model: LT1266293W

1. INTRODUCTION

Thank you for choosing the LITFAD Floating TV Stand, Model LT1266293W. This modern wall-mounted entertainment center is designed to provide a stylish and space-saving solution for your living room, bedroom, or hotel environment. Crafted from manufactured wood, it features three flip-down storage compartments and a sleek white finish. This manual provides essential information for safe installation, proper use, and maintenance of your new TV stand.



Image 1.1: The LITFAD Floating TV Stand (Model LT1266293W) in a living room setting, showcasing its wall-mounted design and integrated storage.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Wall Mounting:** This TV stand is designed for wall mounting. Ensure the wall structure is capable of supporting the weight of the stand and any items placed on it. Consult a professional if unsure about wall suitability.
- **Weight Capacity:** Do not exceed the maximum weight capacity of the stand. Overloading can cause the unit to detach from the wall, leading to injury or damage. Specific weight limits are not provided; exercise caution.
- **Secure Installation:** Use appropriate hardware for your wall type (drywall, wooden studs, plastered walls, solid walls). Ensure all mounting screws and anchors are securely fastened.
- **Child Safety:** Keep small parts and packaging materials away from children. Ensure the unit is securely mounted to prevent tipping hazards.
- **Material Safety:** The stand is constructed from environmentally-friendly wood, free from formaldehyde and strong odors, making it suitable for use in homes with pregnant women, children,

and the elderly.

- **Electrical Cords:** Route all electrical cords safely to prevent tripping hazards and damage to the cords. Utilize the provided cable management openings if available.

3. SETUP AND INSTALLATION

The LITFAD Floating TV Stand requires assembly and secure wall mounting. An instruction manual and assembly tools are included with your purchase.

3.1. Before You Begin

- **Unpack:** Carefully unpack all components and check against the parts list (provided in the included manual) to ensure all pieces are present and undamaged.
- **Tools Required (not exhaustive):** You may need a drill, level, measuring tape, stud finder (for drywall), and screwdriver.
- **Choose Location:** Select a suitable wall location, considering the height, proximity to power outlets, and wall material. This stand is suitable for dry walls, wooden walls, plastered walls, and solid walls.
- **Dimensions:** Refer to the product dimensions to plan your installation space. The stand measures approximately 47 inches (L) x 9 inches (W) x 7.5 inches (H).



Image 3.1: Dimensional overview of the TV stand, indicating its length, width, and height for installation planning.

3.2. Assembly Steps (General Guidance)

Follow the detailed step-by-step instructions provided in the separate assembly manual included in your package. The general process involves:

1. Assemble the main frame of the TV stand using the provided hardware.
2. Attach the flip-down doors to the cabinet using the hinges. Ensure hinges are properly aligned and secured for smooth operation.

3. Identify the wall mounting points on the back of the assembled unit.
4. Mark the desired mounting height on your wall. Use a level to ensure the marks are perfectly horizontal.
5. Drill pilot holes at the marked locations, suitable for your wall type and the provided wall anchors/screws.
6. Insert wall anchors if necessary.
7. Carefully lift the TV stand and align its mounting points with the drilled holes.
8. Secure the TV stand to the wall using the appropriate screws. Ensure it is firmly attached and does not wobble.



Image 3.2: The internal structure and hinges of the storage compartments, illustrating how the flip-down doors operate.

4. OPERATING INSTRUCTIONS

The LITFAD Floating TV Stand is designed for straightforward use as a media console and storage unit.

- **Storage:** Utilize the three flip-down compartments to store media accessories such as remote controls, cables, gaming controllers, or small electronic devices.
- **Cable Management:** The top surface may feature pre-drilled holes for cable routing, allowing you to neatly organize wires from your TV and media devices.

- **Placement of Devices:** Place lightweight media devices (e.g., soundbars, streaming boxes) on the top surface, ensuring they do not exceed the stand's weight capacity.

5. MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your LITFAD Floating TV Stand.

- **Cleaning:** Wipe the surface with a dry, soft cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood material.
- **Inspection:** Periodically check all mounting hardware and screws to ensure they remain tight and secure. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the finish.
- **Heat Sources:** Keep the stand away from direct heat sources to prevent warping or damage.

6. TROUBLESHOOTING

If you encounter any issues with your LITFAD Floating TV Stand, refer to the following common solutions:

- **Stand feels wobbly after installation:**
 - Ensure all wall mounting screws are fully tightened.
 - Verify that the wall anchors are correctly installed and suitable for your wall type.
 - Check if the wall surface is even. Uneven surfaces can affect stability.
- **Doors do not close properly:**
 - Check the hinge alignment and ensure all hinge screws are tight.
 - Adjust the hinges if they are adjustable to ensure proper door closure.
- **Scratches or minor damage:**
 - For minor scratches, a furniture repair pen or touch-up paint matching the white finish may be used.
 - Contact customer support for advice on more significant damage.

7. SPECIFICATIONS

Brand	LITFAD
Model Number	LT1266293W
Dimensions (L x W x H)	47 inches x 9 inches x 7.5 inches (120cm x 22cm x 19cm)
Material	Manufactured Wood
Color	White
Number of Cabinets	3 (with flip-down doors)
Mounting Type	Wall Mounted

Care Instructions	Wipe with Dry Cloth
-------------------	---------------------

8. WARRANTY AND SUPPORT

Specific warranty details for the LITFAD Floating TV Stand are not provided in this manual. Please refer to the product packaging or the retailer's website for warranty information.

For any questions regarding assembly, parts, or product functionality, please contact LITFAD customer service. You can typically find contact information on the product packaging or by visiting the official LITFAD store page: [LITFAD Store](#).