

Manuals.plus /
› TRIUMPHKEY /
› TRIUMPHKEY Gaming Chair Model 0482 User Manual

TRIUMPHKEY 0482

TRIUMPHKEY Gaming Chair Model 0482 User Manual

Comprehensive Guide for Assembly, Operation, and Maintenance

INTRODUCTION

Thank you for choosing the TRIUMPHKEY Gaming Chair Model 0482. This ergonomic gaming chair is designed to provide comfort and support during long gaming sessions or work hours. It features a reclining backrest, a retractable footrest, and a built-in lumbar massage function. This manual provides detailed instructions for assembly, operation, and maintenance to ensure you get the most out of your new chair.



Image: The TRIUMPHKEY Gaming Chair Model 0482 in grey, showcasing its ergonomic design and lumbar massage feature.

SAFETY GUIDELINES

Please read and understand all safety information before assembling and using the chair. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Capacity:** The chair is designed for a maximum load of **150 kg**. Do not exceed this weight limit.
- **Surface Use:** Use the chair only on flat, indoor surfaces such as hardwood floors or carpets to ensure stability.
- **Children and Pets:** Keep children and pets away from the assembly area. Small parts can be a choking hazard.

- **Proper Assembly:** Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- **Avoid Standing:** Do not stand on the chair.
- **Moving the Chair:** When moving the chair, lift it rather than dragging it to prevent damage to the base or floor.
- **Electrical Components:** For the massage function, ensure the USB cable is connected properly and avoid exposing it to water or excessive force.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Backrest
- Seat Cushion
- Armrests (2)
- Star Base
- Casters (5)
- Gas Lift Cylinder
- Gas Lift Cover
- Mechanism Plate
- Lumbar Support Pillow with Massage Function
- Headrest Pillow
- Retractable Footrest
- Hardware Kit (screws, washers, Allen wrench)

ASSEMBLY GUIDE

Assembly typically takes about 20 minutes. Follow these steps carefully. It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.
2. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the star base. Cover it with the gas lift cover.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the screw holes on the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat. Secure with screws provided in the hardware kit.
4. **Attach Armrests to Seat:** Secure the armrests to the sides of the seat cushion using the provided screws. Do not overtighten initially.
5. **Connect Backrest to Seat:** Attach the backrest to the seat cushion by aligning the metal brackets on the backrest with the corresponding holes on the seat mechanism/armrests. Secure with screws. Once all screws are in place, tighten all armrest and backrest screws firmly.
6. **Mount Seat Assembly onto Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder. Press down firmly to secure.
7. **Attach Footrest:** Slide the retractable footrest into its designated slots under the seat.
8. **Attach Pillows:** Place the headrest pillow on top of the backrest and the lumbar support pillow in the lower back

area. The lumbar pillow has a USB cable for the massage function.



Image: An overview of the chair's components and features, useful for visual reference during assembly.

OPERATING YOUR CHAIR

Adjusting Chair Height

To adjust the chair's height, locate the lever on the right side, beneath the seat.

- **To raise:** Lift the lever while taking your weight off the seat. The chair will rise automatically.
- **To lower:** Lift the lever while seated. The chair will lower under your weight.

Reclining the Backrest

The backrest can be reclined between 90° and 150°.

- **To recline:** Pull the recline lever located on the right side of the seat, then lean back to your desired angle. Release

the lever to lock the backrest in position.

- **To return upright:** Pull the recline lever and lean forward.

SEDIA DA GAMING MASSAGGIANTE

Sedia da gaming con schienale reclinabile da 90° a 145°, poggiapiedi estensibile e funzione massaggiante per la zona lombare. Design ergonomico adatto a diversi utilizzi:



Lavoro



Gioco



Pisolino



Image: Illustration showing the adjustable recline angles of the chair, from 90 degrees (upright) to 145 degrees (reclined).

Using the Retractable Footrest

The footrest provides additional comfort when reclining.

- **To extend:** Pull the footrest out from under the seat.
- **To retract:** Push the footrest back under the seat until it is fully stored.

Activating the Lumbar Massage Function

The lumbar pillow features a 2-point massage function.

- **To activate:** Connect the USB cable from the lumbar pillow to a compatible USB power source (e.g., computer, power bank, USB wall adapter).

- **To deactivate:** Disconnect the USB cable.

MASSAGGIO LOMBARE ELETTRICO

Massaggio a doppio punto ad alta frequenza – basta collegare il cavo USB per alleviare la fatica in qualsiasi momento.




Image: Close-up of the lumbar support pillow, illustrating the two-point massage function with glowing blue circles.

CARE AND MAINTENANCE

Regular care will extend the life and appearance of your TRIUMPHKEY Gaming Chair.

- **Cleaning:** Wipe the chair's surface with a soft, damp cloth. For stubborn stains, use a mild soap solution and then wipe with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading and material degradation.
- **Moving Parts:** Periodically check all screws and bolts and re-tighten them if necessary to ensure stability and safety.
- **Casters:** Keep casters clean from hair and debris to ensure smooth movement.

TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair wobbles or is unstable.	Loose screws or uneven floor.	Ensure all assembly screws are tightened. Move the chair to a flat surface.
Gas lift does not adjust height.	Gas lift is faulty or lever is not engaged.	Check if the lever is fully engaged. If the issue persists, the gas lift may need replacement. Contact customer support.
Backrest does not recline or lock.	Recline mechanism is jammed or faulty.	Ensure no obstructions are preventing movement. Check the recline lever for proper function.
Lumbar massage not working.	USB power issue or cable disconnected.	Ensure the USB cable is securely connected to a working power source. Try a different USB port or power bank.
Casters do not roll smoothly.	Debris caught in casters.	Remove any hair or debris from the caster wheels.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	TRIUMPHKEY
Model	0482
Color	Grey (as per current product variant)
Product Dimensions	66 x 66 x 130 cm (L x W x H)
Seat Dimensions	Approx. 50 cm (width)
Adjustable Height	Yes
Recline Angle	90° to 150°
Weight Capacity	150 kg
Special Features	Adjustable Height, Wheels, Ergonomic Design, Lumbar Massage, Retractable Footrest
Item Weight	20.5 Kilograms

Capacità di carico massima

150 kg

Altezza adatta

150-190 cm



Image: Detailed diagram illustrating the dimensions of the TRIUMPHKEY Gaming Chair.

WARRANTY AND CUSTOMER SUPPORT

TRIUMPHKEY is committed to providing high-quality products and excellent customer service. For warranty information, technical support, or to report missing/damaged parts, please contact your retailer or visit the official TRIUMPHKEY website. Please have your model number (0482) and purchase date ready when contacting support. For further assistance, you may visit the [TRIUMPHKEY Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DB84K1XF>

More documents and user manuals: **<https://manuals.plus/>**