

Jxrev J53

Jxrev J53 Wireless Earbuds

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the Jxrev J53 Wireless Earbuds. These earbuds are designed to provide a high-quality audio experience with advanced features for convenience and durability. This manual will guide you through the setup, operation, and maintenance of your new earbuds.

The Jxrev J53 earbuds feature 13mm dynamic speakers for Hi-Fi stereo sound and deep bass. Environmental Noise Cancellation (ENC) technology reduces ambient noise by up to 35dB for clearer calls. The portable charging case includes an LED power display to show real-time battery status. With an IP7 waterproof nano-coating, these earbuds are suitable for sports and various weather conditions.

2. What's in the Box

- Jxrev J53 Wireless Earbuds (2 units)
- Portable Charging Case
- USB Charging Cable
- User Manual

3. Setup

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the charging case to a power source using the provided USB cable. The LED display on the case will show the charging progress and battery levels.

A full charge for the earbuds takes approximately 1 hour, providing up to 8 hours of playback. The fully charged case can provide about 4 additional recharges, extending total playback time to 40 hours.



Image: Blue Jxrev J53 earbuds in charging case with LED display showing battery levels and playback times.



Image: Rose Jxrev J53 earbuds in charging case with LED display showing battery levels and playback times.

3.2 Pairing with Your Device

The Jxrev J53 earbuds utilize Bluetooth 5.3 technology for stable and fast connections. For the first connection, open the lid of the charging case. The earbuds will automatically enter pairing mode. On your device (smartphone, tablet, computer, laptop, or TV), go to Bluetooth settings and select "J53" from the list of available devices. Once connected, the earbuds will automatically reconnect to your device when the case lid is opened.

ADVANCED BLUETOOTH 5.4

Connecting and pairing in 1 second once you open the charging case.



Image: Diagram illustrating Bluetooth 5.3 connectivity of Jxrev J53 earbuds with various devices.

4. Operating Instructions

4.1 Touch Controls

Each earbud features a sensitive touch control key for managing music and calls without needing to access your phone. Specific touch functions may vary slightly, but generally include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap right earbud.
- **Previous Track:** Double tap left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Volume Up/Down:** Specific gestures may apply (refer to quick start guide for detailed gestures).



Image: Person wearing Jxrev J53 earbud, highlighting noise cancelling and touch control.

4.2 Single or Dual Earbud Mode

The Jxrev J53 earbuds can be used together for stereo sound or individually. To use a single earbud, simply take one out of the charging case. It will automatically connect to your device if previously paired. The other earbud can remain in the case or be used by another person for shared listening.

5. Maintenance

5.1 Water Resistance

The earbuds are equipped with an IP7 waterproof nano-coating, protecting them from sweat and light rain. This makes them suitable for workouts and outdoor activities. However, they are not designed for swimming or submersion in water. Ensure the earbuds are dry before placing them back into the charging case.

5.2 Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth to wipe the surfaces. Avoid using abrasive materials or harsh chemicals. For earbud grilles, gently remove any debris with a small, soft brush.

6. Troubleshooting

- **Earbuds not pairing:** Ensure both earbuds are charged and out of the case. Turn off Bluetooth on your device, then turn it back on and try pairing again.
- **Only one earbud working:** Place both earbuds back into the charging case, close the lid, then open it again. This should reset the connection.
- **Low volume or poor sound quality:** Check the volume settings on your device. Ensure the earbuds are clean and properly seated in your ears.
- **Charging issues:** Verify the charging cable and power adapter are working correctly. Ensure the charging contacts on the earbuds and case are clean and free of debris.

7. Specifications

Feature	Specification
Brand	Jxrev
Model Name	J53
Ear Placement	In Ear
Form Factor	In Ear
Control Type	Media Control
Control Method	Touch
Audio Driver Type	Dynamic Driver
Audio Driver Size	13 Millimeters
Connectivity Technology	Wireless
Wireless Technology	Bluetooth
Bluetooth Version	5.3
Water Resistance Level	Water Resistant (IP7)
Additional Features	Ergonomic, Lightweight, Noise Cancellation (ENC)
Earbud Weight	3g (single earbud)
Total Playback Time	Up to 40 hours (with charging case)
Earbud Playback Time	Up to 8 hours (single charge)
Charging Time	Approx. 1 hour

8. Product Overview Video

Your browser does not support the video tag.

Video: An overview of the Jxrev J53 Wireless Earbuds, highlighting key features and design.

9. Warranty and Support

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official Jxrev website. Keep your purchase receipt for any warranty claims.