

[Manuals.plus](#) /

> [OUTON](#) /

> OUTON LED Floor Lamp with Double Head Instruction Manual

OUTON DGEUFL0032-ST-B

OUTON LED Floor Lamp with Double Head

INSTRUCTION MANUAL - MODEL: DGEUFL0032-ST-B

1. INTRODUCTION

Thank you for choosing the OUTON LED Floor Lamp. This manual provides detailed instructions for the assembly, operation, and maintenance of your new lamp. Please read this manual thoroughly before use to ensure proper function and safety. This lamp is designed to provide versatile and efficient lighting for various activities such as reading, working, sewing, drawing, and more.

Key features include a double-head design with 360-degree rotation, adjustable height, remote and touch control, dimmable brightness, four color temperatures, a 1-hour timer, and a memory function.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Ultra Large, Wide & Bright:** 26-inch wide, 18W, 1800LM LED double-head design with 360-degree rotation for extensive illumination.
- **Adjustable Height:** Innovative mechanism allows height adjustment up to 75 inches for optimal lighting.
- **Dual Control:** Smooth dimming via touch control and a remote control with up to 15 meters (49.3 feet) range.
- **Customizable Lighting:** Four distinct color temperatures (warm, warm white, cool white, daylight white) and 1%-100% stepless dimming.
- **Smart Functions:** 1-hour timer and memory function to recall last selected settings.
- **Easy Assembly & Long Lifespan:** Quick assembly in under 3 minutes with no tools required, and an estimated lifespan of 50,001+ hours.

2.2 Components

Familiarize yourself with the main components of your OUTON LED Floor Lamp:

- LED Lamp Head (Double Head Design)
- Flexible Gooseneck
- Adjustable Pole Sections
- Sturdy Metal Base

- Touch Control Panel (on pole)
- Remote Control
- Power Cord



Figure 2.1: Overview of the OUTON LED Floor Lamp with its remote control and different light modes.



Figure 2.2: Key adjustable features and components of the lamp, including its dimensions.

3. SETUP AND ASSEMBLY

The OUTON LED Floor Lamp is designed for quick and easy assembly, typically taking less than 3 minutes without the need for additional tools. Follow these steps:

1. **Assemble Lamp Body:** Carefully connect the telescoping pole sections by screwing them clockwise until secure.
2. **Connect to Base:** Attach the assembled pole to the sturdy metal base by spinning it clockwise until it is firmly connected.
3. **Position Lamp Head:** Adjust the flexible gooseneck and the double lamp heads to your desired position.
4. **Plug In:** Connect the power cord to a suitable electrical outlet.



Figure 3.1: Visual guide for assembling the floor lamp.

4. OPERATING INSTRUCTIONS

4.1 Touch Control

The touch control panel is located on the lamp pole. It allows for quick adjustments:

- **Power On/Off:** Short press the power button.
- **Adjust Brightness:** Slide your finger up or down the touch strip to adjust brightness from 1% to 100%.
- **Change Color Temperature:** Tap the color temperature icon to cycle through Warm White, Natural White, Daylight, and Cool White modes.
- **1-Hour Timer:** Long press the power button to activate the 1-hour timer. The lamp will automatically turn off after one hour.



Figure 4.1: Detail of the touch control panel on the lamp pole.

4.2 Remote Control

The included remote control offers convenient operation from up to 15 meters (49.3 feet) away. Ensure the remote has working batteries (not included, typically 2x AAA). The remote features dedicated buttons for:

- **Power On/Off**
- **1-Hour Timer**
- **Brightness Adjustment:** Increase (+) and Decrease (-) buttons.
- **Color Temperature Adjustment:** Increase (+) and Decrease (-) buttons.
- **Max Brightness:** Dedicated button for instant maximum brightness.
- **Preset Modes:** Leisure Mode, Reading Mode, Working Mode, Breastfeeding Mode, Night Light Mode.



Figure 4.2: Layout and functions of the remote control.

4.3 Adjusting Height and Angle

- **Height Adjustment:** Loosen the locking mechanism on the pole sections, adjust to your desired height (up to 75 inches), and then tighten to secure.
- **Gooseneck Adjustment:** The flexible gooseneck allows for 360-degree rotation and bending to direct light precisely where needed.
- **Lamp Head Adjustment:** Each lamp head can be independently rotated 180 degrees to widen or focus the light spread.

Maximum height up and down 15in/38cm



Figure 4.3: The lamp's adjustable height capabilities.



Figure 4.4: Illustration of the four color temperature modes and dimming range.

4.4 Memory Function

The lamp features a memory function that automatically saves your last selected brightness and color temperature settings. When you turn the lamp on again, it will revert to these preferred settings, eliminating the need to re-adjust every time.

1-Hour Timer & Memory Function

Set your preferred color temperature and brightness levels



Figure 4.5: The 1-hour timer and memory function in use.

5. MAINTENANCE

The OUTON LED Floor Lamp requires minimal maintenance due to its durable design and long-lasting LED components.

- **Cleaning:** Ensure the lamp is unplugged before cleaning. Use a soft, dry cloth to wipe down the lamp pole, base, and lamp heads. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **LED Lifespan:** The integrated LED lights have an impressive lifespan of over 50,000 hours, meaning you will rarely, if ever, need to replace them.
- **Cord Care:** Regularly inspect the power cord for any signs of damage. If the cord is damaged, do not use the lamp and contact customer support.

6. TROUBLESHOOTING

If you encounter any issues with your OUTON LED Floor Lamp, please refer to the following common problems and

solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply.	Ensure the power cord is securely plugged into a working outlet. Check if the outlet has power.
Remote control is not working.	Batteries are dead or incorrectly inserted. Remote is out of range.	Replace batteries (2x AAA, not included) and ensure they are inserted with correct polarity. Move closer to the lamp (within 15 meters).
Brightness or color temperature cannot be adjusted.	Control panel or remote issue.	Try using the other control method (touch or remote). If using remote, check batteries. If the issue persists, contact customer support.
Light settings glitch or flicker occasionally.	Minor electrical interference or software anomaly.	Unplug the lamp from the power outlet for 30 seconds, then plug it back in. This can reset the internal electronics.

If the problem persists after attempting these solutions, please contact OUTON customer support for further assistance.

7. SPECIFICATIONS

Feature	Specification
Model Number	DGEUFL0032-ST-B
Brand	OUTON
Power Source	Corded Electric
Wattage	18W
Luminous Flux	1800LM
Light Source Type	LED
Color Temperatures	Warm White, Natural White, Daylight, Cool White
Brightness Adjustment	1% - 100% Stepless Dimmable
Control Method	Touch Control & Remote Control
Remote Control Range	Up to 15 meters (49.3 feet)
Product Dimensions	9.5"D x 9.5"W x 73.5"H (adjustable height)
Item Weight	6 Pounds
Material	Metal
Lifespan	50,001+ hours

8. WARRANTY AND SUPPORT

OUTON is committed to providing high-quality products and excellent customer service. While specific warranty details are not provided in this manual, OUTON aims to respond to customer inquiries quickly, typically within 12 hours.

For any questions, concerns, or support needs regarding your OUTON LED Floor Lamp, please refer to the contact information provided with your purchase or visit the official OUTON brand store online.

© 2025 OUTON. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page
<https://manuals.plus/asin/B0DB8D8QWR>
More documents and user manuals: **<https://manuals.plus/>**