Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- JALL /
- > JALL Sunrise Alarm Clock White Noise Sound Machine User Manual

JALL K6

JALL Sunrise Alarm Clock White Noise Sound Machine

Model: K6 Brand: JALL

Introduction

The JALL Sunrise Alarm Clock White Noise Sound Machine (Model K6) is an all-in-one device designed to enhance your sleep and wake-up experience. It combines a sunrise simulation alarm clock, a white noise sound machine with 25 soothing sounds, 17 colorful night lights, and a Bluetooth speaker. This manual provides detailed instructions for setting up, operating, and maintaining your device.




Figure 1: Main view of the JALL Sunrise Alarm Clock.

SETUP

Power Connection

The JALL K6 device is not battery-powered and requires a continuous electrical connection. Use the provided 47-inch power cord and adapter to connect the device to a standard wall outlet. The device supports both USB-A and USB-C connections for power input.




Figure 2: Power connection points on the JALL K6 device.

Initial Time and Date Setting

Upon first connection or after a power interruption, you may need to set the current time and day. Locate the 'Time Set' button on the top panel. Press and hold this button to enter time setting mode. Use the rotary knob to adjust hours and minutes, then press the knob to confirm each setting. The day of the week can also be set in a similar manner.

Your browser does not support the video tag.

Video 1: A detailed guide on setting up the JALL K6 White Noise Sound Machine Alarm Clock, including time and date settings.

OPERATING INSTRUCTIONS

Time and Alarm Settings

The device supports both 12-hour and 24-hour time formats. To set an alarm, press the 'On/Off AL Set' button. Use the rotary knob to adjust the alarm time. The alarm supports daily, weekday, and weekend options. The snooze function

provides an extra 9 minutes of sleep and can be used unlimited times. If no operation occurs for 30 minutes after the alarm sounds, the alarm will automatically turn off. The alarm light will turn off after 60 minutes if not dismissed.

Sunrise Simulation

Activate the sunrise simulation feature by pressing the 'Sunrise' button. The light will gradually increase from 10% to 100% brightness over a period of 10-60 minutes before your set alarm time, simulating a natural sunrise to gently wake you up.




Figure 3: Visual representation of the sunrise simulation feature.

Light Functions

The device offers 17 distinct lighting modes. This includes 8 solid color lights (Pink, Green, Blue, Indigo, Purple, Grey, Red, Orange) and 9 RGB Mood Lights. The brightness of these lights can be adjusted using the light control roller. The time display itself is dimmable and can be turned off completely to ensure a dark sleeping environment.




Figure 4: Various colorful light modes available on the device.




Figure 5: Options for dimming or turning off the clock display.

Sound Functions

Equipped with a 5W stereo HiFi speaker, the device offers 25 built-in soothing sounds. These include various white noise options, pink noise, campfire, birds, seagulls, river, rain, wind chimes, and soft music. The volume can be adjusted using the dedicated volume knob. Additionally, the device supports Bluetooth connectivity, allowing you to stream audio from your phone or other Bluetooth-enabled devices.



Figure 6: A selection of the 25 built-in natural sounds.



Figure 7: The 5W stereo speaker provides high-fidelity sound.

Your browser does not support the video tag.

Video 2: Demonstration of the various soothing sounds available on the JALL K6 device.

Night Light and Bedside Lamp

The device can also function as a versatile night light or bedside lamp. Simply press the 'Snooze' button to toggle the light on. The light control roller allows you to adjust the brightness, providing soft and warm illumination for activities like feeding a baby, going to the toilet, or reading at night.

MAINTENANCE

To ensure the longevity and optimal performance of your JALL K6 device, follow these simple maintenance guidelines:

• **Cleaning:** Gently wipe the surface of the device with a soft, dry cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.

- Storage: When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- Handling: Handle the device with care to prevent drops or impacts that could damage internal components or the light globe.

TROUBLESHOOTING

If you encounter any issues with your JALL K6 device, please refer to the following common troubleshooting tips:

- **Device Not Powering On:** Ensure the power adapter is securely plugged into both the device and a working electrical outlet. Verify that the outlet is receiving power.
- Alarm Not Sounding: Check that the alarm is enabled and the volume is not set to zero. Confirm the alarm time and day settings are correct.
- Bluetooth Connectivity Issues: Make sure Bluetooth is enabled on your mobile device and the JALL K6 is in pairing mode. Ensure no other devices are currently connected to the alarm clock.
- Light Not Working: Check the dimmer settings to ensure the light is not set to its lowest brightness or turned off.

For further assistance, please contact JALL customer support.

SPECIFICATIONS

Product Dimensions	7.5 x 3.5 x 7.5 inches
Weight	15.84 ounces
Item Model Number	K6
Batteries	1 CR2032 batteries required (included)
Manufacturer	JALL
Color	White
Material	Acrylonitrile Butadiene Styrene (ABS)

WARRANTY AND SUPPORT

JALL offers a 365-Day warranty on products sold on Amazon. For any product inquiries, technical support, or warranty claims, please contact JALL customer service through the Amazon platform or visit the official JALL store page.

You can find more information and contact details on the JALL Store.

Related Documents - K6



JALL Wake-up Light User Manual - Sunrise Alarm Clock Instructions

Comprehensive user manual for the JALL Wake-up Light Sunrise Alarm Clock. Learn how to set time, alarms, wake-up light modes (sunrise simulation, mood light, RGB), FM radio, bedtime sounds, and fall asleep functions. Includes setup, maintenance, and troubleshooting tips.



JALL K6 White Noise Sound Machine Sunrise Alarm Clock User Manual

User manual for the JALL K6 White Noise Sound Machine Sunrise Alarm Clock, covering setup, features, alarm settings, light modes, Bluetooth, sounds, sleep timer, and troubleshooting.



JALL K8 Sunrise Alarm Clock User Manual

Comprehensive user manual for the JALL K8 Sunrise Alarm Clock, detailing setup, time and alarm settings, FM radio, mood lighting, music functions, fall asleep mode, and troubleshooting.



JALL RGB Digital Alarm Clock User Manual

User manual for the JALL RGB Digital Alarm Clock, detailing setup, time setting, alarm functions, display options, USB output, and FAQs. Includes warranty information and customer support contact.



JALL ACA-002-B Sunrise Alarm Clock User Manual

User manual for the JALL ACA-002-B Sunrise Alarm Clock, detailing setup, operation, and troubleshooting for its features including wake-up light, alarm functions, colorful light modes, FM radio, and fall-asleep mode.



JALL Sunrise Alarm Clock User Manual

User manual for the JALL Sunrise Alarm Clock, covering setup, operation, features like alarm settings, colorful light modes, FM radio, and troubleshooting.