

[manuals.plus](#) /› [JOYBOS](#) /› [Joybos Extensible Window Cleaner JBS-BLC-N1101-JWT Instruction Manual](#)

JOYBOS JBS-BLC-N1101-JWT

Joybos Extensible Window Cleaner Instruction Manual

Model: JBS-BLC-N1101-JWT

1. INTRODUCTION

Thank you for choosing the Joybos Extensible Window Cleaner. This manual provides essential information for the safe and effective use, setup, and maintenance of your new window cleaning tool. Please read these instructions carefully before use and retain them for future reference.

The Joybos Extensible Window Cleaner is designed to simplify window cleaning, featuring a telescopic handle for extended reach, a rotating head for versatile cleaning angles, and a dual-sided cleaning head with a microfiber pad for washing and a squeegee for streak-free drying.

2. PRODUCT OVERVIEW

The Joybos Extensible Window Cleaner consists of a telescopic handle and a dual-sided cleaning head. Familiarize yourself with the components before assembly and use.






Figure 1: Fully assembled Joybos Extensible Window Cleaner, showing the telescopic handle and cleaning head.




Figure 2: Product dimensions, illustrating the length of the handle and width of the cleaning head.

- **Telescopic Handle:** Allows adjustment of length for reaching high windows.
- **Rotating Head:** Enables the cleaning head to pivot for optimal angle and access to corners.
- **Microfiber Pad:** Soft, absorbent pad for applying cleaning solution and scrubbing.
- **Squeegee Blade:** Rubber blade for removing water and cleaning solution, leaving a streak-free finish.

3. SETUP

The Joybos Extensible Window Cleaner comes largely pre-assembled. Follow these steps for initial preparation:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check for any visible damage or missing parts. If any issues are found, do not proceed with use and contact customer support.
3. **Extend Handle:** To extend the telescopic handle, twist the locking mechanism counter-clockwise to loosen, pull the handle to the desired length, then twist clockwise to secure.
4. **Prepare Cleaning Solution:** Fill a bucket or spray bottle with your preferred window cleaning solution.

4. OPERATING INSTRUCTIONS

Follow these steps for effective window cleaning:

- 1. Wet the Microfiber Pad:** Dip the microfiber pad into your cleaning solution or spray the solution directly onto the window surface.
- 2. Wash the Window:** Use the microfiber pad side to scrub and clean the window surface. The rotating head (Figure 3) allows you to adjust the angle for optimal contact, especially in corners and edges.



Figure 3: The cleaning head can rotate to various angles for comprehensive cleaning.




Figure 4: Using the microfiber pad to apply solution and scrub the window surface.

3. **Squeegee Dry:** Flip the cleaning head to the squeegee blade side. Starting from the top of the window, pull the squeegee downwards in overlapping strokes to remove the cleaning solution and water. Wipe the squeegee blade with a clean cloth after each stroke to prevent streaks.



Figure 5: Using the squeegee blade to dry the window for a streak-free finish.



Figure 6: Demonstrating the extended reach of the telescopic handle for high windows.

4. **Clean Edges:** For any remaining drips or streaks on edges, use a clean, dry cloth.

5. MAINTENANCE

Proper maintenance ensures the longevity and performance of your window cleaner.

- **Microfiber Pad:** After each use, remove the microfiber pad from the cleaning head. Hand wash or machine wash the pad with mild detergent and warm water. Do not use bleach or fabric softeners. Air dry completely before reattaching or storing.
- **Squeegee Blade:** Rinse the rubber squeegee blade with clean water after each use. Inspect for any nicks or damage. Replace if necessary to maintain streak-free performance.
- **Handle:** Wipe the telescopic handle with a damp cloth to remove any dirt or residue. Ensure the locking mechanism is clean and functions smoothly.
- **Storage:** Store the window cleaner in a clean, dry place, away from direct sunlight and extreme temperatures. The compact design allows for storage in tight spaces (Figure 7).



Figure 7: The window cleaner can be stored vertically, minimizing space requirements.

6. TROUBLESHOOTING

No common troubleshooting issues have been identified for this product. If you encounter any problems, please ensure you have followed all operating and maintenance instructions. For persistent issues, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	JOYBOS
Model Number	JBS-BLC-N1101-JWT
Item Weight	420 grams
Package Dimensions	45.4 x 18.5 x 6.6 cm


Handle Type	Telescopic
Cleaning Head Features	Rotating, Dual-sided (Microfiber Pad & Squeegee)



8. WARRANTY AND SUPPORT

Information regarding specific warranty terms and customer support contact details is not available in the provided product data. Please refer to the product packaging or the retailer's website for warranty information and customer service contacts.

© 2024 JOYBOS. All rights reserved.

Related Documents - JBS-BLC-N1101-JWT

	<p>Joybos Square Spin Mop User Manual and Instructions</p> <p>A comprehensive guide for the Joybos Square Spin Mop, detailing product features, installation, usage steps, and maintenance for optimal cleaning performance. Learn how to assemble, use, and clean your spin mop system effectively.</p>
	<p>Joybos Metal Storage Cabinet Assembly Instructions</p> <p>Comprehensive guide for assembling the Joybos Metal Storage Cabinet, including step-by-step instructions and important cautions for a stable installation.</p>
	<p>Joybos 5-Tier Kitchen Utility Storage Cabinet Installation Guide</p> <p>Step-by-step installation instructions and parts list for the Joybos 5-Tier Kitchen Utility Storage Cabinet with Dust-Proof Cabinet Doors.</p>
	<p>JOYBOS Stackable Storage Bins: Assembly Guide</p> <p>A step-by-step guide detailing the assembly process for JOYBOS stackable storage bins, including unfolding side panels, securing the rear, and installing the top panel.</p>

	<p>Joybos Freestanding Kitchen Pantry Storage Cabinet with Pegboard Wall Installation Guide</p> <p>Comprehensive installation instructions for the Joybos Freestanding Kitchen Pantry Storage Cabinet with Pegboard Wall. Includes a detailed parts list and step-by-step assembly guide.</p>
	<p>FROST DENMARK Toilet Roll Holder 1101 & Back Plate 1102 - Installation and Product Details</p> <p>Detailed product information, technical specifications, and fitting instructions for the FROST DENMARK Toilet Roll Holder 1101 and Back Plate 1102. Learn about materials, finishes, mounting, and maintenance.</p>