

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ERAZER](#) /

› [ERAZER Spectator X40 Gaming Monitor User Manual](#)

ERAZER SPECTATOR X40

ERAZER Spectator X40 Gaming Monitor User Manual

Model: SPECTATOR X40 (MD 21727)

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your ERAZER Spectator X40 gaming monitor. Please read this manual thoroughly before using the product to ensure optimal performance and safety.



Image 1.1: The ERAZER Spectator X40 monitor integrated into a gaming setup.

Key Features:

- 27-inch QHD (2560 x 1440) resolution display for detailed visuals.

- High refresh rate of 180 Hz for smooth motion.
- Fast 1ms response time to minimize ghosting.
- HDR10 support for enhanced contrast and color.
- Adaptive Sync technology for tear-free gaming.
- Integrated speakers for audio output.
- Versatile connectivity with HDMI and DisplayPort inputs.

2. SETUP

2.1 Unpacking the Monitor

Carefully remove all components from the packaging. Ensure all items listed in the packing contents are present. Keep the packaging materials for future transport or storage.

2.2 Assembling the Stand

1. Place the monitor face down on a soft, clean surface to prevent scratches.
2. Attach the stand base to the stand neck using the provided screws.
3. Secure the assembled stand to the back of the monitor until it clicks into place or is firmly screwed.

Monitor QHD



Image 2.1: Front view of the ERAZER Spectator X40 monitor with its assembled stand.

2.3 Connecting Cables

Connect the necessary cables to the appropriate ports on the monitor and your computer or other devices.

- **Power Cable:** Connect one end of the power cable to the monitor's power input and the other end to a power outlet.
- **DisplayPort Cable:** For optimal image quality and performance, connect your PC to the monitor using the DisplayPort cable.
- **HDMI Cable:** Connect your PC, Blu-ray player, game console, or streaming stick to the monitor via one of the HDMI ports.
- **Headphone Jack:** Connect headphones or external speakers to the 3.5mm audio output jack if desired.



2 x HDMI® 2.0
1 x Presa per cuffie

1 x Displayport 1.4
1 x Presa per
alimentatore

Image 2.2: Rear view of the monitor highlighting the HDMI and DisplayPort connections.

2.4 Initial Power-On

After connecting all cables, press the power button on the monitor. The power indicator light will illuminate, and the display will turn on. If no image appears, ensure your input source is correctly selected on the monitor and your device is powered on.

3. OPERATING INSTRUCTIONS

3.1 Power On/Off

Press the power button located on the monitor to turn it on or off. A short press typically turns it on, while a longer press may turn it off or put it into standby mode.

3.2 On-Screen Display (OSD) Menu Navigation

The monitor features an OSD menu for adjusting various settings. Use the control buttons (usually located on the back or bottom right of the monitor) to navigate the menu:

- Press a button to open the OSD menu.
- Use directional buttons to move between menu options.
- Press an 'Enter' or 'OK' button to select an option or confirm a setting.
- Use an 'Exit' or 'Back' button to return to the previous menu or close the OSD.

3.3 Adjusting Display Settings

Within the OSD menu, you can adjust settings such as:

- **Brightness/Contrast:** Adjust the overall luminance and difference between light and dark areas.
- **Color Settings:** Modify color temperature, gamma, and individual RGB levels.
- **Input Source:** Manually select between HDMI 1, HDMI 2, or DisplayPort inputs.
- **Refresh Rate:** Ensure your device is outputting at 180Hz for the smoothest experience. This can often be set in your operating system's display settings.
- **Adaptive Sync:** Enable or disable Adaptive Sync for tear-free gaming. Ensure your graphics card supports this feature.
- **HDR:** Activate HDR10 mode for compatible content.
- **Audio:** Adjust volume for integrated speakers or connected headphones.

Supporto multifunzione

regolabile in altezza, inclinabile, orientabile & Pivot 90°



Image 3.1: The multi-functional stand allows for height adjustment, tilt, swivel, and 90-degree pivot rotation.

4. MAINTENANCE

4.1 Cleaning the Monitor

- Always turn off and unplug the monitor before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a specialized screen cleaner.
- Do not spray cleaner directly onto the screen. Apply it to the cloth first.
- Avoid using abrasive cleaners, alcohol, or ammonia-based solutions, as these can damage the screen surface.

4.2 General Care

- Keep the monitor away from direct sunlight, heat sources, and excessive dust.
- Ensure adequate ventilation around the monitor to prevent overheating.
- Avoid placing heavy objects on the monitor or its cables.

5. TROUBLESHOOTING

If you encounter issues with your monitor, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No image on screen	Power cable disconnected, incorrect input source, device not powered on.	Check power connections. Select correct input source via OSD. Ensure connected device is on.
Image flickering or distorted	Loose video cable, incorrect resolution/refresh rate, graphics driver issues.	Ensure video cable is securely connected. Adjust resolution/refresh rate in PC settings. Update graphics drivers.
No sound from speakers/headphones	Volume too low, incorrect audio output selected, cable issue.	Adjust monitor volume via OSD. Check PC audio output settings. Ensure headphone cable is fully inserted.
Adaptive Sync not working	Feature not enabled, incompatible graphics card, outdated drivers.	Enable Adaptive Sync in OSD. Verify graphics card compatibility. Update graphics drivers.

6. SPECIFICATIONS

Detailed technical specifications for the ERAZER Spectator X40 monitor:

Feature	Specification
Model Name	SPECTATOR X40 (MD 21727)
Screen Size	27 Inches (68.6 cm)
Display Technology	LED
Resolution	2560 x 1440 (QHD)
Aspect Ratio	16:9
Refresh Rate	180 Hz
Response Time	1 Millisecond (MPRT)
Contrast Ratio	1000:1
Brightness	250 cd/m ²
Viewing Angle	178 Degrees
Connectivity	2x HDMI 2.0, 1x DisplayPort 1.4, 1x Headphone Jack
Special Features	Integrated Speakers, Ergonomic Stand (Height, Tilt, Swivel, Pivot), Adaptive Sync, HDR10
Dimensions (with stand)	614 x 228 x 421-562 mm (W x D x H)
Weight (with stand)	6.3 Kilograms

Feature	Specification
Power Input	220 Volt



Image 6.1: Physical dimensions of the ERAZER Spectator X40 monitor.

7. WARRANTY INFORMATION

Your ERAZER Spectator X40 monitor comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging or visit the official ERAZER/MEDION website for detailed terms and conditions, including warranty duration and coverage.

8. SUPPORT

For technical assistance, product inquiries, or service requests, please contact ERAZER/MEDION customer support. You can find contact information, FAQs, and additional resources on the official MEDION website. Please have your product model number (SPECTATOR X40) and serial number ready when contacting support.

