

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Shark](#) /

› [Shark UV730 Navigator Lift-Away Upright Vacuum Instruction Manual](#)

## Shark UV730

# Shark UV730 Navigator Lift-Away Upright Vacuum Instruction Manual

Model: UV730

## PRODUCT OVERVIEW

The Shark UV730 Navigator Lift-Away Upright Vacuum is designed for powerful cleaning across various surfaces. It features a self-cleaning brushroll, Lift-Away technology for portable cleaning, and advanced filtration to capture dust and allergens.



The Shark UV730 Navigator Lift-Away Upright Vacuum, a versatile cleaning solution.

## KEY FEATURES

- **Self-Cleaning Brushroll:** PowerFins HairPro technology for powerful hair pickup with no hair wrap.
- **Lift-Away Technology:** Detachable pod for easy above-floor cleaning, stairs, and hard-to-reach areas.
- **Anti-Allergen Complete Seal Technology + HEPA Filtration:** Captures 99.99% of dust and allergens (based on ASTM F1977 at .3 microns or larger).
- **Powerful LED Headlights:** Illuminates hidden debris in dimly lit areas.
- **Swivel Steering:** For easy maneuverability around furniture and obstacles.

# GET TO KNOW THE SHARK LIFT-AWAY® VACUUM



## Fingertip Controls

Ergonomic handle with suction control slider to customize your clean.

## Anti-Allergen Complete Seal with HEPA

Traps 99.9% of dust and allergens inside the vacuum. (Based on ASTM F1977 of particles .3 microns or larger.)

## Lift-Away® Technology

lift away the pod to clean stairs, furniture, and more.

## Swivel Steering

Easily maneuver around furniture while cleaning.

## PowerFins™

Designed to pick up more hair with no hair wrap (vs. Shark bristle brushroll).

## Self-Cleaning Brushroll

Powerful pet hair pickup with no hair wrap.

Anatomy of the Shark Lift-Away Vacuum, detailing its ergonomic controls, filtration, and cleaning technologies.

## SETUP AND ASSEMBLY

Your Shark Navigator Lift-Away vacuum comes partially assembled. Follow these steps to set up your unit:

1. Insert the wand into the floor nozzle until it clicks securely.
2. Place the pod onto the wand, ensuring it slides down and locks into place.
3. Connect the hose to the back of the pod by pushing it firmly into the port.
4. Securely attach desired accessories to the accessory holder on the vacuum for convenient storage.

## OPERATING INSTRUCTIONS

### Power and Floor Settings

The power switch is located on the main pod. Select the appropriate setting for your floor type:

- "0" Off: Turns the vacuum off.
- "I" Hard Floor: For bare floors and delicate area rugs. The brushroll will not spin in this mode.
- "II" Carpet: For carpets and area rugs. The brushroll will spin to deep-clean.



# CARPETS & FLOORS

Deep-clean carpets and gently clean bare floors.

The Shark UV730 vacuum effectively cleans both carpets and hard floors.

## Using Lift-Away Mode

To clean above-floor areas, stairs, or under furniture, detach the pod from the nozzle:

1. Press the "Lift-Away" button on the main pod.
2. Lift the pod away from the floor nozzle.
3. Attach desired cleaning tools to the end of the hose or wand for versatile cleaning.



## LIFT AWAY THE POD TO CLEAN LOW

Lift-Away technology lets you detach  
the pod to clean under furniture.

The Lift-Away pod allows for easy cleaning under low-lying furniture.



# POWER ABOVE THE FLOOR

Lift away the pod to clean stairs.

The portable pod makes cleaning stairs and elevated surfaces effortless.



# EXTENDED REACH

Lift away the pod to clean up high.

Achieve extended reach for high-up cleaning tasks with the detachable wand.

## Using Attachments

The vacuum comes with various attachments for specialized cleaning. Connect them to the hose or wand as needed for tasks such as dusting, crevice cleaning, or pet hair removal from upholstery.

## MAINTENANCE

### Emptying the Dust Cup

Empty the dust cup after each use or when debris reaches the MAX FILL line to maintain optimal suction.

1. Ensure the vacuum is unplugged from the power outlet.
2. Press the dust cup release latch and lift the dust cup off the pod.
3. Hold the dust cup over a trash bin and press the bottom release latch to empty the contents.
4. Close the bottom flap until it clicks securely.

### Cleaning Filters

Regularly clean the pre-motor and post-motor (HEPA) filters to maintain optimal suction and filtration performance.

#### Pre-Motor Filters (Foam & Felt)

Rinse these filters every 3 months:

1. Remove the dust cup.
2. Pull the foam and felt filters out from the top of the motor housing.
3. Rinse thoroughly with water until the water runs clear.
4. Air-dry completely for at least 24 hours before reinstalling. Do not use a hairdryer.

#### Post-Motor HEPA Filter

Rinse this filter once a year:

1. Remove the filter cover located at the front of the pod.
2. Pull out the HEPA filter.
3. Rinse with water until the water runs clear.
4. Air-dry completely for at least 24 hours before reinstalling. Do not use a hairdryer.



The Anti-Allergen Complete Seal Technology and HEPA filter system ensures thorough air purification.

#### Cleaning the Brushroll

The PowerFins HairPro Self-Cleaning Brushroll is designed to prevent hair wrap. If any debris remains, carefully remove it:

1. Ensure the vacuum is unplugged.

2. Use scissors to carefully cut away any hair or debris wrapped around the brushroll.
3. Remove any blockages from the nozzle air path.



## LED HEADLIGHTS

Reveal hidden debris around your home.

LED headlights reveal hidden debris, making cleaning more effective.

### TROUBLESHOOTING

- **No Power:** Check the power cord connection, wall outlet, and circuit breaker.
- **Loss of Suction:** Empty the dust cup, clean all filters, and check for blockages in the hose, nozzle, or attachments.
- **Brushroll Not Spinning:** Ensure the floor setting is on "II Carpet". Check for blockages in the brushroll or nozzle.

For further assistance, refer to the full user manual or contact Shark customer support.

### SPECIFICATIONS

Brand	Shark
Model	UV730
Special Feature	Bagless

<b>Filter Type</b>	HEPA Filter
<b>Included Components</b>	Detachable Pod, HEPA Filter
<b>Is Cordless?</b>	No
<b>Recommended Uses</b>	Bare Floor, Carpet, Hard Floor, Hardwood, Office
<b>Number of Items</b>	1
<b>Controller Type</b>	Push Button
<b>Style</b>	Upright
<b>Portable</b>	Yes (Lift-Away pod)
<b>Number of Power Levels</b>	3 (Off, Hard Floor, Carpet)
<b>Indoor/Outdoor Usage</b>	Indoor
<b>Power Source</b>	Corded Electric

## **WARRANTY AND SUPPORT**

---

For warranty information or customer support, please visit the official Shark website or contact their customer service line. Keep your purchase receipt for warranty claims.