Wielio AT-M269A

Wielio Portable Full HD 1080P Projector User Manual

Model: AT-M269A

1. Safety Information

Please read all safety instructions carefully before using this product. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Power Supply:** Use only the provided power adapter. Ensure the voltage matches the projector's requirements.
- **Ventilation:** Do not block ventilation openings. Ensure adequate airflow around the projector to prevent overheating.
- **Heat:** The projector lamp generates heat. Do not touch the lens or surrounding areas immediately after use.
- **Water and Moisture:** Do not expose the projector to rain, moisture, or liquids. Keep it away from sources of water.
- **Cleaning:** Unplug the projector before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosols.
- **Light Source:** Do not look directly into the projector lens when the lamp is on, as the bright light can damage your eyes.
- **Repairs:** Do not attempt to repair the projector yourself. Refer all servicing to qualified service personnel.

2. Package Contents

Carefully unpack the box and ensure all items are present and in good condition. If any items are missing or damaged, contact your retailer.

- Wielio Portable Projector (Model: AT-M269A)
- Power Cable
- HDMI Cable
- 3.5mm Jack to 3x RCA (Cinch) Cable
- Remote Control (requires 2x AAA batteries, not included)
- User Manual



Image: The brown cardboard packaging box for the Wielio projector, showing contact information for UK and EU representatives.



Image: The brown cardboard packaging box for the Wielio projector, displaying a label with "Product Name: Projector", "Model: AT-M269A", "Brand: Wielio", and manufacturer details.

3. Product Overview

The Wielio Portable Full HD 1080P Projector (Model: AT-M269A) is a compact and lightweight device designed for home theater and portable projection needs. It supports 1080P Full HD resolution with 4K support, features 5G WiFi for seamless streaming, and 5.2 Bluetooth for audio connectivity.



Image: A white portable projector with a black front panel, projecting a vibrant sunset scene onto a curved screen. Icons on the screen indicate 4K Support, 18000 Lumens, 5G WiFi, and Bluetooth 5.2.

3.1. Features

- Native 1080P Full HD Resolution with 4K Support
- 5G WiFi Connectivity for fast wireless mirroring
- Bluetooth 5.2 for external audio device connection
- Multiple Input Ports: HDMI, USB (x2), 3.5mm Audio Out, AV
- Compact and Portable Design

3.2. Projector Parts

- **Lens:** Projects the image onto the screen.
- **Focus Adjustment:** Manual dial located on the top of the projector, near the lens.
- **Power Button:** Located on the top surface.
- **Input Ports (Rear Panel):** HDMI, USB (x2), 3.5mm Audio Out, AV (for 3x RCA cable).
- **Ventilation Grilles:** Located on the sides and rear to dissipate heat.

- **Tripod Mount:** Standard metallic tripod thread on the bottom for mounting.

4. Setup

4.1. Placement

- Place the projector on a stable, flat surface.
- Ensure there is sufficient space around the projector for proper ventilation.
- Position the projector perpendicular to the projection surface (wall or screen) for optimal image geometry. This model does not feature automatic keystone correction.
- Adjust the distance from the projection surface to achieve the desired screen size.

4.2. Power Connection

1. Connect the power cable to the projector's power input port.
2. Plug the other end of the power cable into a suitable electrical outlet.
3. The projector will enter standby mode.

4.3. Connecting Input Devices

- **HDMI:** Connect your laptop, gaming console, Blu-ray player, or other HDMI-enabled device using the provided HDMI cable.
- **USB:** Insert a USB flash drive into one of the USB ports to play media files (photos, music, videos).
- **AV (RCA):** Use the 3.5mm to 3x RCA cable to connect older devices with AV output.

4.4. Focus Adjustment

After powering on and selecting an input source, rotate the manual focus dial located on the top of the projector, near the lens, until the projected image appears clear and sharp.

5. Operating Instructions

5.1. Powering On/Off

- **Power On:** Press the power button on the projector or the remote control. The indicator light will change, and the projector will start.
- **Power Off:** Press the power button again. Confirm shutdown if prompted. Allow the fan to run briefly to cool down the lamp before unplugging.

5.2. Menu Navigation

Use the arrow buttons on the remote control or the projector's control panel to navigate through the on-screen menu. Press the "OK" or "Enter" button to confirm selections. The menu allows adjustment of picture settings, sound, and input sources.

5.3. Input Source Selection

Press the "Source" or "Input" button on the remote control to cycle through available input sources (HDMI, USB, AV, Screen Mirroring). Select the desired source.

5.4. Screen Mirroring (Wireless Connection)

The projector supports wireless screen mirroring for iOS and Android devices via 5G WiFi.

1. Select the "Screen Mirroring" or "Wireless Display" option from the projector's main menu.
2. Ensure your mobile device and the projector are connected to the same WiFi network.
3. On your iOS device, open Control Center and tap "Screen Mirroring" or "AirPlay Mirroring", then select the projector from the

list.

4. On your Android device, enable "Wireless Display", "Smart View", "Screen Cast", or similar function in your settings, then select the projector from the list.
5. Follow any on-screen prompts on both devices to establish the connection.

5.5. Bluetooth Audio Connection

Connect external Bluetooth speakers or headphones for enhanced audio experience.

1. Navigate to the Bluetooth settings in the projector's menu.
2. Enable Bluetooth and put your external audio device into pairing mode.
3. Select your device from the list of available Bluetooth devices on the projector's screen.
4. Confirm the pairing. Audio will now be routed through the connected Bluetooth device.

6. Maintenance

- **Lens Cleaning:** Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Do not use abrasive materials or harsh chemicals.
- **Dust Removal:** Periodically clean the projector's exterior with a soft, dry cloth. Use a small brush or compressed air to clear dust from ventilation grilles.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to use the original packaging for storage.
- **Power Off Properly:** Always allow the projector to complete its cool-down cycle before unplugging it or moving it.

7. Troubleshooting

Problem	Possible Cause	Solution
No image projected	Power not connected or off Incorrect input source selected Input device not connected or off Lens cap on (if applicable, though this model may not have one)	Check power connection and press power button Select correct input source (HDMI, USB, etc.) Ensure input device is on and connected properly Check if anything is obstructing the lens
Image is blurry	Focus not adjusted Projector too close/far from screen	Adjust the manual focus dial Adjust projector distance to screen
No sound	Volume too low or muted Incorrect audio output selected Bluetooth device not connected	Increase volume or unmute Check audio settings on projector and source device Ensure Bluetooth device is paired and connected
Wireless mirroring issues	Not on same WiFi network Network interference Device compatibility	Ensure both devices are on the same 2.4G or 5G WiFi network Try moving closer to the WiFi router or reducing interference Ensure your device supports screen mirroring

Problem	Possible Cause	Solution
Loud fan noise	Normal operation (cooling) Blocked ventilation	Some fan noise is normal for projectors Ensure ventilation grilles are clear and not obstructed

8. Specifications

Feature	Detail
Brand	Wielio
Model	AT-M269A
Display Technology	LED
Native Resolution	1920 x 1080 (Full HD)
Maximum Supported Resolution	4K (via HDMI input)
Connectivity	USB, HDMI, 5G WiFi, Bluetooth 5.2
Special Features	Portable, Lightweight, Screen Mirroring (iOS/Android)
Form Factor	Portable
Mounting Type	Tabletop Mount (with tripod thread)
Controller Type	Button Control, Remote Control
Package Dimensions	25.5 x 24.4 x 11.2 cm
Weight	1.35 kg

9. Warranty and Support

Wielio products are designed for reliability and performance. For warranty information, please refer to the warranty card included with your product or contact your point of purchase.
For technical support, troubleshooting assistance, or inquiries regarding your Wielio Portable Projector, please contact the manufacturer or your regional representative. Contact details may be found on the product packaging or the official Wielio website. As per packaging information, you may contact:

- **UK Representative:** GOAL REACH CONSULTING LTD, OFFICE 1029 3 HARDMAN STREET 10TH FLOOR, SPINNINGFIELDS MANCHESTER, UK M3 3HF (golaservice@hotmail.com)
- **EU Representative:** SUCCESS COURIER SL, CALLE RIO TORMES NUM. 1, PLANTA 1, DERECHA, OFICINA 3, Fuenlabrada, Madrid, 28947 Spain (successservice2@hotmail.com)

© 2024 Wielio. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question