

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [BZGG](#) /
- › BZGG Q22 Portable Electric Space Heater User Manual

BZGG Q22

BZGG Q22 Portable Electric Space Heater User Manual

Model: Q22 | Brand: BZGG

1. IMPORTANT SAFETY INSTRUCTIONS

Please read this entire manual carefully before using the BZGG Q22 Portable Electric Space Heater. Failure to follow these instructions may result in fire, electric shock, injury, or property damage. Keep this manual for future reference.

- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- Do not use the heater in wet or damp locations, such as bathrooms, laundry areas, or near sinks.
- Do not cover the heater or block the air intake/outlet in any manner. This can cause overheating and fire.
- Keep flammable materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front, sides, and rear of the heater.
- This heater is equipped with an automatic **Overheat Protection** system that shuts off the unit if parts of the heater get excessively hot. If the unit shuts off, unplug it, wait 10 minutes for it to cool down, and then plug it back in.
- The heater features a **Tip-Over Protection** switch located on the bottom. The heater will automatically turn off if it is tipped over or lifted from a flat surface. Ensure the heater is placed on a firm, level surface for proper operation.
- The casing is made from V-0 flame retardant material for enhanced safety.
- This product is UL-certified, meeting USA safety standards.
- Unplug the heater when not in use.

2. PRODUCT OVERVIEW

The BZGG Q22 Portable Electric Space Heater is designed to provide efficient and safe personal heating for indoor spaces.

Key Features:

- **Rapid Heating:** Advanced PTC ceramic heating technology provides warmth within 2 seconds.
- **Two Heating Modes:** Choose between 700W (Eco) and 1000W (High) to suit your comfort needs.
- **Quiet Operation:** Operates at a low noise level of approximately 40dB, ensuring minimal disturbance.
- **Compact & Portable:** Measuring 5.28"D x 4.45"W x 8.5"H with a built-in carry handle, it's ideal for desks, bedrooms,

and small workspaces.

- **Enhanced Safety:** Includes Overheat Protection, Tip-Over Protection, and V-0 flame retardant casing.
- **Working Light:** An indicator light confirms the unit is operational.

Product Components:




Figure 1: Front view of the BZGG Q22 Portable Electric Space Heater, showcasing the heating element and protective grille.



Figure 2: The compact design of the heater, highlighting its portable handle for easy transport.



Figure 3: Rear view of the heater, illustrating the single button for two heating modes.

3. SETUP

1. **Unpack:** Carefully remove the heater from its packaging. Retain packaging for storage or return if necessary.
2. **Placement:** Place the heater on a stable, flat, and heat-resistant surface. Ensure there is at least 3 feet (0.9 m) of clear space around the heater to prevent obstruction of airflow and reduce fire risk.
3. **Power Connection:** Plug the heater directly into a standard 120V AC, 60Hz electrical wall outlet. Do not use extension cords or power strips.

4. OPERATING INSTRUCTIONS

1. **Power On:** Ensure the heater is placed on a flat surface to engage the tip-over safety switch. Locate the power switch on the back of the unit.
2. **Select Heating Mode:**
 - Slide the switch to position 'I' for **Low Heat (700W)**.
 - Slide the switch to position 'II' for **High Heat (1000W)**.
3. **Working Indicator:** A small light at the bottom front of the heater will illuminate when the unit is operating, indicating that the tip-over switch is engaged and the heater is active.
4. **Power Off:** To turn off the heater, slide the switch on the back to the 'O' position. Unplug the unit from the wall outlet when not in use.



Figure 4: The single power switch on the back of the heater for selecting between two heating modes.

TIP-OVER PROTECTION




Figure 5: The tip-over safety switch located on the bottom of the heater, which must be engaged for operation.

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

- **Cleaning:** Always unplug the heater from the power outlet and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners, polishes, or any chemical solutions.
- **Do Not Immerse:** Never immerse the heater in water or any other liquid.
- **Storage:** When not in use, store the heater in a cool, dry place, preferably in its original packaging, away from direct sunlight and moisture.

6. TROUBLESHOOTING

If your BZGG Q22 heater is not functioning as expected, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in, tip-over switch not engaged, or overheat protection activated.	Ensure power cord is securely plugged into a 120V outlet. Place heater on a firm, level surface. If overheated, unplug and let cool for 10 minutes before restarting.
Insufficient heat output.	Incorrect heating mode selected or room size exceeds heating capacity.	Switch to High Heat (1000W) mode. Ensure the heater is appropriate for the room size (up to 200 sq ft).
Unusual noise or smell.	Internal malfunction or foreign object.	Immediately unplug the heater and discontinue use. Contact customer support for assistance.

7. SPECIFICATIONS

- **Brand:** BZGG
- **Model:** Q22
- **Power Output:** 700W (Eco Mode) / 1000W (High Mode)

- **Voltage:** 120V AC, 60Hz
- **Dimensions:** 5.28" (Depth) x 4.45" (Width) x 8.5" (Height)
- **Item Weight:** 1.65 pounds
- **Heating Technology:** PTC Ceramic
- **Noise Level:** Approximately 40dB
- **Heating Coverage:** Up to 200 sq ft
- **Safety Features:** Overheat Protection, Tip-Over Protection, V-0 Flame Retardant Material, UL-Certified
- **Cord Length:** Approximately 4 feet

8. OFFICIAL PRODUCT VIDEO

Video 1: An official product video from BZGG demonstrating the features and operation of the Q22 Space Heater. This video highlights its compact size, heating capabilities, and safety features.

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

