Volkano VK-20235

Volkano Aurum Series VK-20235 Rechargeable Bluetooth and 2.4GHz Wireless Mouse User Manual

1. Introduction

Thank you for purchasing the Volkano Aurum Series Rechargeable Bluetooth and 2.4GHz Wireless Mouse. This manual provides essential information for setting up, operating, and maintaining your device. Please read it carefully before use and retain it for future reference.

2. Package Contents

- Volkano Aurum Series Wireless Mouse
- Nano USB Receiver
- USB Type-C Charging Cable
- User Manual



Image: The retail packaging for the Volkano Aurum Series mouse, displaying the mouse and its nano USB receiver.

3. Product Features

- **Dual Connectivity:** Supports both Bluetooth 5.2 and 2.4GHz wireless modes for versatile connection options.
- **Adjustable DPI:** Customize cursor sensitivity for precise control on various surfaces.
- **Ergonomic Design:** Provides comfort and reduces hand strain during extended use.
- **Multi-Button Functionality:** Features 6 buttons (Left, Right, Scroll Wheel Click, DPI, Forward, Backward) plus a scroll wheel for enhanced productivity.
- **Rechargeable Battery:** Built-in rechargeable battery with USB Type-C charging.
- **Nano USB Receiver:** Compact receiver for reliable 2.4GHz wireless connection.
- **Wide Compatibility:** Compatible with Windows XP/Vista/7/8, Mac, PC, and Laptops.



Image: Front view of the Volkano Aurum Series wireless mouse, showcasing its design.



Image: Side view of the mouse, illustrating the ergonomic contours and side buttons.

4. Setup

4.1 Charging the Mouse

1. Connect the supplied USB Type-C charging cable to the charging port on the front of the mouse.
2. Connect the other end of the cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicator on the mouse will illuminate during charging and turn off when fully charged.

4.2 Connecting via 2.4GHz Wireless (USB Receiver)

1. Locate the Nano USB Receiver, usually stored in a compartment on the bottom of the mouse.
2. Plug the Nano USB Receiver into an available USB port on your computer.
3. Turn on the mouse using the power switch located on the bottom.
4. The computer should automatically detect and install the necessary drivers. The mouse will be ready for use.

4.3 Connecting via Bluetooth 5.2

1. Turn on the mouse using the power switch on the bottom.
2. Press and hold the Bluetooth pairing button (often located on the bottom or a dedicated button) until the LED indicator starts blinking, indicating it's in pairing mode.
3. On your computer or device, go to Bluetooth settings.
4. Search for new devices and select "Volkano Aurum Mouse" (or similar name) from the list.
5. Once paired, the LED indicator on the mouse will stop blinking and remain solid or turn off.



Image: Bottom view of the mouse, showing the sensor, power switch, and receiver storage.

5. Operating Instructions

5.1 Basic Functions

- **Left Click:** Primary selection and activation.
- **Right Click:** Accesses contextual menus.
- **Scroll Wheel:** Scrolls content vertically. Pressing the scroll wheel often acts as a middle click.
- **Forward/Backward Buttons:** (Located on the side) Navigate web pages or folders.



Image: Top view of the mouse, highlighting the main buttons and scroll wheel.

5.2 DPI Adjustment

The mouse features an adjustable DPI (Dots Per Inch) button, typically located behind the scroll wheel. Press this button to cycle through different sensitivity levels. A higher DPI setting results in faster cursor movement, while a lower DPI provides more precise control.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. Store it in a cool, dry place.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the mouse regularly to maintain battery health.

7. Troubleshooting

Problem	Possible Solution
Mouse not responding	Ensure the mouse is turned on. Check battery level and charge if necessary. For 2.4GHz: Ensure the Nano USB Receiver is securely plugged into a working USB port. Try a different USB port. For Bluetooth: Ensure Bluetooth is enabled on your device and the mouse is paired. Try re-pairing. Try restarting your computer.
Cursor movement is erratic or jumpy	Clean the optical sensor on the bottom of the mouse. Use the mouse on a clean, non-reflective surface or a mouse pad. Adjust the DPI setting to a lower sensitivity.

Problem	Possible Solution
Cannot connect via Bluetooth	Ensure the mouse is in Bluetooth pairing mode (blinking LED). Make sure your device's Bluetooth is on and discoverable. Remove any previous pairings of the mouse from your device's Bluetooth settings and try pairing again. Ensure the mouse is not connected to another device via Bluetooth.
Short battery life	Ensure the mouse is fully charged before use. Turn off the mouse when not in use. Reduce the distance between the mouse and the receiver/Bluetooth device.

8. Specifications

Feature	Detail
Model Name	Aurum
Model Number	VK-20235-BK
Connectivity Technology	Bluetooth 5.2, 2.4GHz Wireless (USB)
Movement Detection	Laser
Number of Buttons	6 (Left, Right, Scroll Click, DPI, Forward, Backward) + Scroll Wheel
Hand Orientation	Right
Charging Port	USB Type-C
Compatible Devices	Personal Computer, Laptop
Operating Systems	Windows XP/Vista/7/8, Mac OS
Color	Black

9. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Volkano website. Keep your proof of purchase for any warranty claims.