

Kenmore 110.26832692

Kenmore Washer Water Drain Pump Replacement Manual

For Kenmore Washer Model: 110.26832692

INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your replacement water drain pump, designed for compatibility with Kenmore Washer Model 110.26832692. Please read these instructions carefully before proceeding with installation or use to ensure proper function and safety.

SAFETY INFORMATION

Always observe the following safety precautions when handling or installing the drain pump:

- **Disconnect Power:** Before beginning any installation or maintenance, ensure the washer is unplugged from the electrical outlet to prevent electric shock.
- **Water Shut-off:** Turn off the water supply to the washer to prevent leaks.
- **Wear Protective Gear:** Use appropriate personal protective equipment, such as gloves and eye protection, to avoid injury.
- **Drain Residual Water:** Be prepared for residual water in the washer and hoses. Have towels and a bucket ready.
- **Professional Assistance:** If you are unsure about any step, consult a qualified appliance technician.

PACKAGE CONTENTS

Your package should contain the following item:

- 1 x Washer Water Drain Pump (Replacement Part)

INSTALLATION INSTRUCTIONS

Follow these steps carefully to replace the water drain pump in your Kenmore 110.26832692 washer. Refer to your washer's specific service manual for detailed diagrams if necessary.



Image 1: Overview of the replacement water drain pump. This component is responsible for expelling water from the washer tub during the drain cycle.

1. **Prepare the Washer:** Disconnect the washer from its power source and turn off the water supply. Pull the washer away from the wall to access the rear.
2. **Access the Pump:** Depending on your specific Kenmore 110.26832692 model, you may need to remove the front panel, rear panel, or tilt the washer back to access the drain pump located at the bottom. Consult your washer's service manual for exact access procedures.

- 3. **Drain Residual Water:** Place a shallow pan or towels under the pump area to catch any remaining water in the hoses. Carefully disconnect the hoses attached to the old drain pump.
- 4. **Remove Old Pump:** Locate the mounting screws or clips securing the old drain pump. Remove them and carefully detach the pump from its mounting bracket. Disconnect any electrical wiring connected to the pump.
- 5. **Install New Pump:** Connect the electrical wiring to the new drain pump. Ensure connections are secure. Mount the new pump onto the bracket using the original screws or clips.
- 6. **Connect Hoses:** Reattach the drain hoses to the new pump. Ensure all clamps are tightened to prevent leaks.
- 7. **Reassemble Washer:** Reinstall any panels or covers that were removed to access the pump.
- 8. **Test Operation:** Reconnect the washer to the power supply and turn on the water. Run a short drain/spin cycle to check for proper operation and any leaks.

OPERATING PRINCIPLES

The water drain pump is an integral component of your washing machine's drainage system. During the wash and rinse cycles, once the water needs to be expelled from the tub, the washer's control system activates the drain pump. The pump then draws water from the washer tub and forces it through the drain hose, effectively emptying the machine. Proper functioning of this pump ensures that water is removed efficiently, allowing the spin cycle to effectively remove moisture from your laundry.

MAINTENANCE

To ensure the longevity and efficient operation of your drain pump, consider the following maintenance tips:

- **Regular Cleaning:** Periodically check the washer's drain filter (if accessible and present in your model) for lint, coins, or other debris that could obstruct the pump.
- **Avoid Overloading:** Overloading the washer can put undue stress on the pump and other components.
- **Inspect Hoses:** Occasionally inspect the drain hoses for kinks, blockages, or damage that could impede water flow.

TROUBLESHOOTING

If your washer is experiencing drainage issues after pump replacement, refer to the table below for common problems and potential solutions:

Problem	Possible Cause	Solution
Washer not draining	<ul style="list-style-type: none">◦ Clogged drain hose◦ Kinked drain hose◦ Pump impeller obstructed◦ Electrical connection issue	<ul style="list-style-type: none">◦ Check and clear the drain hose for blockages.◦ Straighten any kinks in the drain hose.◦ Disconnect power, access the pump, and check for debris around the impeller.◦ Verify all electrical connections to the pump are secure.
Loud noise during drain cycle	<ul style="list-style-type: none">◦ Debris in pump◦ Loose pump mounting	<ul style="list-style-type: none">◦ Disconnect power and inspect the pump for foreign objects.◦ Ensure the pump is securely mounted to its bracket.

Problem	Possible Cause	Solution
Water leaking from pump area	<ul style="list-style-type: none">◦ Loose hose clamps◦ Damaged hoses◦ Improperly seated pump	<ul style="list-style-type: none">◦ Tighten all hose clamps.◦ Inspect hoses for cracks or tears and replace if necessary.◦ Ensure the pump is correctly installed and sealed.

If troubleshooting steps do not resolve the issue, it is recommended to contact a qualified appliance repair technician.

SPECIFICATIONS

- **Product Type:** Washer Water Drain Pump (Replacement Part)
- **Compatibility:** Kenmore Washer Model 110.26832692
- **Manufacturer:** 20 SECOND SOAP (Supplier of this replacement part)
- **UPC:** 689035815232
- **ASIN:** B0DBGGY267



WARRANTY AND SUPPORT

For information regarding the warranty of this replacement part or for technical support, please refer to the documentation provided by the seller or manufacturer at the time of purchase. You may also contact the seller directly through the platform where the purchase was made.



This manual is for informational purposes only. Always prioritize safety and consult a professional if needed.

Related Documents - 110.26832692

	<p>Kenmore Elite 796.4127# Front-Loading Automatic Washer Use & Care Guide</p> <p>Comprehensive Use & Care Guide for the Kenmore Elite 796.4127# Front-Loading Automatic Washer, covering installation, operation, maintenance, troubleshooting, and warranty information.</p>
	<p>Kenmore 40512 Owner's Manual and Use & Care Guide</p> <p>Comprehensive Owner's Manual and Use & Care Guide for the Kenmore Elite 796.4051# front-loading automatic washer. Covers installation, operation, maintenance, troubleshooting, and warranty details. Provided by Sears.</p>



**Kenmore 41022
Owner's Manual**

[Shop genuine replacement parts for Kenmore 41022](#)



[Find Your Kenmore Washer Parts - Select From 132 Models](#)

Manual continues below

[Kenmore 41022 Elite Front-Loading Washer: Owner's Manual & Use and Care Guide](#)

Detailed owner's manual and use & care guide for the Kenmore 41022 Elite front-loading automatic washer. Includes installation, operation, maintenance, troubleshooting, and warranty information.



Kenmore.
Two-Speed
Speed Control



STIRRA, BATHURST AND CO., BATHURST, TASMANIA, N. H. 9710-0333.
 PO BOX 100000, TASMANIA, N. H. 9710-0000.

[Kenmore Two-Speed Speed Control Automatic Washer Owner's Manual and Installation Instructions](#)

This document provides comprehensive owner's manual and installation instructions for the Kenmore Two-Speed Speed Control Automatic Washer. It covers essential safety precautions, detailed installation steps, operating procedures, laundry tips, maintenance guidelines, and troubleshooting advice.



U-56

Front-Loading Aut

Use & Care Guide
Lavadora automática
Manual de Uso y Cuidado

Laveuse automatique
Guide d'utilisation et c
Model Model Model 110-4788



DOI: 10.1002/anie.200500014

Kenmore Elite HE 5t Front-Loading Automatic Washer Use & Care Guide

This comprehensive guide provides essential information for the Kenmore Elite HE 5t front-loading automatic washer. Learn about installation requirements, safe operation, features and benefits, maintenance, and troubleshooting tips to ensure optimal performance and longevity of your appliance.



E L I T E

 H_{E^3}

Front-Loading Aut
 Completely automatic and
 1 modern automa

Laveuse automatique
Manual del propietario
Laveuse automatique
Manual del propietario



0000 01 00000000	0000000000000000
	0000000000000000

[Kenmore Elite HE3 Front-Loading Automatic Washer Owner's Manual and Installation Instructions](#)

Owner's manual and installation guide for the Kenmore Elite HE3 front-loading automatic washer, covering setup, operation, safety, and maintenance. Includes model numbers 110.4282, 110.4483, 110.4482.