

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [XIAOMI](#) /
- › [Xiaomi Handheld Garment Steamer BHR8269EU User Manual](#)

## XIAOMI BHR8269EU

# Xiaomi Handheld Garment Steamer User Manual

Model: **BHR8269EU** | Brand: **XIAOMI**

## INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Xiaomi Handheld Garment Steamer. Please read it thoroughly before operating the device and keep it for future reference.


### Key Features:

- **Compact and Portable:** Designed for easy use at home or while traveling.
- **Quick Heating:** Ready to use in a short time for efficient wrinkle removal.
- **Versatile Fabric Care:** Suitable for a wide range of fabrics, from delicate silk to sturdy denim.
- **Powerful Steam Output:** Effectively removes wrinkles and refreshes garments.

## PACKAGE CONTENTS

Ensure all items are present in the package:

- Xiaomi Handheld Garment Steamer (Model BHR8269EU)
- Water Tank
- Brush Attachment
- User Manual



**Image:** Components included with the Xiaomi Handheld Garment Steamer, illustrating the main unit, a stand, a protective glove, and the user manual.

## SETUP

---

### 1. **Fill the Water Tank:**

Remove the water tank from the main unit. Fill the tank with clean tap water up to the maximum fill line. Ensure the tank is securely reattached to prevent leaks.



**Image:** The Xiaomi Handheld Garment Steamer, showing the transparent water tank at the base of the handle.

## 2. **Attach Accessories (Optional):**

If using the brush attachment for thicker fabrics or to remove lint, securely attach it to the steamer head.

### 3. **Connect to Power:**

Plug the steamer into a suitable power outlet. The indicator light will illuminate, signaling that the device is heating up.

## **OPERATING INSTRUCTIONS**

---

### 1. **Pre-heating:**

Allow the steamer to heat for approximately 30-45 seconds until the indicator light changes or stops blinking, indicating it's ready for use.

### 2. **Steaming Garments:**

Hold the garment taut with one hand. With the other hand, hold the steamer upright and press the steam trigger. Move the steamer head slowly over the fabric, allowing the steam to penetrate and relax the fibers. For best results, steam from top to bottom.



**Image:** A detailed view of the steamer's soleplate, highlighting the steam vents for efficient wrinkle removal.



**Image:** Side profile of the Xiaomi Handheld Garment Steamer, emphasizing its compact and ergonomic design for comfortable handling.



**Image:** A person demonstrating the use of the Xiaomi Handheld Garment Steamer, with steam effectively smoothing out wrinkles on a fabric.

### 3. **Steaming Delicate Fabrics:**

For delicate materials like silk or linen, hold the steamer slightly away from the fabric to avoid direct contact, or use a protective cloth if provided.

### 4. **Steaming Thick Fabrics:**

For thicker fabrics such as denim or wool, use the brush attachment to help lift fibers and allow steam to penetrate more deeply.

### 5. **Finishing:**

Once steaming is complete, release the steam trigger and allow the garment to cool and dry before wearing or storing.

### **Official Product Videos:**

Your browser does not support the video tag.

**Video:** Demonstration of the handheld steamer's features, including water filling, steam output, and use on various fabrics. This video highlights its 2-in-1 functionality for both flat and hanging garments.

Your browser does not support the video tag.

**Video:** A summary of the product's key benefits and ease of use, showcasing its effectiveness in quickly smoothing clothes.

## MAINTENANCE

---

### 1. **Empty Water Tank:**

After each use, unplug the steamer and allow it to cool completely. Empty any remaining water from the tank to prevent mineral buildup.

### 2. **Cleaning the Steamer Head:**

Wipe the steamer head with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.

### 3. **Descaling (Periodically):**

If you notice reduced steam output or mineral residue, descale the steamer by filling the tank with a mixture of equal parts white vinegar and water. Run the steamer until the tank is empty, then rinse thoroughly with clean water.

### 4. **Storage:**

Store the steamer in a cool, dry place. Its compact design makes it easy to store or pack for travel.



**Image:** The Xiaomi Handheld Garment Steamer shown packed inside a suitcase, demonstrating its portability and ease of travel.

## TROUBLESHOOTING

- **No Steam Output:**

- Check if the water tank is filled and properly seated.
- Ensure the steamer is plugged in and has had sufficient time to heat up.
- Descale the unit if mineral buildup is suspected.

- **Water Leaking:**

- Verify the water tank is securely attached and the cap is tightly closed.
- Ensure the steamer is held upright during use. Tilting too much can cause leaks.

- **Steamer Not Heating:**

- Check the power connection and ensure the outlet is functional.
- Allow adequate pre-heating time.

## SPECIFICATIONS

<b>Brand</b>	XIAOMI
<b>Model Number</b>	BHR8269EU
<b>Power</b>	1300 Watts
<b>Voltage</b>	12 Volts
<b>Water Tank Capacity</b>	160 Milliliters
<b>Dimensions (L x W x H)</b>	19.99 x 19.99 x 14 cm
<b>Weight</b>	500 grams
<b>Material</b>	Plastic
<b>Color</b>	Rose
<b>Product Benefits</b>	Wrinkle Removal

## WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included in your product packaging or visit the official XIAOMI website. Keep your proof of purchase for any warranty claims.

For further assistance, you may contact XIAOMI customer service through their official channels.