

[Manuals.plus](#) /

› [Dreamflame](#) /

› Dreamflame 50-inch Electric Fireplace Instruction Manual

Dreamflame 50-inch Electric Fireplace

Dreamflame 50-inch Electric Fireplace

Model: bf6338ff-c8de-42f1-b2b4-b3e8ee946f2c

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before installing, operating, or servicing this electric fireplace. Failure to follow these instructions may result in fire, electric shock, or personal injury.

- Always unplug the fireplace when not in use or before cleaning.
- Do not operate any fireplace with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors. This fireplace is intended for indoor use only.
- Keep combustible materials such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the fireplace.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fireplace.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This fireplace is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Always use properly grounded, fused outlets.
- Do not cover the front air outlet on top of the fireplace heater.

PRODUCT OVERVIEW

The Dreamflame 50-inch Electric Fireplace offers a modern heating and aesthetic solution for your home. It features realistic flame effects with adjustable colors and brightness, along with a powerful heater to provide supplemental warmth.


Key features include:

- **Realistic Flame & Modern Décor:** Features realistic logs and crystal clear cube ember beds, which can be used separately or combined for various visual effects. Includes 3 colors of top light and 3 colors of flame for a customizable ambiance.
- **Energy-effective Heater & Safety:** Offers two heating options (750W/1500W) to heat rooms up to 400 sq. ft. Equipped with a thermostat (71°F ~ 99°F) and overheating protection.
- **Dual Installation Options:** Can be easily wall-mounted or recessed into a wall or fireplace cabinet.
- **Convenient Control:** Operates via a hidden touchscreen panel and an included remote control.



Modern High Quality


Strong rust
resistant material



Hand-painted Realistic
Logs without ash



Hidden
Touchscreen panel



Multicolor
Mood lights



Image: The Dreamflame 50-inch Electric Fireplace showcasing its modern design, strong rust-resistant material, hand-painted realistic logs, hidden touchscreen panel, and multicolor mood lights.

PACKAGE CONTENTS

Please check that all components are present and undamaged before installation.

- Dreamflame 50-inch Electric Fireplace Unit

- Remote Control (requires 2 AAA batteries, not included)
- Mounting Bracket
- Log Set
- Crystal Ember Bed
- Hardware for installation (screws, anchors)
- User Manual

INSTALLATION

This electric fireplace offers both wall-mounted and recessed installation options. Ensure you have the necessary tools and follow all safety guidelines.

Dimensions and Clearance

Before installation, ensure you have adequate space and maintain proper clearances. The overall dimensions are 50.0" W x 6.0" D x 17.7" H. For recessed installation, the insert part dimensions are 48.8" W x 5.5" D x 16.9" H. Always reserve some space for the plug-in cable and air vent.





Image: Detailed dimensions of the 50-inch electric fireplace, including overall size and recessed insert dimensions, crucial for planning installation.

Wall-Mounted Installation

1. Choose a suitable location on a wall, ensuring it is away from combustible materials and has access to a grounded electrical outlet.
2. Attach the mounting bracket (included) to the wall using appropriate screws and anchors, ensuring it is level and securely fastened to wall studs if possible.
3. Carefully lift the fireplace unit and hook it onto the mounting bracket. Ensure it is securely seated.
4. Plug the fireplace into a grounded 120V AC outlet.

Recessed Installation

1. Construct a framed opening in your wall or cabinet with dimensions of approximately 49.2" W x 6.25" D x 17.25" H. Ensure the framing is sturdy and can support the weight of the fireplace.
2. Ensure there is access to a grounded electrical outlet within the framed opening or nearby.
3. Carefully slide the fireplace unit into the framed opening.

4. Secure the fireplace to the framing using the provided screws through the designated mounting holes on the sides of the unit.
5. Plug the fireplace into a grounded 120V AC outlet.



Simple Installation for variety spaces



Image: Visual guide illustrating both wall-mounted and recessed installation methods for the electric fireplace, showing how the mounting bracket is used for wall-mounting and the required cavity for recessed installation.

OPERATING INSTRUCTIONS

The Dreamflame electric fireplace can be operated using the hidden touchscreen panel on the unit or the included remote control.

Remote Control and Touchscreen Panel

The remote control provides full functionality. The touchscreen panel offers direct access to all settings.

Dual Control Methods




Image: The remote control and the hidden touchscreen panel of the electric fireplace, with labels indicating functions such as Temperature, Timer, Heater, Mood Light, Flame Color, and Power.

- **Power Button:** Turns the fireplace ON or OFF.
- **Flame Color Button:** Cycles through various flame color options (e.g., orange, blue, purple, or combinations).
- **Mood Light Button:** Adjusts the color of the top mood lighting (3 colors available).
- **Heater Button:** Activates the heating function. Press to cycle between 750W and 1500W heat settings, or turn off the heater while flames remain on.
- **Timer Button:** Sets the automatic shut-off timer from 1 to 9 hours.
- **Temperature Button:** Adjusts the thermostat setting from 71°F to 99°F. The heater will cycle on and off to maintain the set temperature.

Flame and Ember Bed Customization

The fireplace allows for customization of the flame appearance and ember bed.

Bright and Clear Flame from LED technology



Logs&Crystals



Two Bed Fuel



Crystals



Image: Examples of bright and clear LED flame technology, showing different flame colors (orange, blue, purple) and the two bed fuel options: logs and crystals, which can be combined.

- Use the **Flame Color Button** to select your desired flame effect.
- The fireplace comes with both a log set and crystal ember bed. You can choose to use either, or a mixture of both, to create your preferred visual effect.

Heating Function

The heater provides supplemental warmth for areas up to 400 sq. ft.



Image: The electric fireplace operating with the heating function, showing temperature settings from 71°F to 99°F and heating options of 750W/1500W, indicating sufficient heat for up to 400 sq. ft.

- Press the **Heater Button** to activate the heating element.
- Toggle between 750W (low heat) and 1500W (high heat) settings.
- Use the **Temperature Button** to set your desired room temperature. The heater will automatically turn on and off to maintain this setting.
- The heat can be switched off independently while the flame effects remain active.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your electric fireplace.

- **Cleaning:** Always unplug the fireplace before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or sprays.
- **Ventilation:** Ensure the air intake and exhaust vents are clear of dust and debris. Periodically vacuum these areas.

- **Light Bulbs:** The flame effect uses LED technology, which typically does not require replacement.
- **Storage:** If storing the fireplace for an extended period, unplug it and store it in a dry, dust-free location.

TROUBLESHOOTING

If you encounter issues with your fireplace, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power to the unit; Power cord not plugged in; Circuit breaker tripped.	Ensure the power cord is securely plugged into a grounded outlet. Check the household circuit breaker.
No heat output.	Heater function is off; Thermostat set too low; Overheat protection activated.	Press the Heater button to turn on the heating function. Increase the thermostat setting. Unplug the unit for 15 minutes to reset the overheat protection.
Flame effect not working.	Flame effect is off; Internal component issue.	Ensure the fireplace is powered on and the flame effect is activated. If the issue persists, contact customer support.
Remote control not working.	Batteries are dead or incorrectly inserted; Remote sensor blocked.	Replace batteries (2 AAA). Ensure there are no obstructions between the remote and the fireplace sensor.

If you experience any issues not listed here or if the problem persists, please contact Dreamflame customer support.

SPECIFICATIONS

- **Brand:** Dreamflame
- **Model Number:** bf6338ff-c8de-42f1-b2b4-b3e8ee946f2c
- **Product Dimensions (Overall):** 127 cm W x 14 cm D x 43.2 cm H (50.0" W x 6.0" D x 17.7" H)
- **Recessed Insert Dimensions:** 48.8" W x 5.5" D x 16.9" H
- **Material:** Metal
- **Color:** Black
- **Power Source:** AC (Corded)
- **Heating Options:** 750W / 1500W
- **Heating Coverage:** Up to 400 sq ft
- **Thermostat Range:** 71°F ~ 99°F
- **Flame Colors:** Multiple (3 main colors + combinations)
- **Mood Light Colors:** 3 colors
- **Timer:** 1-9 hours
- **Control Methods:** Touchscreen Panel, Remote Control
- **Installation Type:** Wall Mount, Recessed
- **Item Weight:** 28.9 kg

- **Batteries for Remote:** 2 AAA (not included)

WARRANTY AND SUPPORT

Dreamflame provides a **1-year quality warranty** for this electric fireplace. We also offer **Lifetime Support** for our products.

If you have any questions, concerns, or require assistance with your Dreamflame electric fireplace, please do not hesitate to contact our customer support team. Please have your model number and purchase information ready when contacting support.

For further assistance, please visit the [Dreamflame Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question