

[Manuals.plus](#) /

> [HOMCOM](#) /

> HOMCOM Tilt-Out Laundry Hamper, Laundry Cabinet with Removable Basket and Drawer, Bathroom Storage Cabinet, White - User Manual

HOMCOM 834-704V80WT

HOMCOM Tilt-Out Laundry Hamper User Manual

Model: 834-704V80WT | Brand: HOMCOM

1. INTRODUCTION

Thank you for choosing the HOMCOM Tilt-Out Laundry Hamper. This versatile cabinet is designed to provide efficient storage and organization for your laundry and bathroom essentials. It features a convenient tilt-out design with a removable laundry basket and an additional top drawer for smaller items. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following safety guidelines:

- **Secure the cabinet to the wall to prevent tipping, especially in households with children or pets.** Use the provided anti-tipping hardware.
- Do not overload the cabinet or the laundry hamper beyond the specified weight capacities.
- Ensure all screws and fasteners are tightened securely during assembly and periodically check for looseness.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Assemble the unit on a soft, clean surface to prevent scratches.



Image: Anti-tipping design for enhanced stability. Always secure the cabinet to a wall.

3. PACKAGE CONTENTS

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (various sizes)
- Tilt-Out Door
- Top Drawer
- Removable Fabric Laundry Hamper
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Tipping Hardware
- Instruction Manual

4. ASSEMBLY AND SETUP

Assembly is required for this product. Please follow the step-by-step instructions provided in the separate assembly guide included with your package. It is recommended to have a second person assist with

assembly for easier handling and safety.

- **Tools Required:** Typically a Phillips head screwdriver and possibly a hammer.
- **Preparation:** Clear a spacious area for assembly. Lay out all parts and hardware, organizing them by type.
- **Step-by-Step:** Follow the numerical sequence in the assembly guide. Do not overtighten screws.
- **Anti-Tipping Device:** Crucially, install the anti-tipping device as instructed to secure the cabinet to a wall stud.



Image: The assembled laundry hamper cabinet in a bathroom environment.

5. OPERATING INSTRUCTIONS

The HOMCOM Tilt-Out Laundry Hamper is designed for convenient laundry management and storage.

- **Using the Tilt-Out Hamper:** Gently pull the handle on the front panel to tilt the door outwards. The fabric laundry basket is suspended inside. Place dirty clothes directly into the basket.
- **Removing the Laundry Basket:** The fabric basket is removable and foldable. Simply lift it off its support rod to transport clothes to your laundry room. This eliminates the need to move the entire cabinet.
- **Using the Top Drawer:** The top drawer provides additional storage space for smaller items such as

detergent, dryer sheets, toiletries, or other bathroom supplies. Pull the knob to open the drawer.



Image: Labeled view highlighting the extra storage drawer and the convenient fabric basket.



Image: Detail of the removable fabric basket attachment.

6. MAINTENANCE

To keep your HOMCOM laundry hamper in optimal condition, follow these maintenance tips:

- **Cleaning:** The painted MDF frame resists water and has a smooth surface that is easy to clean. Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Spills:** Promptly wipe up any spills to prevent water damage, especially on the wooden top surface.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain stability.
- **Fabric Basket:** The fabric basket can be spot cleaned or hand washed as needed. Allow it to air dry completely before reinserting into the cabinet.

7. TROUBLESHOOTING

If you encounter any issues with your laundry hamper, please refer to the following common troubleshooting steps:

- **Cabinet Feels Unstable/Wobbly:**

- Ensure all assembly screws are fully tightened.
- Verify that the cabinet is placed on a flat, level surface.
- Confirm that the anti-tipping device is correctly installed and securely anchored to the wall.

- **Drawer or Tilt-Out Door Does Not Operate Smoothly:**

- Check for any obstructions in the drawer slides or hinge mechanisms.
- Ensure all hardware related to the drawer slides and hinges is properly installed and tightened.

- **Missing or Damaged Parts:**

- Refer to the package contents list. If parts are missing or damaged upon arrival, contact customer support immediately for replacements.

8. SPECIFICATIONS

Feature	Detail
Overall Dimensions (L x W x H)	20.5" x 13" x 35.4" (52 x 33 x 90 cm)
Weight Capacity (Top)	22 lbs (10 kg)
Weight Capacity (Hamper/Drawer)	11 lbs (5 kg) each
Hamper Volume	14.4 gallons (54.5 L)
Material	Engineered Wood (Painted MDF)
Color	White
Special Features	Anti-Tipping, Removable Hamper, Anti-slip Foot Pads
Installation Method	Freestanding (with wall anchor recommended)



Image: Product dimensions for planning placement.

9. WARRANTY AND SUPPORT

This HOMCOM product comes with a **90-day warranty against manufacturer defects** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, missing parts, or any product-related inquiries, please contact Aosom Canada, the manufacturer, directly:

- **Manufacturer:** Aosom Canada
- **Phone:** 1-416-792-6088
- **Place of Business:** Markham, Ontario, CA
- **Online Store:** [Visit the HOMCOM Store on Amazon.ca](#)

Please retain your proof of purchase for warranty validation.

