

LITFAD LT1235086N

LITFAD Solid Wood Floating TV Stand Instruction Manual

Model: LT1235086N

INTRODUCTION

Thank you for purchasing the LITFAD Solid Wood Floating TV Stand. This manual provides essential information for the safe assembly, installation, and proper use of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

- Always follow the assembly instructions precisely. Incorrect assembly can lead to instability and potential injury.
- Ensure the wall you intend to mount the TV stand on is suitable and can support the weight of the unit and its contents. Consult a professional if unsure.
- Do not exceed the maximum load-bearing capacity of 200kg (440 lbs).
- Keep small parts and packaging materials away from children during assembly.
- Regularly check all connections and fasteners to ensure they remain tight and secure.
- The rounded-corner design minimizes collision risk, but exercise caution during installation and use.

PACKAGE CONTENTS

Before assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Floating TV Stand Unit (1 piece)
- Assembly Hardware Kit (screws, anchors, brackets, etc.)
- Assembly Tool (e.g., Allen wrench)
- Instruction Manual (this document)



Image: The LITFAD Solid Wood Floating TV Stand installed in a modern living room, showcasing its design and functionality.

SPECIFICATIONS

Category	Floating TV Stand
Model Number	LT1235086N
Dimensions (L x W x H)	63" x 9.5" x 8" (160cm x 24cm x 20cm)
Material	Wood (Rubber Wood)
Color	Natural
Number of Drawers	2
Number of Cabinets	1 (flip-down door)

Load-bearing Capacity	200kg (440 lbs)
Assembly Level	Partial Assembly
Special Features	Cable Management, Rounded Corners




Image: Detailed dimensions of the TV stand, indicating length, width, and height.

SETUP AND ASSEMBLY INSTRUCTIONS

This TV stand requires partial assembly and wall mounting. It is recommended that two people perform the installation for safety and ease.

Tools Required (Not Included):

- Drill
- Level
- Measuring Tape
- Pencil
- Stud Finder (recommended for wooden walls)

Assembly Steps:

- 1. Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the included parts list to ensure all pieces are present.
- 2. Assemble the Main Unit:** Follow the detailed diagrams in the separate assembly manual to connect the main sections of the TV stand. This typically involves attaching the back panel, side panels, and internal dividers.
- 3. Install Drawers and Cabinet Door:** Assemble the drawers and attach the cabinet flip-down door according to the

instructions. Ensure they slide smoothly and close properly.

4. **Choose Mounting Location:** Select a suitable wall location. The stand can be mounted on dry walls, wooden walls, plastered walls, and solid walls. Use a stud finder for wooden walls to ensure secure attachment to studs.
5. **Mark Drilling Points:** Hold the assembled TV stand against the wall at the desired height. Use a level to ensure it is perfectly horizontal. Mark the drilling points for the mounting brackets with a pencil.
6. **Drill Pilot Holes:** Drill pilot holes at the marked points. The size of the drill bit should match the wall anchors provided.
7. **Install Wall Anchors and Brackets:** Insert the appropriate wall anchors into the pilot holes. Secure the mounting brackets to the wall using the provided screws. Ensure the brackets are firmly attached.
8. **Mount the TV Stand:** Carefully lift the TV stand and align it with the installed wall brackets. Secure the stand to the brackets using the remaining hardware. Double-check that the stand is stable and securely fastened to the wall.



Image: The fully assembled LITFAD Floating TV Stand, ready for use.

OPERATING INSTRUCTIONS

Once securely installed, your LITFAD Floating TV Stand is ready for use.

- **Storage:** Utilize the two drawers and the flip-down cabinet for organizing media accessories, remote controls, and other items.
- **Cable Management:** The stand features a hollow back and cable management holes. Route your TV and media device cables through these openings to maintain a tidy appearance and prevent tangles.
- **Weight Distribution:** Distribute the weight of items placed on the stand evenly. Avoid placing excessively heavy objects on one side. Remember the maximum load capacity of 200kg.



Image: The TV stand with drawers and cabinet open, demonstrating its storage capabilities.



Covering wall sockets



Loading capacity: 200kg

Image: Illustration of the integrated cable management system and the stand's robust 200kg load capacity.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your LITFAD Floating TV Stand.

- **Cleaning:** Wipe the surface with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the wood finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads.
- **Fasteners:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary.

TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Stand feels unstable after mounting:**
 - Ensure all mounting screws are fully tightened.
 - Verify that the wall anchors are appropriate for your wall type and correctly installed.
 - If mounting to drywall, ensure you have secured it to wall studs where possible, or used heavy-duty drywall anchors.
- **Drawers do not slide smoothly:**

- Check that the drawer slides are correctly aligned and installed.
- Ensure no debris is obstructing the drawer tracks.
- Verify that the stand itself is level.

- **Cabinet door does not close properly:**

- Inspect the hinges for proper alignment and tightness.
- Ensure nothing inside the cabinet is obstructing the door's path.

If these steps do not resolve the issue, please contact LITFAD customer support for further assistance.

WARRANTY AND SUPPORT

LITFAD is committed to providing high-quality products. For specific warranty details, please refer to the warranty card included with your purchase or visit the official LITFAD website. For any questions, concerns, or assistance with your product, please contact LITFAD customer support through the retailer where you purchased the item or via the contact information provided on the LITFAD brand store page.

You can visit the LITFAD Store for more information: [LITFAD Store on Amazon](#)

© 2024 LITFAD. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question