

LITFAD LT1235086WW-63"L

LITFAD Solid Wood Floating TV Stand Instruction Manual

Model: LT1235086WW-63"L

1. INTRODUCTION

Thank you for choosing the LITFAD Solid Wood Floating TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new TV console. Please read these instructions carefully before beginning assembly and retain them for future reference.

This floating TV stand is designed to provide a modern and space-saving solution for your entertainment needs, featuring integrated storage and cable management.

2. SAFETY INFORMATION

Your safety is paramount. Please observe the following guidelines:

- Ensure all components are securely fastened during assembly. Loose parts can lead to instability.
- The TV stand must be mounted on a suitable wall type (dry walls, wooden walls, plastered walls, solid walls) using appropriate hardware. Consult a professional if unsure about your wall's capacity.
- Do not exceed the maximum load-bearing capacity of 200kg (approximately 440 lbs). Distribute weight evenly.
- The design incorporates rounded corners to minimize collision damage, enhancing safety, especially in homes with children.
- Keep small parts and packaging materials away from children during assembly to prevent choking hazards.



Image: Close-up view of the TV stand's rounded corner, highlighting the smooth, safety-conscious design.

3. PACKAGE CONTENTS

Before assembly, verify that all items listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Floating TV Console Unit
- Assembly Tools (as required)
- Instruction Manual (this document)
- Mounting Hardware (screws, anchors, etc.)

4. SPECIFICATIONS

Category	Floating TV Stand
----------	-------------------

Style	Modern / Creative / Simple
Dimensions (L x W x H)	63" x 9.5" x 8" (160cm x 24cm x 20cm)
Material	Wood (Rubber Wood)
Color	Wood/White
Drawers Included	2
Cabinets Included	1 (with flip-down door)
Cable Management	Included (Hollow back and cable management hole)
Load-bearing Capacity	200kg (approx. 440 lbs)
Assembly Level	Partial Assembly Required





Image: Dimensional diagram of the LITFAD Floating TV Stand, illustrating its length (63 inches), width (9.5 inches), and height (8 inches).

5. SETUP AND INSTALLATION

This floating TV stand requires wall mounting. Follow these steps for a secure installation:

- 1. Choose Location:** Select a suitable wall in your living room or bedroom. Ensure the wall is capable of supporting the weight of the TV stand and its contents. This stand is compatible with dry walls, wooden walls, plastered walls, and solid walls.
- 2. Mark Mounting Points:** Using a level and measuring tape, mark the desired height and mounting points on the wall according to the stand's pre-drilled holes.

3. **Drill Pilot Holes:** Drill pilot holes at the marked points. Use a drill bit appropriate for your wall type and the provided wall anchors.
4. **Install Wall Anchors:** Insert the wall anchors into the pilot holes. For wooden walls, anchors may not be necessary if screws can be directly driven into studs.
5. **Attach Mounting Brackets (if applicable):** If separate mounting brackets are provided, attach them to the wall using the screws.
6. **Mount the TV Stand:** Carefully lift the TV stand and align its mounting points with the wall anchors or brackets. Secure the stand to the wall using the provided screws. Ensure it is level and firmly attached.
7. **Assemble Drawers and Cabinet:** Follow the specific instructions for assembling and installing the drawers and the flip-down cabinet door.



Image: The LITFAD Floating TV Stand installed on a wall, positioned beneath a wall-mounted television, showcasing its modern aesthetic and space-saving design.



Covering wall sockets



Loading capacity: 200kg

Image: A visual demonstration of the TV stand's hollow back design for covering wall sockets and its robust load-bearing capacity, illustrated with multiple water bottles.

6. OPERATING INSTRUCTIONS

Once installed, your floating TV stand is ready for use:

- **Storage:** Utilize the two drawers and the flip-down cabinet for discreet storage of media accessories, remote controls, DVDs, or other items.
- **Cable Management:** The stand features a hollow back and dedicated cable management holes. Route your device cables through these openings to keep them organized and out of sight, maintaining a clean and tidy appearance. This design helps to conceal power strips and messy wires.
- **Placement:** The top surface can accommodate various media devices such as DVD players, DVRs, high-definition video recorders, cable TV boxes, AV components, and routers.



Image: An angled view of the LITFAD Floating TV Stand with its two drawers pulled open, revealing ample storage space for various items.

7. MAINTENANCE

To ensure the longevity and appearance of your LITFAD Floating TV Stand, follow these simple maintenance instructions:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the wood finish and paint.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or water damage to the wood.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Environmental Conditions:** Avoid placing the stand in direct sunlight or near heat sources, which can cause fading or warping of the wood. Maintain a stable room temperature and humidity.

8. TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Stand feels wobbly after installation:** Ensure all mounting screws are fully tightened and that the wall anchors are properly seated. Verify that the wall material is suitable for the mounting hardware used.
- **Drawers do not slide smoothly:** Check for any obstructions in the drawer glides. Ensure the drawers are correctly aligned and that all assembly screws for the drawer slides are tight.
- **Visible cables despite management features:** Re-route cables through the designated holes and hollow back area. Use cable ties (not included) to bundle and secure excess wiring.
- **Surface scratches or minor damage:** For minor scratches on the wood, a wood repair marker or furniture polish designed for wood surfaces may be used. For painted surfaces, touch-up paint matching the original color may be applied carefully.

9. WARRANTY INFORMATION

LITFAD products are manufactured with quality and durability in mind. For specific warranty details regarding your floating TV stand, please refer to the warranty card included with your purchase or visit the official LITFAD website. Typically, warranties cover manufacturing defects under normal use conditions.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact LITFAD customer service. You can typically find contact information on the product packaging, the official LITFAD website, or through your retailer's support channels.

We are committed to providing high-quality products and support to ensure your satisfaction.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question