

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [ZMISHIBO](#) /

› [ZMISHIBO ZMCF005 19.7" Low Profile Ceiling Fan with Lights and Remote User Manual](#)

ZMISHIBO ZMCF005

ZMISHIBO ZMCF005 19.7" Low Profile Ceiling Fan with Lights and Remote User Manual

Model: ZMCF005

INTRODUCTION

Welcome to your new ZMISHIBO 19.7" Low Profile Ceiling Fan with Lights and Remote. This manual provides detailed instructions for safe installation, operation, and maintenance of your new ceiling fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

- Always disconnect power at the main circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting the fan's weight.
- Ensure all connections are tight and secure to prevent electrical shock or fire.
- Do not bend the fan blades during installation or cleaning.
- Keep children away from the fan during operation.
- This product is designed for indoor use only.

WHAT'S INCLUDED

Before installation, verify all components are present and undamaged.

- Fan Motor Host
- Light Body (LED Rings)
- Fan Blade
- Mounting Plate/Bracket
- Remote Control
- Screws and Hardware Kit
- Driver/Controller



Ultra Quiet Design


Enjoy a comfortable environment



Low Noise



6 Wind Speeds



This image displays all the individual components included in the ZMISHIBO ceiling fan package. Visible items include the main fan motor housing, the LED light rings, the transparent fan blades, the ceiling mounting bracket, the remote control, and various screws and connectors.

INSTALLATION GUIDE

Follow these steps for proper installation. For a visual guide, please refer to the official installation video.

This video provides a step-by-step guide on how to install the ZMISHIBO ceiling fan. It covers unpacking, assembling the fan components, wiring, and mounting the fan to the ceiling.

Step 1: Prepare the Fan Body

Loosen the four canopy screws on the fan motor host. Twist counterclockwise to remove the mounting plate. Thread the screw arm and the wire of the connected port through the fan motor host together. Tug lightly on the wire, keeping it at a certain length to connect the driver. Note that the nut does not need to be tightened at this point to make it easier to adjust the angle of the bracket in the next step. Check if the position of the bracket is correct, and then tighten the nut to facilitate the next step of connecting the lamp body. Lightly tug the wires to the right length, and secure the bracket and light body with screws.

Step 2: Install Fan Blade

Install the fan blade, taking care to secure it by turning it counterclockwise.

Step 3: Connect Wiring

Use the double-sided tape that comes on the back of the driver to secure it inside the back cover. Connect each of the 3 wires to a port on the driver.

Step 4: Mount to Ceiling

Install the ceiling bracket and hang the fan using the safety cable. Connect ceiling wiring, ensuring same color wiring connections (live, neutral, ground) are correctly matched. Secure the fan body to the ceiling bracket with screws.

OPERATING INSTRUCTIONS

Your ZMISHIBO ceiling fan can be controlled via the included remote control or a smart app (Bluetooth required).

Remote Control Functions

- **ON/OFF:** Turns the fan and light on/off.
- **ALL OFF:** Turns off all functions.
- **Light Brightness Adjustment:** Increase or decrease light brightness (10%-100%).
- **Color Temperature Adjustment:** Cycle through warm (3000K), natural (4000K), and white (6000K) light.
- **Night Light Mode:** Activates a dim, warm light setting.
- **Fan Speed:** Select from 6 wind speeds (1-6).
- **F/R (Forward/Reverse) Function:** Changes fan direction for summer (downdraft) or winter (updraft) modes.
- **Timer Setting:** Set a 2-hour timer for automatic shutdown.
- **Code Pair:** For pairing the remote with the fan.

App Control

Download the "Fanlamp Pro" app from Google Play or Apple Store. Follow the in-app instructions for Bluetooth pairing and control.



APP & Remote Control



This image illustrates the dual control options for the ZMISHIBO ceiling fan. On the left, the physical remote control is shown with buttons for light, fan speed, timer, and direction. On the right, a smartphone displays the 'Fanlamp Pro' app interface, mirroring the remote's functions for convenient control.

KEY FEATURES

- **LED Light Source:** Energy-saving LED with 120V output, 2200LM brightness (10%-100% dimmable), and 3 color temperatures (3000K-6000K). Features a light memory function.
- **Reversible DC Motor:** Offers 2 airflow modes for year-round comfort (downdraft for summer, updraft for winter).
- **Quiet Operation:** Pure copper motor ensures smooth operation with low noise ($\leq 30\text{dB}$).


- **6 Wind Speeds:** Provides superior airflow with 7 blades and adjustable speeds from soft to cool wind.
- **Timer Setting:** Convenient 2-hour timer function.



This image visually demonstrates the lighting capabilities of the ZMISHIBO ceiling fan. It shows three distinct color temperatures: warm white (3000K), natural white (4000K), and cool white (6000K). Below, a gradient bar illustrates the smooth dimming function, ranging from 10% to 100% brightness.




Reversible Air Circulation for Summer & Winter



This image explains the reversible air circulation feature of the ZMISHIBO ceiling fan. It shows arrows indicating forward cool airflow for summer mode and reverse warm airflow for winter mode. Different fan speeds are also associated with soft, natural, and cool wind.



Product Size



Memory Function



120 Volt



2200 LM



After-sales Service



Room Size:

Height:
7FT-10FT

Length & Width:
8.5FT x 8.5FT

This image emphasizes the quiet operation and multiple speed settings of the ZMISHIBO ceiling fan. It features a family relaxing in a room, with icons indicating 'Low Noise' and '6 Wind Speeds'. A graph at the bottom compares the fan's noise level ($\leq 30\text{dB}$) to typical conversation and meeting noise levels.

SPECIFICATIONS

Feature	Detail
Brand	ZMISHIBO
Model Number	ZMCF005

Feature	Detail
Color	White
Material	Acrylic
Style	Modern
Product Dimensions	5.7"L x 19.7"W x 19.7"H
Room Type	Bedroom, Home Office, Kids Room, Kitchen, Living Room
Special Features	6 Speeds, Adjustable Color Temperature, Dimmable, Reversible DC Motor, Timer Setting
Control Method	App, Remote Control
Light Source Type	LED
Voltage	120 Volts
Wattage	35 watts
Brightness	2200 Lumen
Color Temperature	3000K-6000K
Size	19.7 INCH
Item Weight	6.63 pounds
Batteries	2 AAA batteries required (included)
Installation Type	Flush Mount
Indoor/Outdoor Usage	Indoor



This image provides a detailed view of the product's dimensions, including its 19.7-inch diameter and 5.7-inch height. It also suggests suitable room sizes (Height: 7FT-10FT, Length & Width: 8.5FT x 8.5FT) for effective air circulation, along with key features like Memory Function, 120 Volt, 2200 LM, and 2-year After-sales Service.

MAINTENANCE

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** The fan blades are transparent and can be gently wiped clean.
- **Light Source:** The LED light source is integrated and not user-replaceable.
- **Regular Checks:** Periodically check all screw connections for tightness.

TROUBLESHOOTING

Fan Not Operating / Light Not Turning On

- Ensure power is supplied to the fan at the circuit breaker.
- Check all wire connections are secure.
- Verify remote control batteries are correctly installed and charged.
- Ensure the remote is properly paired with the fan (refer to "Code Pair" in operating instructions).

Fan is Noisy

- Check that all screws on the motor housing and mounting bracket are tight.
- Ensure the fan is securely mounted to the ceiling.
- The upgraded remote control eliminates beeping sounds for a peaceful environment.

Light Flickers or Changes Brightness Unexpectedly

- Check for loose wiring connections.
- Ensure the dimmer function is not accidentally activated.

If you encounter problems with the installation, you can click the video for installation guide or tell us.

WARRANTY AND SUPPORT

We provide 2-year support for this product. If you have any issues, please contact us, and we'll reply within 24 hours.

For further assistance, please visit the ZMISHIBO store on Amazon: [ZMISHIBO Store](#).