

vidaXL 852638

vidaXL Sonoma Oak Corner Wall Shelf 45x45x147 cm, 5 Tiers Instruction Manual

Model: 852638 | Brand: vidaXL

INTRODUCTION

This manual provides comprehensive instructions for the assembly, installation, and maintenance of your vidaXL Sonoma Oak Corner Wall Shelf. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This 5-tier corner shelf is designed to maximize space and provide a decorative and practical storage solution for your living room, bedroom, or other areas.

SAFETY INFORMATION

- **Wall Mounting:** Ensure to use appropriate screws and wall plugs suitable for your specific wall type for correct and secure installation. If you are unsure, consult a professional.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 60 kg for the entire unit. Distribute weight evenly across the shelves.
- **Stability:** Always ensure the shelf is securely mounted to the wall to prevent tipping or falling.
- **Children and Pets:** Keep small parts away from children and pets during assembly. Do not allow children to climb on the shelf.
- **Read Instructions:** Read and follow all instructions carefully for safe product use and to prevent injury or damage.

SPECIFICATIONS

Feature	Detail
Brand	vidaXL

Model	852638
Color	Sonoma Oak
Material	Engineered Wood
Dimensions (L x W x H)	45 x 45 x 147 cm (17.7 x 17.7 x 57.9 inches)
Number of Tiers	5
Maximum Load Capacity	60 kg (132 lbs)
Item Weight	11.7 kg (25.8 lbs)
Mounting Type	Wall Mount

The shelf features a practical design, making it a focal point in any room. Its engineered wood construction ensures robustness, stability, and resistance to moisture, while being easy to clean.

PACKAGE CONTENTS

Please refer to the packaging for a complete list of components and hardware. Ensure all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, contact customer support.

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps to assemble and install your corner wall shelf:

- Unpack and Identify Parts:** Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided parts list in your packaging.
- Assemble the Shelf Units:** Follow the diagrams in your package to connect the individual shelf sections. Ensure all connections are tight and secure.
- Prepare for Wall Mounting:** Determine the desired location for your corner shelf. Use a level to mark the precise drilling points on the wall for the mounting brackets.
- Drill and Install Wall Plugs:** Drill holes at the marked locations. Insert appropriate wall plugs into the drilled holes. **Note:** Screws and wall plugs for the interior wall are not included. Use hardware suitable for your specific wall type (e.g., concrete, drywall, brick).
- Mount the Shelf:** Carefully align the shelf with the installed wall plugs and secure it using the provided screws. Ensure the shelf is firmly attached and stable.
- Cover Screw Holes:** Use the provided decorative stickers to cover any visible screw holes for a clean finish.




Figure 1: Product Dimensions



Figure 2: Detail of a Wall Mounting Point

Your browser does not support the video tag.

Video 1: This video demonstrates the installation process and features of a similar corner wall shelf. While the brand shown in the video is 'Edihome', the assembly and functionality are comparable to your vidaXL corner shelf.

OPERATING INSTRUCTIONS

Once securely installed, your corner wall shelf is ready for use. Place items such as books, decorative objects, small plants, or awards on the five tiers. Ensure that items are distributed evenly and do not exceed the maximum weight capacity of 60 kg for the entire unit. Avoid placing excessively heavy items on a single shelf to maintain stability.



Figure 3: Assembled Corner Wall Shelf with Decorative Items

MAINTENANCE

The engineered wood material of your vidaXL corner shelf is designed for easy maintenance. To keep your shelf in optimal condition:

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Promptly wipe up any spills to prevent moisture damage.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood finish.



Figure 4: Sonoma Oak Wood Grain Detail

TROUBLESHOOTING

- **Shelf is Wobbly:** Ensure all screws are tightened correctly. Verify that the wall plugs are appropriate for your wall type and securely installed. If the issue persists, re-evaluate the mounting points.
- **Parts Missing/Damaged:** If you find any parts missing or damaged upon opening the package, do not proceed with assembly. Contact vidaXL customer support for assistance.
- **Difficulty Assembling:** Review the assembly diagrams and instructions carefully. Ensure you are using the correct hardware for each step. If needed, seek assistance from another person.

WARRANTY AND SUPPORT

For warranty information, product support, or to report any issues, please refer to the warranty card included with your product or visit the official vidaXL website. Keep your purchase receipt as proof of purchase for any warranty claims.



© 2026 vidaXL. All rights reserved.