

Aechonow AEC-US01-CTT01146A105ZYX

Aechonow Flower Cat Tree Floor to Ceiling Instruction Manual

Brand: Aechonow | **Model:** AEC-US01-CTT01146A105ZYX

1. SAFETY INSTRUCTIONS

- Ensure all components are securely fastened before allowing pets to use the cat tree.
- Regularly inspect the cat tree for loose parts, wear, or damage. Tighten screws and replace worn components as needed.
- Place the cat tree on a flat, stable surface. For floor-to-ceiling models, ensure the tension rod is properly adjusted and secured against the ceiling to prevent tipping.
- Keep the cat tree indoors in a dry place to maintain material integrity.
- This product is designed for cats. Keep children from climbing or playing on the cat tree to prevent injury.

2. PACKAGE CONTENTS

Before assembly, verify that all parts listed in the instruction manual are present. Refer to the included parts diagram for identification.




Image: Detailed diagram of all cat tree components and their dimensions.

3. ASSEMBLY INSTRUCTIONS

Assembly is straightforward with clear instructions and labeled parts. Follow these steps for a stable and enjoyable cat tree.

Assembly Overview Video

Video: *Aechonow Floor To Ceiling Cat Tree For Large Cats - Assembly and Usage Overview.*

Detailed Assembly Steps

1. **Base Assembly:** Attach the shortest posts to the main base platform using the provided

screws. Ensure they are tightened securely.

2. **Cat Condo Installation:** Secure the cat condo unit to the base structure. Use the appropriate screws to fasten it firmly.
3. **Platform and Hammock Attachment:** Continue building upwards, attaching the various platforms and hammocks. Pay attention to the orientation of each piece as indicated in the manual.
4. **Upper Posts and Top Platform:** Install the longer posts and the top platform. These will form the upper levels of the cat tree.
5. **Ceiling Tension Rod Adjustment:** For floor-to-ceiling stability, insert the adjustable tension rod into the top post. Rotate the rod to extend it until it firmly presses against the ceiling. Secure the lower nut to lock the position, then rotate the upper nut to keep the cat tree stable.
6. **Scratching Ramp:** Attach the scratching ramp to the designated lower platform.
7. **Interactive Elements:** Hang any included plush balls or toys from the platforms as desired.

Ceiling Height Adjustment Guide



Image: Visual guide for selecting appropriate pole combinations based on ceiling height (220-275cm).

4. PRODUCT FEATURES AND USAGE

The Aecheonow Flower Cat Tree is designed to provide a multi-level activity center for your cats, promoting exercise, rest, and play.

- **Spacious Design:** Features 2 large perches, 2 large hammocks, and 1 large condo, suitable for large cats or multiple cats.
- **Multiple Jumping Routes:** Various platforms and levels encourage active play and climbing.
- **Scratching Posts:** Equipped with durable sisal-wrapped posts for healthy claw maintenance.
- **Interactive Elements:** Plush balls are included to keep your cats engaged and entertained.

Floor to Ceiling Design

Maximize the use of vertical space



Image: An assembled Aechonow Flower Cat Tree with cats on different levels.

Ample Rest Space

Multiple spots for carefree cat naps




Image: Close-up of cats resting in the hammocks and condo.

Cat Tree in Use Video

Video: A cat demonstrating the use of the Aechonow Floor to Ceiling Cat Tree, including climbing and playing with attached toys.

5. CARE AND MAINTENANCE

- **Cleaning:** Spot clean or hand wash with mild detergent. Do not machine wash.
- **Location:** Keep indoors in a dry place. Avoid exposure to direct sunlight or excessive moisture.
- **Inspection:** Regularly check all screws and connections for tightness. Re-tighten as necessary to maintain stability.

6. TROUBLESHOOTING

- **Instability/Wobbling:** Ensure the top telescopic rod is fully extended and securely tightened against the ceiling. Check all connecting screws throughout the structure and tighten any loose ones.
- **Missing Parts/Damaged Components:** If any parts are missing or damaged upon arrival, please contact customer support immediately for assistance.
- **Cat Disinterest:** Encourage your cat to use the tree by placing treats or favorite toys on different levels. Catnip can also be used to attract them.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Item Weight	40 Pounds
Item Dimensions (LxWxH)	19 x 15.8 x 108 inches (Adjustable height: 86"-108")
Material	Faux Fur
Color	Flower (Pink/Green)
Model Name	Cat Tree
Item Model Number	AEC-US01-CTT01146A105ZYX
Mounting Type	Floor Mount (with ceiling tension)
Specific Uses for Product	Climbing, Jumping, Running, Scratching

8. WARRANTY AND SUPPORT

This Aecheonow Cat Tree comes with a **2 Year Manufacturer Warranty**.

For warranty claims, technical support, or any questions regarding your product, please contact Aecheonow customer service through your retailer's support channels or visit the official Aecheonow website for contact information.

