

[Manuals.plus](#) /

› [Snughome](#) /

› Snughome 5-Tier Shoe Rack with 2 Drawers Instruction Manual (Model 792483811067)

Snughome 792483811067

Snughome 5-Tier Shoe Rack with 2 Drawers Instruction Manual

Model: 792483811067

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use of this product. Keep this manual for future reference.

- Do not exceed the weight limits for each shelf or drawer.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten as necessary.
- Place the shoe rack on a flat, stable surface to prevent tipping.
- Keep small parts away from children during assembly.
- Avoid climbing or standing on the unit.
- Do not expose the product to excessive moisture or direct sunlight for prolonged periods.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- Wooden Top Panel
- Metal Mesh Shelves (5 tiers)
- Fabric Drawers (2 units)
- Drawer Knobs
- Adjustable Feet
- Assembly Hardware (screws, wrench, etc.)



Image: The Snughome 5-Tier Shoe Rack with 2 Drawers, showcasing its rustic brown wooden top, black metal frame, and mesh shelves, filled with various types of shoes and accessories.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically takes 15-30 minutes. A Phillips head screwdriver (not included) may be required in addition to the provided tools.

- 1. Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the package contents list to ensure everything is present.
- 2. Assemble the Frame:** Connect the vertical metal frame pieces using the provided screws and wrench. Ensure all connections are finger-tight initially.
- 3. Install Shelves:** Slide the metal mesh shelves into the designated slots on the frame. The shelves should fit snugly. For the boot area, ensure the taller section is correctly positioned.
- 4. Attach Wooden Top:** Secure the wooden top panel to the top of the metal frame using the appropriate screws.

5. **Insert Drawers:** Assemble the fabric drawers if necessary (usually involves inserting a bottom panel). Attach the drawer knobs. Slide the assembled drawers into their compartments under the wooden top.
6. **Tighten All Screws:** Once all components are in place, fully tighten all screws to ensure the unit is stable and secure.
7. **Adjust Feet:** Adjust the leveling feet at the bottom of the rack to ensure stability on uneven floors.

Product Size



Image: Detailed product dimensions of the 5-tier shoe rack, showing height, width, and depth, as well as individual shelf heights and drawer dimensions.



Image: Close-up view of the sturdy metal frame construction, highlighting the secure screw connections.




Image: Close-up view of the rustic brown wooden top panel, showing its texture and finish.



Image: Close-up view of a metal mesh shelf, demonstrating its design for shoe ventilation and support.



Image: Close-up view of the adjustable leveling feet at the base of the shoe rack.

OPERATING INSTRUCTIONS

This Snughome shoe rack is designed for efficient storage of various footwear and small accessories.

- **Shoe Storage:** Utilize the five metal mesh tiers to store shoes. The design accommodates sneakers, heels, and flats.
- **Boot Area:** The dedicated taller section on the lower left is specifically designed for storing boots upright, preventing creases and maintaining their shape.
- **Drawer Use:** The two fabric drawers located under the wooden top are ideal for storing smaller items such as socks, shoe care products, keys, or other entryway essentials.
- **Top Surface:** The sturdy wooden top can be used to place decorative items, bags, or other frequently accessed items.



Image: The shoe rack positioned in an entryway, demonstrating its capacity for various shoe types and the use of the top surface for decor and a basket.

Spacious Fabric Storage Drawer



Image: A close-up view of the two fabric drawers, one open to show stored headphones and a book, highlighting their utility for small accessories.



MAINTENANCE

Proper care will ensure the longevity and appearance of your Snughome shoe rack.

- **Cleaning:** Wipe the metal frame and wooden top with a dry, soft cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth.
- **Avoid Moisture:** Do not use harsh chemicals or abrasive cleaners. Avoid excessive moisture, especially on the wooden top, to prevent damage.
- **Drawer Care:** The fabric drawers can be spot cleaned with a mild detergent and air-dried. Do not machine wash.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Rack is wobbly or unstable.	Screws are loose; uneven floor.	Ensure all screws are fully tightened. Adjust the leveling feet at the bottom of the rack.
Drawers do not slide smoothly.	Drawer not assembled correctly; obstruction.	Check drawer assembly. Ensure nothing is obstructing the drawer's path.
Missing parts during assembly.	Packaging error.	Contact Snughome customer support with your purchase details.
Shoes fall off shelves easily.	Overloaded shelf; incorrect placement.	Distribute weight evenly. Ensure shoes are placed fully on the mesh surface.

SPECIFICATIONS

Feature	Detail
Model Number	792483811067
Dimensions (D x W x H)	11.81" x 29.92" x 37.08"
Material	Engineered Wood, Metal
Number of Tiers	5
Number of Drawers	2 (Fabric)
Mounting Type	Floor Mount (Freestanding)
Color	Rustic Brown
Assembly Required	Yes

WARRANTY AND SUPPORT

Snughome products are designed for quality and durability. For any questions regarding assembly, missing parts, or product performance, please contact Snughome customer support. Please retain your proof of purchase for any warranty claims. Specific warranty details may vary and are typically provided

with the product packaging or available on the manufacturer's official website.
For assistance, visit the [Snughome Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question