

Redragon K673 PRO

Redragon K673 MAX 75% Wireless Gasket RGB Gaming Keyboard User Manual

Model: K673 PRO

Brand: Redragon

INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for setting up, operating, and customizing your Redragon K673 MAX 75% Wireless Gasket RGB Gaming Keyboard. Please read thoroughly to ensure optimal performance and longevity of your device.

Key Features:

- **Gasket-Mounted Design:** The body structure utilizes precision-locked covers with gaskets for noise reduction and flexibility, providing a crisp, clean, and softer typing feel.
- **Tri-Mode Connection:** Offers versatile connectivity via USB-C wired, Bluetooth (BT 3.0/5.0), and 2.4GHz wireless modes.
- **5-Layer Noise Dampening:** Equipped with 3.5mm PO foam, IXPE switch foam, PET sound pad, bottom socket foam, and a silicone bottom pad with a silicone gasket to significantly reduce hollow noise and create ultra-clean typing acoustics.
- **Custom Mint Mambo Switches:** Thick-lubed linear switches combined with a gasket form factor for cushioned, rich linear travel and silky, creamy typing feedback.
- **Hot-Swap Sockets:** Upgraded sockets are compatible with nearly all 3-pin and 5-pin switches.
- **One-Knob Control:** Convenient access knob for backlight brightness, media control (volume, play/pause, switch), and GIF display.
- **81-Key Layout:** Innovative 75% layout retains essential function keys while offering a compact size for increased mouse movement space.

PACKAGE CONTENTS

- Redragon K673 MAX 75% Wireless Gasket RGB Gaming Keyboard
- USB-C Cable
- Keycap/Switch Puller
- Spare Switches



Image: Redragon K673 MAX keyboard with included accessories, highlighting its 3-mode tech, 75% gasket design, 5-layer sound kit, and 4000mAh battery.

SETUP

Connectivity Modes:

The Redragon K673 MAX keyboard supports three connection modes:

1. **USB-C Wired:** Connect the provided USB-C cable to the keyboard and your computer. The keyboard will automatically be recognized.
2. **2.4GHz Wireless:** Locate the 2.4G USB receiver (dongle) stored on the right side of the keyboard. Plug it into an available USB port on your computer. Slide the switch on the left side of the keyboard to '2.4G'. The keyboard should connect automatically.
3. **Bluetooth (BT 3.0/5.0):** Slide the switch on the left side of the keyboard to 'BT'. On your device (computer, tablet, smartphone), enable Bluetooth and search for available devices. Select 'BT3.0 Keyboard' or 'BT5.0 KB' to pair.



Image: The keyboard features two-level adjustable feet for ergonomic typing and a user-friendly magnetic storage slot for the 2.4GHz wireless dongle on the side.

Adjustable Feet:

The keyboard features two-level adjustable feet on the underside. Flip them out to set your preferred typing angle for enhanced comfort.

Initial Charging:

For first-time use, it is recommended to fully charge the keyboard using the provided USB-C cable. The LED indicator will show charging status (Red for under 20%, Blue for under 60%, Cyan for under 80%, Green for 80%+).

Video: A review showcasing the unboxing, features, and connectivity options of the Redragon K673 PRO keyboard.

OPERATING INSTRUCTIONS

One-Knob Control:

The multi-function knob located on the top-right corner provides easy control over various settings:

- **Volume Control:** Rotate the knob to adjust system volume. Short press to mute/unmute.
- **Backlight Brightness:** Long press the knob for 3 seconds to switch to brightness control. Rotate to adjust backlight brightness. Short press again to switch back to volume control.
- **Media Control:** The knob can also control media playback (play/pause, next/previous track) depending on the active function.




Image: The easy-access knob on the Redragon K673 MAX keyboard allows for quick adjustment of backlight brightness and media volume. Long press to switch between functions.

RGB Lighting Control:

Customize your keyboard's RGB lighting effects:

- **Change Backlight Mode:** Press FN + INS to cycle through 20 available backlight patterns.
- **Change Backlight Color:** Press FN + ENTER to change the backlight color.
- **Adjust Speed:** Press FN + Left Arrow to slow down the backlight rotating speed, and FN + Right Arrow to speed it up.
- **Adjust Brightness:** Press FN + Down Arrow to decrease backlight brightness, and FN + Up Arrow to increase it.
- **Turn On/Off Backlight:** Press FN + Spacebar to toggle the backlight on/off.



Image: Key combinations for dynamic and vivid RGB lighting control, including adjusting brightness, speed, and backlight effects.

CUSTOMIZATION

Hot-Swappable Switches:

The Redragon K673 MAX features advanced hot-swap sockets, allowing you to easily change switches without soldering. This provides flexibility to customize your typing experience with different switch types (3-pin or 5-pin compatible).

ADVANCE HOT-SWAP SOCKETS

PLUSH & SOLID, CUSTOM Mambo SWITCH



Image: Advanced hot-swap sockets on the Redragon K673 MAX keyboard, featuring custom Mint Mambo switches for plush and solid typing feedback.

5-Layer Noise Dampening:

Experience a significantly quieter and more satisfying typing sound thanks to the keyboard's 5-layer noise dampening system. This includes multiple layers of foam and silicone pads strategically placed within the keyboard's gasket-mounted structure.

GASKET DESIGNED+NOISE DAMPENINGx5

NEXT-LEVEL EXPERIENCE AWAITS




Image: Detailed diagram illustrating the 5-layer noise dampening system and gasket design of the Redragon K673 MAX keyboard for a next-level typing experience.

MAINTENANCE

To ensure the longevity and optimal performance of your Redragon K673 MAX keyboard, regular maintenance is recommended:

- **Cleaning:** Use a soft, dry cloth to wipe down the keycaps and keyboard body. For deeper cleaning, remove keycaps using the provided puller and use compressed air to clear debris from beneath the switches.
- **Switch Care:** If a switch becomes faulty, use the provided switch puller to carefully remove and replace it with a spare switch.
- **Storage:** Store the keyboard in a dry, cool environment away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your Redragon K673 MAX keyboard, refer to the following common solutions:

- **Connectivity Issues:** Ensure the keyboard is switched to the correct mode (2.4G, BT, or wired). For

wireless modes, check battery level and ensure the receiver/Bluetooth is properly paired. Try reconnecting or restarting your device.

- **Backlight Not Working/Incorrect:** Check the brightness settings using FN + Up/Down Arrow or the knob. Cycle through RGB effects using FN + INS. Ensure the backlight is not turned off via FN + Spacebar.
- **Keys Not Responding:** Ensure the keyboard is powered on and connected. If using wireless, check battery levels. Try connecting via USB-C cable to rule out wireless issues.
- **Factory Reset:** If issues persist, you can perform a factory reset by pressing and holding FN + ESC for 3 seconds.

PRODUCT SPECIFICATIONS

Brand	Redragon
Model Number	K673 PRO
Connectivity Technology	2.4Ghz, BT, USB-C
Keyboard Description	81 Keys Wireless Gasket Gaming Keyboard
Special Feature	Hot-Swappable
Color	Moonrise Violet
Keyboard Backlighting	RGB
Material	Polybutylene Terephthalate (PBT)
Item Weight	2.57 pounds
Power Source	USB Powered
Batteries	1 Lithium Polymer batteries required (included)

WARRANTY AND SUPPORT

Redragon products typically come with a manufacturer's warranty. For specific warranty details, including coverage period and terms, please refer to the warranty card included in your product packaging or visit the official Redragon website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Redragon customer service through their official website or the contact information provided in your product documentation.