



[Manuals.plus](#) /

> [wobuzhi](#) /

> wobuzhi Space Heater User Manual

wobuzhi JS-2A

wobuzhi Space Heater User Manual

Model: JS-2A

INTRODUCTION

Thank you for purchasing the wobuzhi Space Heater, Model JS-2A. This portable electric heater is designed to provide efficient and comfortable warmth for indoor spaces. It features advanced PTC ceramic heating technology, a built-in humidifier, 70° oscillation, and multiple safety features including overheat and tip-over protection. Please read this manual thoroughly before operation to ensure safe and optimal performance.



Image: The wobuzhi Space Heater, Model JS-2A, showcasing its sleek design, digital display, and the direction of warm air flow. A remote control is also visible, indicating wireless operation capabilities.

SAFETY INFORMATION

Your safety is paramount. Please adhere to the following safety guidelines:

- Always plug the heater directly into a 120V wall outlet. Do not use extension cords or power strips.
- Ensure the heater is placed on a stable, level surface to prevent accidental tipping.
- Keep flammable materials such as furniture, curtains, and bedding at least 3 feet (0.9 meters) away from the front, sides, and rear of the heater.
- Do not operate the heater in wet or damp locations, such as bathrooms or laundry areas.
- Do not insert any objects into the ventilation or exhaust openings as this may cause electric shock or damage the heater.
- Unplug the heater when not in use or before cleaning.
- Supervise children and pets when the heater is in operation.

Built-in Safety Features:

- **Overheat Protection:** The heater is equipped with an internal safety device that automatically shuts off the unit if it overheats. This prevents potential fire hazards.
- **Tip-Over Protection:** An integrated switch automatically turns off the heater if it is accidentally tipped over (up to 30 degrees). This feature enhances safety, especially in households with children or pets.
- **V-0 Flame Retardant Material:** Constructed with V-0 flame retardant materials for added fire safety.
- **Enhanced Safety Plug:** Features a robust safety plug designed for secure and reliable power connection.



Tip-Over Protection

Turns off when tilted up to 30°



Over-Heat Protection



Image: Visual representation of the heater's safety mechanisms, including automatic shut-off when tipped over and internal overheat protection.

SETUP

1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging materials for future storage or transport.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is adequate clearance around the heater (at least 3 feet from walls, furniture, and other objects).
3. **Power Connection:** Plug the power cord directly into a standard 120V AC wall outlet. Do not use extension cords, power strips, or surge protectors.
4. **Humidifier Water Tank (Optional):** If you intend to use the humidification feature, locate the water tank. Fill the tank with clean, distilled water up to the MAX water level indicator. Ensure the tank is securely closed and properly seated in the heater.

OPERATING INSTRUCTIONS

The wobuzhi Space Heater can be operated using the touch control panel on the unit or the included remote control.



Image: Detailed view of the heater's control panel, showing icons for Timer, Spray Mode, Power Indicator, Oscillation, Mode Settings, Decrease, Flame Effect, and Increase buttons.

Control Panel and Remote Functions:

- **Power Button (⏻):** Press to turn the heater ON or OFF.
- **Mode Settings Button (M):** Cycle through heating modes:
 - **High Heat (1500W):** Provides maximum heating power for rapid warmth.
 - **Low Heat (900W):** Offers a lower heat output for sustained warmth and energy saving.
 - **Fan-Only:** Circulates air without heat, useful for warmer days.
 - **ECO Mode:** Automatically adjusts power (between 900W and 1500W) based on the room's temperature to maintain the set temperature and optimize energy consumption.

- **Temperature Adjustment (+ / -):** Adjust the desired temperature setting. The display will show the set temperature.
- **Oscillation Button (☺):** Activates or deactivates the 70° wide-angle oscillation feature, distributing warmth evenly across the room.
- **Timer Button (L):** Set an automatic shut-off timer for up to 12 hours. Press repeatedly to cycle through timer intervals.
- **Spray Mode Button (☂):** Activates or deactivates the humidification function. Ensure the water tank is filled.
- **Flame Effect Button (🔥):** Toggles the 3D simulated flame effect ON or OFF.

Quick Start Guide:

1. Plug the heater into a 120V wall outlet.
2. Press the Power button (⏻) to turn on the heater.
3. Use the Mode Settings button (M) to select your desired heating mode (High, Low, Fan-Only, ECO).
4. Adjust the temperature using the + and - buttons.
5. Press the Oscillation button (☺) for wider heat distribution.
6. Optionally, activate the Spray Mode (☂) for humidification and the Flame Effect (🔥) for visual ambiance.

Rapid Warmth In Seconds

2S XFast heating without waiting



Image: The heater demonstrating its rapid heating capability, indicating warmth within seconds.

Energy-Efficiency ECO Mode



Image: A graph illustrating the energy efficiency of the ECO mode, showing how it reduces power consumption while maintaining comfort.

Sleep Comfortably

45db quiet operation for an undisturbed sleep



Image: The heater in a bedroom setting, highlighting its quiet operation (45dB) for undisturbed sleep.

MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your heater.

- **Cleaning the Exterior:** Before cleaning, always unplug the heater and allow it to cool completely. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Dust Removal:** Use a vacuum cleaner with a brush attachment to gently remove dust from the air intake and exhaust grilles.
- **Humidifier Tank Cleaning:** If using the humidifier function, regularly clean the water tank to prevent mineral buildup and mold growth. Empty any remaining water after each use. For thorough cleaning, use a mild descaling solution or a mixture of white vinegar and water. Rinse thoroughly before refilling.
- **Storage:** When not in use, store the heater in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

TROUBLESHOOTING

If you encounter issues with your wobuzhi Space Heater, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; power outlet malfunction; tip-over switch activated; overheat protection activated.	Ensure the heater is securely plugged into a working 120V outlet. Check if the heater was tipped over; place it upright. Unplug the heater for 10-15 minutes to reset the overheat protection, then plug it back in.
No heat or insufficient heat.	Incorrect mode selected; temperature setting too low; room too large for heating coverage.	Ensure High Heat or Low Heat mode is selected. Increase the temperature setting. Note that the heater is designed for rooms up to 200 sq ft.
Humidifier function not working or leaking.	Water tank empty or improperly seated; water level exceeds MAX line; internal malfunction.	Ensure the water tank is filled with clean water and correctly installed. Do not overfill the tank; ensure water level is below the MAX line. If leaking persists, discontinue use of the humidifier function and contact customer support.
Unusual noise during operation.	Dust buildup in fan; internal component issue.	Unplug the heater and clean the air grilles to remove dust. If the noise persists, discontinue use and contact customer support.
Remote control not working.	Dead batteries; obstruction between remote and heater.	Replace the batteries in the remote control. Ensure there are no obstacles blocking the signal path.

SPECIFICATIONS

Feature	Detail
Brand	wobuzhi
Model Number	JS-2A
Power Output	1500W (High Heat), 900W (Low Heat)
Voltage	120 Volts
Heating Technology	PTC Ceramic
Oscillation Angle	70°
Timer	Up to 12 hours
Special Features	3 Heating Modes (High, Low, Fan-Only), ECO Mode, Overheating & Tip-Over Protection, Humidifier (Spray Mode), 3D Flame Effect, Remote Control
Color	Silver Gray
Form Factor	Tower

Feature	Detail
Indoor/Outdoor Usage	Indoor
Product Dimensions	7.95"D x 6.61"W x 16.14"H
Item Weight	5.17 pounds
Heating Coverage	Up to 200 square feet

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the purchase documentation or contact the seller directly. wobuzhi offers protection plans for extended coverage, which can be purchased separately.

For technical assistance or inquiries, please visit the official wobuzhi store on Amazon or contact their customer service as provided at the point of purchase.

Online Store: [wobuzhi Amazon Store](#)

© 2024 wobuzhi. All rights reserved.
This manual is subject to change without notice.