

TecTake 405123-1

User Manual

TecTake Hanging Garden Chair with UV-Protected Sun Canopy

1. INTRODUCTION

This manual provides essential information for the safe and effective assembly, operation, and maintenance of your TecTake Hanging Garden Chair. Please read this manual thoroughly before use and retain it for future reference.

The TecTake Hanging Garden Chair is designed for outdoor and indoor relaxation, featuring an ergonomically shaped lying surface, a UV-protected sun canopy, and a sturdy steel frame. It offers a comfortable and stable seating solution for gardens, patios, and balconies.



Image: The TecTake Hanging Garden Chair in grey, showcasing its ergonomic design, sun canopy, and integrated side pocket.

2. SAFETY INFORMATION

Attention: Please note the maximum load capacity of **160 kg**. Exceeding this limit may result in damage to the product or personal injury.

Use the hanging lounger only on flat and stable surfaces to prevent tipping. Ensure the ground is level and firm before assembly and use.

Read and follow the assembly instructions carefully. Incorrect assembly can compromise the stability and safety of the chair.

In case of strong wind or storm, remove the sun canopy and additionally secure or store the hanging lounger to prevent damage or injury.

For outdoor use, it is recommended to use a protective cover to shield the product from adverse weather conditions when not in use, prolonging its lifespan.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Hanging Lounger (main frame and seating components)
- Side Pocket
- Sun Canopy
- Assembly Materials (screws, bolts, tools if included)
- Assembly Instructions (this manual)

tectake
garden

Product information

MEASUREMENTS

Dimensions

132 x 195 x 197 cm

Lying surface

71 x 208 cm

Sun canopy

132 x 154 cm

Pocket

37 x 32 cm

Lying height (without load)

63 cm

TECHNICAL DATA

Load capacity 160 kg

Weight 31.5 kg

Material powder-coated steel,
polyester

CONTENTS

Hanging lounger

Side pocket

Assembly materials

Assembly instructions

Measurements may vary



Image: A detailed diagram illustrating the dimensions and key components included in the package, such as the hanging lounger, side pocket, and sun canopy.

4. ASSEMBLY INSTRUCTIONS

Assembly of the TecTake Hanging Garden Chair requires careful attention to detail. It is recommended that **two people** undertake the assembly process to ensure stability and ease of construction.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat

surface. Identify each component using the provided parts list.

2. **Assemble Base Frame:** Connect the base frame components according to the diagrams in the assembly instructions. Ensure all connections are secure before proceeding.
3. **Attach Upright Support:** Secure the main upright support to the assembled base frame. This is a critical step for the chair's stability.
4. **Mount Hanging Mechanism:** Attach the hanging mechanism to the top of the upright support. Ensure all bolts are tightened securely.
5. **Assemble Lounger Seat:** Assemble the padded lounger seat and attach the headrest and armrests.
6. **Hang Lounger Seat:** Carefully lift and attach the assembled lounger seat to the hanging mechanism. Double-check all connections.
7. **Install Sun Canopy:** Attach the sun canopy to the designated points on the frame.
8. **Attach Side Pocket:** Secure the side pocket to the frame as shown in the instructions.
9. **Final Check:** Before first use, inspect all bolts, screws, and connections to ensure they are fully tightened and secure. Verify the chair is stable and does not wobble.

Tip: Familiarize yourself with all part numbers and diagrams before starting assembly to streamline the process.



Image: An illustration highlighting key features such as strong suspension for safety, padded surfaces for comfort, and the large sun canopy for UV protection.


5. OPERATION

The TecTake Hanging Garden Chair is designed for comfortable relaxation and gentle swinging motion.

- **Using the Lounger:** Gently sit on the padded surface. The ergonomic design provides optimal support for your body.
- **Swinging Motion:** The chair allows for a safe and gentle swinging motion. Avoid excessive force or sudden movements.
- **Sun Canopy Adjustment:** The large sun canopy provides shade and UV protection. It can be adjusted or removed if desired, depending on sun exposure and weather conditions.
- **Side Pocket:** Utilize the practical side pocket with its multiple compartments to store small items such as phones, books, or drinks, keeping them within easy reach.



THOUGHTFUL
Design



Soft
padding



Side pocket
with 3 sections

Image: A close-up view demonstrating the soft padding of the lounger and the convenient multi-compartment side pocket.

6. MAINTENANCE

Proper maintenance will ensure the longevity and continued enjoyment of your hanging garden chair.

- **Cleaning:** The soft cushioning is water-repellent and washable. For general cleaning, wipe surfaces with a damp cloth and mild soap. For deeper cleaning, follow specific care instructions for the fabric if provided.
- **Frame Care:** The powder-coated steel frame is designed for durability. Clean the frame with a damp cloth. Avoid abrasive cleaners that could damage the coating.
- **Weather Protection:** To protect against bad weather and prolong the product's life, especially when used outdoors, it is highly recommended to use a protective cover when the chair is not in use.
- **Storage:** During prolonged periods of non-use or in harsh weather conditions (e.g., winter), store the chair in a dry, sheltered location.
- **Inspection:** Periodically inspect all bolts, screws, and connections for tightness. Re-tighten if necessary to maintain stability and safety.

WIND & WEATHER resistant





Image: Visual representation of the chair's wind and weather resistance, highlighting its water-repellent fabric and robust powder-coated steel frame.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Chair feels unstable or wobbly.	Loose connections; uneven surface.	Ensure all bolts and screws are fully tightened. Move the chair to a flat, level surface.
Missing parts during assembly.	Packaging error; parts misplaced.	Double-check all packaging materials. Contact TecTake customer support with your product model and details of missing parts.
Difficulty assembling.	Instructions unclear; complex steps.	Review the assembly instructions carefully. Ensure you have all necessary tools. Consider having a second person assist with assembly.
Rust appearing on frame (outdoor use).	Prolonged exposure to moisture without protection.	While the frame is powder-coated, prolonged exposure to harsh weather can cause wear. Use a protective cover when not in use, especially in rainy or humid conditions. Clean and dry the frame regularly.

8. SPECIFICATIONS






Feature	Detail
Brand	TecTake
Model Number	405123-1
Colour	Grey
Product Dimensions (L x W x H)	195 x 132 x 197 cm
Item Weight	31.6 kg
Load Capacity	160 kg
Material	Powder-coated steel, polyester
Special Features	Side Pocket, Armrests, Cushion Availability, UV-Protected Sun Canopy

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact TecTake customer service directly. Refer to your purchase documentation for specific warranty terms and contact details. You can often find support contact information on the manufacturer's official website or through the retailer where the product was purchased.

Online Support: [Visit the TecTake Store on Amazon](#)

Related Documents - 405123-1

	<p>TecTake Rattan Garden Furniture Assembly Instructions</p> <p>Comprehensive assembly instructions for TecTake rattan garden furniture sets, including a detailed parts list and step-by-step visual guidance. Model numbers: 403696, 403697, 403880, 403881.</p>
	<p>tectake Gazebo Instruction Manual - Assembly Guide</p> <p>Comprehensive instruction manual for assembling and maintaining your tectake gazebo. Includes parts list, step-by-step assembly, location advice, care instructions, and contact information.</p>
	<p>tectake Gazebo Instruction Manual - Assembly and Care Guide</p> <p>Comprehensive instruction manual for the tectake gazebo (models 404821, 404823, 404822, 404875), covering parts list, assembly steps, location selection, cleaning, maintenance, and storage. Includes safety warnings for outdoor use.</p>
	<p>TecTake 402756 Home Gym Assembly and Exercise Guide</p> <p>Instruction manual for the TecTake 402756 home gym, covering assembly, safety precautions, and exercise guidance. Includes preparation tips and warm-up/cool-down routines.</p>
	<p>TecTake Stand-Up Paddleboard Instruction Manual</p> <p>Comprehensive instruction manual for the TecTake Stand-Up Paddleboard, covering assembly, inflation, deflation, and storage. Includes safety warnings and usage guidelines.</p>



[TecTake 400777 Semi-Automatic Washing Machine User Manual and Instructions](#)

This user manual provides comprehensive instructions for the TecTake 400777 semi-automatic washing machine, covering installation, operation, safety guidelines, and maintenance. Learn how to effectively wash and spin your clothes with this efficient appliance.