

ZABBOW LG-008

ZABBOW Manual Food Processor (Model LG-008) Instruction Manual

Your guide to efficient food preparation.

1. INTRODUCTION

Thank you for choosing the ZABBOW Manual Food Processor, Model LG-008. This 8-cup hand-powered crank chopper and mincer blender is designed to simplify your food preparation tasks. It is ideal for chopping and mixing various ingredients such as vegetables, meat, fruits, onions, garlic, and more. Its manual operation ensures quiet use and no electricity is required, making it a versatile tool for any kitchen.

2. PRODUCT COMPONENTS

The ZABBOW Manual Food Processor consists of several key components:

- **Controller/Handle:** The crank mechanism for manual operation.
- **Lid:** Secures the contents during operation and houses the egg white separator.
- **Cutting Board (Top part of the lid):** The upper section of the lid assembly.
- **Three-leaf Rotary Knife:** Made from 420 stainless steel for efficient chopping.
- **Mixed Maple Leaf (Stirring Blades):** An accessory for mixing ingredients.
- **Transparent Container:** An 8-cup (1.5L) capacity bowl with an anti-skid base.
- **Non-slip Gasket:** Located at the base of the container for stability.

ZABBOW

2 sets of stainless steel blades




Figure 1: Product Structure Decomposition

3. SETUP

1. Ensure all components are clean and dry before assembly.
2. Place the transparent container on a stable, flat surface. The non-slip gasket at the base will help secure it.
3. Carefully place the three-leaf rotary knife onto the central pin inside the container. Ensure it is seated properly.
4. Add your desired ingredients into the container. Do not overfill.
5. Place the lid onto the container, aligning the central shaft of the knife with the opening in the lid.
6. Attach the controller/handle to the top of the lid, ensuring it engages with the knife shaft.



Figure 2: Assembled Food Processor in Use

4. OPERATING INSTRUCTIONS

4.1 Chopping Ingredients

1. With the three-leaf rotary knife installed and the lid secured, hold the lid firmly with one hand.
2. Rotate the crank handle with the other hand. The blades will spin, chopping the ingredients.
3. Continue rotating until the desired consistency is achieved. For coarser chops, use fewer rotations; for finer chops, use more rotations.
4. Always ensure the lid is securely in place before operating.

Good kitchen helper great time savers



Figure 3: Three-leaf Rotary Knife and Example Ingredients

4.2 Mixing Ingredients

1. Remove the three-leaf rotary knife.
2. Install the mixed maple leaf (stirring blades) onto the central pin.
3. Add ingredients suitable for mixing, such as eggs for scrambling or light batters.
4. Secure the lid and attach the handle.
5. Rotate the crank handle to mix the ingredients.



Figure 4: Before and After Mixing Examples

4.3 Egg White Separation

The lid features a built-in egg white separator. Crack an egg directly into the designated area on the lid, and the egg white will separate from the yolk, flowing into the container below.

4.4 Video Demonstrations

Your browser does not support the video tag.

Video 1: Demonstration of ZABBOW Manual Food Processor chopping various ingredients like meat, garlic, and celery, and mixing eggs.

Your browser does not support the video tag.

Video 2: Unboxing and demonstration of the ZABBOW Manual Food Processor, including chopping onions and using the egg white separator.

5. MAINTENANCE AND CLEANING

To ensure the longevity and hygiene of your ZABBOW Manual Food Processor, follow these cleaning instructions:

- All parts of the food chopper are detachable for easy cleaning.
- After each use, disassemble the unit.
- Rinse all parts with water. Use mild soap if necessary.
- **Product Care Instructions:** Hand Wash. Do not place in a dishwasher as this may damage components.
- Allow all parts to air dry completely before reassembling or storing.
- Exercise caution when handling the sharp stainless steel blades.

EASY TO CLEAN AND STORAGE



Figure 5: Easy Cleaning and Storage

6. TROUBLESHOOTING

If you encounter any issues with your ZABBOW Manual Food Processor, please refer to the following common solutions:

- **Blades not rotating smoothly:** Ensure the lid is properly aligned and securely fastened. Check for any food particles obstructing the blade's movement.
- **Ingredients not chopping evenly:** Ensure ingredients are cut into smaller, manageable pieces before placing them in the chopper. Do not overfill the container.
- **Unit sliding on countertop:** Verify that the non-slip gasket at the base is clean and dry. Place the unit on a clean, dry, and flat surface.

7. SPECIFICATIONS

Feature	Detail
Brand	ZABBOW
Model Name	Hand Crank Food Processor (LG-008)
Capacity	8 Cup (1.5L)
Product Dimensions	7.09"D x 7.09"W x 8.66"H
Blade Material	420 Stainless Steel
Power Source	Manual
Special Features	Built-in Grinder, Manual Operation, Safety Lock, Egg White Separator, Anti-skid Base
Product Care Instructions	Hand Wash

Product structure decomposition




Figure 6: Product Size and Example Uses

8. WARRANTY AND SUPPORT

ZABBOW is committed to ensuring your satisfaction. If you have any questions, concerns, or require assistance with your Manual Food Processor, please do not hesitate to contact our customer support. We aim to resolve any issues within 24 hours.

For further assistance, please visit the [ZABBOW Store on Amazon](#).