

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [PDP](#) /

› [PDP Phantom Air Dual-Mode Wireless Gaming Headset User Manual](#)

PDP 049-038-BK

PDP Phantom Air Dual-Mode Wireless Gaming Headset

User Manual

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your PDP Phantom Air Dual-Mode Wireless Gaming Headset. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

The PDP Phantom Air headset offers versatile connectivity with both 2.4GHz low-latency wireless and Bluetooth, designed for seamless audio across Xbox consoles, Windows 10/11 PCs, and other Bluetooth-enabled devices. It features 50mm drivers for immersive audio, a noise-cancelling flip-to-mute microphone, and a long-lasting rechargeable battery.



Image: Front view of the PDP Phantom Air Dual-Mode Wireless Gaming Headset, showcasing its black and green design with the microphone extended.

WHAT'S IN THE Box

Verify that all components are present in the packaging:

- PDP Phantom Air Gaming Headset
- USB Wireless Transmitter
- USB Charging Cable
- User Manual (this document)

IMMERSIVE AUDIO

Through 50mm Drivers



Image: Rear view of the PDP Phantom Air Gaming Headset packaging, displaying product features and contents.

PRODUCT OVERVIEW

Headset Controls and Features

Familiarize yourself with the various controls and features on your headset:

- **Power Button:** Located on the left earcup, used to power the headset on/off.
- **Volume Dial:** On the left earcup, adjusts the overall audio volume.
- **QuickSwitch Button:** Allows seamless switching between 2.4GHz wireless and Bluetooth modes.
- **Microphone:** Flexible boom mic with flip-to-mute functionality.
- **USB-C Charging Port:** For recharging the internal battery.
- **Status LED:** Indicates power, charging, and connection status.

PREMIUM DESIGN

With Zero Gravity Suspension Headband &
Premium Ear Cushion Fabric



Image: Side view of the PDP Phantom Air Gaming Headset, highlighting the location of the volume dial and QuickSwitch button on the earcup.

SETUP

1. Charging the Headset

Before first use, fully charge the headset. Connect the included USB charging cable to the USB-C port on the headset and the other end to a powered USB port (e.g., console, PC, or USB wall adapter). The Status LED will indicate charging status and turn off when fully charged.

A full charge provides up to 35 hours of listening time.



Image: A graphic emphasizing the headset's 35+ hour battery life, illustrating extended playtime.

2. Connecting to Your Device

2.1. 2.4GHz Wireless Connection (Xbox, PC)

1. Insert the USB Wireless Transmitter into an available USB port on your Xbox console or Windows 10/11 PC.
2. Power on the headset by pressing and holding the Power Button until the Status LED illuminates.
3. The headset and transmitter should automatically pair. The Status LED on the headset will turn solid when connected.

2.2. Bluetooth Connection (Mobile, PC, Other Devices)

1. Ensure the headset is powered on.
2. Press and hold the QuickSwitch Button until the Status LED blinks rapidly, indicating Bluetooth pairing mode.
3. On your device, navigate to Bluetooth settings and select "PDP Phantom Air" from the list of available devices.
4. Once paired, the Status LED on the headset will turn solid.

NOISE-CANCELING

Flip-To-Mute Mic



Image: A graphic illustrating the headset's dual-mode wireless capability, featuring icons for Bluetooth and 2.4GHz low-latency connectivity.

OPERATING INSTRUCTIONS

Power On/Off

To power on the headset, press and hold the Power Button for 2 seconds. To power off, press and hold the Power Button for 3 seconds.

Adjusting Volume

Rotate the Volume Dial on the left earcup up or down to increase or decrease the audio volume.

Microphone Usage (Flip-to-Mute)

The integrated microphone features flip-to-mute functionality. To mute the microphone, flip the microphone boom arm upwards. To unmute, flip the microphone boom arm downwards. The microphone also features A.I.-based noise cancellation for clear communication.




Image: A graphic demonstrating the flip-to-mute function of the headset's noise-cancelling microphone.

QuickSwitch Functionality

Press the QuickSwitch Button once to toggle between 2.4GHz wireless mode and Bluetooth mode. This allows for quick transitions between your console/PC and a mobile device without re-pairing.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures. The earcups can swivel to lay flat for convenient storage around your neck or in a bag.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
No audio from headset.	<p>Ensure the headset is powered on and charged.</p> <p>Check the volume dial on the headset and the device's volume settings.</p> <p>Verify the correct connection mode (2.4GHz or Bluetooth) is selected via the QuickSwitch button.</p> <p>For 2.4GHz, ensure the USB transmitter is securely plugged in and recognized by the device.</p> <p>For Bluetooth, ensure the headset is paired and connected in your device's Bluetooth settings.</p>
Microphone not working.	<p>Ensure the microphone boom arm is flipped down (unmuted).</p> <p>Check the microphone input settings on your console or PC.</p> <p>Ensure the headset is the default communication device.</p>
Headset not pairing.	<p>Ensure the headset is in pairing mode (blinking LED for Bluetooth).</p> <p>Move the headset closer to the device/transmitter.</p> <p>Try restarting both the headset and the device.</p> <p>Clear previous Bluetooth pairings on your device and try again.</p>

SPECIFICATIONS

Feature	Detail
Model Number	049-038-BK
Connectivity	2.4GHz Wireless, Bluetooth
Audio Drivers	50mm
Battery Life	Up to 35 hours
Microphone	A.I.-Based Noise-Cancelling, Flip-to-Mute
Compatibility	Xbox Series X S, Xbox One, Windows 10/11, Bluetooth devices
Dimensions (L x W x H)	2.83 x 10.16 x 9.29 inches
Weight	15.8 ounces
UPC	0708056073916

OFFICIALLY LICENSED

By Xbox



Image: A graphic highlighting the headset's 50mm audio drivers, which provide immersive sound.

WARRANTY AND SUPPORT

For warranty information and technical support, please visit the official PDP website or contact their customer service. Keep your proof of purchase for warranty claims.

Manufacturer: PDP

Website: [Visit the PDP Store on Amazon](#)

© 2024 PDP. All rights reserved. PDP, Phantom Air, and their respective logos are trademarks and/or registered trademarks of Performance Designed Products LLC.

Xbox, Xbox Series X|S, Xbox One, Windows 10/11 are trademarks of the Microsoft group of companies.

	<p>Victrix Gambit Wireless Gaming Headset Quick Start Guide</p> <p>Get started quickly with the Victrix Gambit Wireless Stereo Gaming Headset for Xbox Series X S, Xbox One, and Windows 10. This guide covers setup, controls, charging, and Dolby Atmos activation.</p>
	<p>Phantom Air Wireless Headset Quick Start Guide</p> <p>This guide provides instructions for setting up and using the Phantom Air Wireless Headset, including charging, connecting to Xbox and PC via dongle, Bluetooth pairing, and troubleshooting common issues.</p>
	<p>PDP Wired Controller for Xbox Quick Start Guide and Warranty Information</p> <p>Get started with your PDP Wired Controller for Xbox. This guide provides quick setup instructions, details on volume and microphone control, and comprehensive limited warranty information.</p>
	<p>PDP Wired Controller for Xbox Quick Start Guide</p> <p>Get started quickly with your PDP Wired Controller for Xbox. This guide provides setup instructions, button functions, and warranty information.</p>
	<p>PDP Wired Controller for Xbox Quick Start Guide</p> <p>A quick start guide for the PDP Wired Controller for Xbox, covering initial setup, volume control, microphone muting, game/chat balance, and customization via the PDP Control Hub app. Includes warranty information in multiple languages.</p>
	<p>PDP Wired Controller for Xbox Quick Start Guide</p> <p>A quick start guide for the PDP Wired Controller for Xbox, detailing setup, volume control, microphone muting, chat balance, and customization options via the PDP Control Hub App.</p>