

## TODIMART S9

# TODIMART S9 Electric Scooter User Manual

## INTRODUCTION

**65km**  
Longue portée

**12-14 h**  
Charge rapide

**48V 20.8Ah**  
Batterie aux ions lithium


60km  
Nous

35km  
Autre

**UNE BATTERIE DE  
LITHIUM INTELLIGENT**

This manual provides essential information for the safe operation, maintenance, and troubleshooting of your TODIMART S9 Electric Scooter. Please read it thoroughly before your first ride to ensure optimal performance and safety.

The TODIMART S9 Electric Scooter is designed for adults, featuring a powerful 1000W brushless motor and a 48V 20.8Ah lithium battery, offering a range of 55-65 km. It is equipped with 10-inch tubeless all-terrain tires and an intelligent LCD display for real-time ride information.



**Image:** Illustration of the powerful 1000W brushless motor, providing rapid acceleration and efficient climbing capabilities.



**Image:** The TODIMART S9 features a dual suspension system, front and rear, for a smoother and more comfortable ride over varied terrain.

## WHAT'S IN THE BOX

Upon opening the package, verify that all the following items are included:

- TODIMART S9 Electric Scooter
- Charger
- Installation Tool Kit
- User Manual (this document)

If any items are missing or damaged, please contact customer support immediately.

## SETUP AND ASSEMBLY

Your TODIMART S9 Electric Scooter comes partially assembled. Follow these steps to complete the setup:

1. **Unboxing:** Carefully remove the scooter and all accessories from the packaging. Retain the packaging for future storage or service needs.
2. **Unfolding the Scooter:** Lift the handlebar stem until it locks into the upright position. Secure the locking mechanism.
3. **Handlebar Installation:** Attach the handlebars to the stem. Ensure they are securely fastened using the provided screws and tools. Refer to the detailed video for visual guidance.
4. **Rear Fender Installation:** Attach the rear fender to the scooter. Ensure all screws are tightened.
5. **Initial Charge:** Before your first ride, fully charge the scooter's battery. Connect the charger to the charging port and then to a power outlet. The charging indicator will show the charging status. A full charge typically takes 8 to 10 hours.

Your browser does not support the video tag.

**Video:** Unboxing and initial assembly of a similar electric scooter model. Please note that specific details may vary slightly for the TODIMART S9.

## OPERATING INSTRUCTIONS

### Power On/Off

To power on the scooter, press and hold the power button on the display for a few seconds. To power off, repeat the action.

### Intelligent LCD Display

The intelligent LCD display provides real-time information about your ride, including speed, speed mode, battery life, and lighting status. Use the controls near the display to navigate through different settings and modes.

# CONTRÔLE INTELLIGENT

## Compteur LED HD multifonctionnel



Image: Close-up of the TODIMART S9's intelligent LCD display, showing speed, battery level, and mode indicators.



Image: Digital LCD screen mounted on the handlebar, displaying speed and riding statistics. Includes controls for cruise control, turn signals, and power.

### Speed Modes

The scooter features multiple speed modes. You can switch between these modes using the controls on the handlebar to adjust your speed according to riding conditions and local regulations.

## Braking System

The TODIMART S9 is equipped with a dual braking system (front and rear). Apply both brakes gently and evenly to slow down or stop. Avoid sudden braking, especially at high speeds, to prevent loss of control.

## Lighting and Indicators

For enhanced safety, especially during night rides, the scooter includes LED headlights, taillights, and left/right turn indicators. The brake light automatically illuminates when braking. Ensure all lights are functional before riding.

## Folding and Portability

The scooter is designed for easy folding and portability. To fold, disengage the locking mechanism on the handlebar stem and fold it down towards the deck. Ensure it is securely latched for transport. The folded dimensions are approximately 116 x 62 x 54 cm, and it weighs 26.5 kg.



Image: Illustration of the TODIMART S9 electric scooter's folding mechanism, showing its compact size when folded for easy transport.

## MAINTENANCE

### Battery Care

- Charge the battery fully before first use.
- Avoid completely draining the battery. Recharge it regularly, even if not in use for extended periods.
- Store the scooter in a cool, dry place, away from direct sunlight and extreme temperatures.
- Use only the original charger provided with the scooter.



**Image:** Close-up of the TODIMART S9's 48V 20.8Ah lithium battery, highlighting its intelligent design for extended range.

## Tire Care

The scooter is equipped with 10-inch tubeless all-terrain tires. Regularly check tire pressure and inspect for any signs of wear or damage. Proper tire pressure ensures optimal performance, range, and safety.



**Image:** Detailed view of the TODIMART S9's 10-inch tubeless all-terrain tire, designed for durability and grip on various surfaces.

## General Cleaning

Clean the scooter regularly with a damp cloth. Avoid using high-pressure water jets or harsh chemicals, as these can damage electronic components.

## Brake Inspection

Periodically inspect the brake levers, cables, and discs for wear or damage. Ensure the brakes respond effectively. If you notice any issues, have them serviced by a qualified technician.

## TROUBLESHOOTING

This section addresses common issues you might encounter with your TODIMART S9 Electric Scooter. For problems not listed here, please contact customer support.

- **Scooter does not power on:** Ensure the battery is charged. Check all connections.
- **Reduced range:** This can be due to low tire pressure, riding uphill frequently, heavy loads, or cold weather. Ensure tires are properly inflated and consider riding in a lower speed mode.
- **Unusual noises:** Inspect wheels, brakes, and suspension for loose parts or obstructions. If noises persist, seek professional inspection.

- **Brakes not responding:** Check brake cable tension and disc condition. Do not ride the scooter if brakes are not fully functional.

## SPECIFICATIONS

Feature	Specification
Brand	TODIMART
Model Name	S9-1000w 48v 20.8ah(85km)
Color	Black
Age Range	Adult
Special Features	Digital display, Replaceable battery, Speedometer, Integrated speaker, Light, Wide platform, Puncture-proof tire, Dual charging port, Rechargeable, Cruise control, Dual braking system, Lightweight, Foldable, Anti-slip surface
Weight Limit	150 Kilograms
Product Dimensions (L x W x H)	120L x 62W x 116H centimeters
Number of Wheels	2
Wheel Material	Synthetic Rubber
Frame Material	Aluminum
Maximum Weight	150 Kilograms
Handlebar Type	Adjustable
Wheel Type	Pneumatic
Suspension Type	Double Suspension
Handle Type	Ergonomic
Brake Type	Rear braking, Front braking
Charging Time	10 hours
Maximum Distance	85 Kilometers
Item Weight	26.5 Kilograms
Handle Height	120 Centimeters
Wheel Size	10 Inches

Recommended Uses	Stunts, Off-road, Commuting
------------------	-----------------------------

## WARRANTY AND SUPPORT

The TODIMART S9 Electric Scooter comes with a **1-year limited warranty**. Spare parts availability is guaranteed for **5 years**.

For warranty claims, technical support, or inquiries about spare parts, please contact TODIMART customer service through your retailer or the official TODIMART website.