

[Manuals.plus](#) /

> [Bluefin Fitness](#) /

> Bluefin Fitness Vibration Platform Pro Model User Manual

Bluefin Fitness B Bluefin Pro 2023

Bluefin Fitness Vibration Platform Pro Model User Manual

Brand: Bluefin Fitness | Model: B Bluefin Pro 2023

1. INTRODUCTION

The Bluefin Fitness Vibration Platform Pro Model is designed to enhance your fitness routine by providing high-frequency vibrations that engage muscles throughout your body. This manual provides essential information for safe and effective use, setup, operation, and maintenance of your new fitness equipment.





Image: The Bluefin Fitness Vibration Platform Pro Model, a black fitness machine with a standing platform and handlebars.

Key Features:

- Latest upgraded design for effective weight loss and toning.
- Silent Drive Motor operating under 55dB for quiet workouts.
- Targets stubborn fat areas and increases muscle mass through high-frequency vibrations.
- Includes workout exercise cords, a workout poster, and a full instruction manual.
- Built-in speakers for audio playback during workouts.

2. SAFETY INFORMATION

Before operating the Bluefin Fitness Vibration Platform, please read and understand all safety instructions. Failure to follow these guidelines may result in injury or damage to the equipment.

- Consult with a healthcare professional before starting any new exercise program, especially if you have pre-existing medical conditions.

- Ensure the machine is placed on a stable, level surface.
- Do not use the machine if you weigh more than the maximum recommended weight of 150 kilograms (330 lbs).
- Keep children and pets away from the machine during operation.
- Always hold onto the handlebars for stability during use.
- Stop exercising immediately if you feel dizzy, nauseous, or experience any pain.
- Ensure the power cord is not damaged and is properly connected to a grounded outlet.
- The anti-slip surface and rubber suction cups are designed to ensure a safe and steady workout. Always ensure they are clean and free from debris.



Image: Close-up of feet on the anti-slip surface of the vibration platform, highlighting safety features.

3. PACKAGE CONTENTS

Verify that all components are present in your package before beginning assembly:

- Bluefin Fitness Pro Vibration Plate (Main Unit)
- Workout Exercise Cords (Resistance Bands)
- Workout Poster
- Full Instruction Manual
- Tools for Assembly
- US Power Cables (Type A & Type B)




Image: The Bluefin Fitness Pro Vibration Plate shown with its included accessories: resistance bands, workout poster, and instruction manual.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your Bluefin Fitness Vibration Platform. Refer to the included tools and hardware for each step.


1. Carefully unpack all components from the box.
2. Attach the main vertical support column to the base unit using the provided screws and tools. Ensure it is securely fastened.
3. Install the handlebars onto the vertical support column. Adjust the height if necessary and secure them firmly.
4. Connect the power cable to the machine and a suitable power outlet.
5. (Optional) Attach the workout exercise cords to the designated attachment points on the base of the machine.

Your browser does not support the video tag.

Video: A detailed guide on setting up the Bluefin Fitness Vibration Platform, including assembly of the main unit and handlebars.

5. OPERATING INSTRUCTIONS

Familiarize yourself with the control panel and various functions to optimize your workout experience.



WHISPER
QUIET



SUITABLE
FOR FLATS

SILENT DRIVE MOTOR

Silent drive technology produces whisper quiet vibrations meaning you can **workout in peace.**

Image: The control panel displaying various settings, including 180 intensity levels and 10 auto programs.

Control Panel Overview:

- **Mode:** Selects different workout modes or programs.
- **Speed +/-:** Adjusts the vibration intensity (up to 180 levels).
- **Start/Stop:** Begins or ends the workout session.
- **Time:** Sets the duration of your workout.
- **Cal/BMI Display:** Shows estimated calories burned and Body Mass Index.
- **Built-in Speakers:** Connect your device via MP3 input to play music.

Getting Started:

1. Plug in the machine and turn on the power switch (usually located at the back or side of the base).
2. Step onto the platform, ensuring your feet are positioned securely on the anti-slip surface. For varying intensity, adjust your foot placement: wider stance for higher intensity, narrower for lower.
3. Press the "Start" button to begin the vibration.
4. Use the "Speed +" and "Speed -" buttons to adjust the vibration intensity to your comfort level.
5. Select a pre-set program using the "Mode" button, or manually adjust time and speed.
6. To end your workout, press the "Stop" button.

Integrated Features:

- **Calorie Sensors:** Easily track your workout progress with integrated calorie sensors located on the handlebars. Simply grip the sensors during your workout to monitor.
- **Built-in Speakers:** Connect your audio device to the MP3 input to enjoy music while you exercise.
- **360° Rotation Plate:** The central rotating plate allows for dynamic movements, ideal for toning and shaping, providing rapid results.
- **Silent Drive Motor:** Experience whisper-quiet vibrations, making it suitable for use in various environments without disturbance.
- **Bottle Holder:** A convenient attached bottle holder helps you stay hydrated without interrupting your workout.



IMPROVE
CORE STRENGTH



BUILD
MUSCLE


INCREASE MUSCLE POWER

Vibrations cause rapid muscle contractions which help to build muscle and improve strength.

Image: Close-up of the handlebars showing the integrated calorie sensors for tracking progress.



RANGE OF
INTENSITIES



IDEAL FOR
ANY ABILITY

100'S OF SETTINGS TO CHOOSE FROM

With 180 levels of vibration intensity and 10 programmes tailored to specific goals, you can create the perfect workout.

180 | 10

INTENSITY LEVELS | AUTO PROGRAMMES




Image: The control panel with integrated speakers, allowing users to connect an audio device.



BOTTLE
HOLDER



KEEP THIRST
AT BAY

STAY HYDRATED

The attached bottle holder means you can stay hydrated without interrupting your workout.



Image: A water bottle placed in the attached holder on the vibration platform, emphasizing convenience.

6. EXERCISE GUIDE

The Bluefin Fitness Vibration Platform offers various ways to enhance your workout. Experiment with different stances and exercises to target specific muscle groups and achieve your fitness goals. Refer to the included workout poster for visual guidance.

Benefits and Techniques:

- **Full Body Workout:** High-frequency vibrations cause muscles to contract thousands of times per minute, leading to increased calorie burn and overall toning.
- **Burn Fat and Lose Weight:** Vibrations help increase metabolism, contributing to higher fat burning rates.
- **Relieve Joint Stress and Pains:** Vibrations can help reduce joint pain and alleviate muscle pain and cramps.
- **Increase Muscle Power:** Rapid muscle contractions help build muscle and improve strength.
- **Improve Flexibility:** Vibrations assist fluid movement between cells, improving overall flexibility.
- **Resistance Bands:** Utilize the included exercise cords to incorporate upper body and arm workouts, enhancing your full-body routine.



Image: A user demonstrating an exercise stance on the vibration plate, illustrating the benefits of a full-body workout.



Image: A user performing a lunge on the vibration plate, demonstrating how vibrations can aid in fat burning and weight loss.






RELIEVE JOINT STRESS REDUCE MUSCLE PAIN

RELIEVE JOINT STRESS AND PAINS

Vibrations work to reduce joint pain and can also work to relieve muscle pain and cramps.

Image: A user on the vibration plate, illustrating how the vibrations can help relieve joint stress and muscle pain.






IMPROVE FLEXIBILITY REDUCE STIFF MUSCLES

IMPROVE FLEXIBILITY

Vibrations help fluid move between cells which in turns helps to improve overall flexibility.

Image: A user utilizing the resistance bands with the vibration plate to increase muscle power and core strength.






500W MOTOR VERTICAL VIBRATION

VERTICAL LINEAR VIBRATION

The powerful 500w motor provides up to 180 levels of intense vertical vibration to challenge anyone.

Image: A user stretching on the vibration plate, demonstrating how it can improve overall flexibility and reduce stiff muscles.

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your vibration platform.

- **Cleaning:** Wipe down the machine with a soft, damp cloth after each use. Avoid abrasive cleaners or solvents.
- **Storage:** Store the machine in a cool, dry place away from direct sunlight and moisture.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Inspect the power cord for any signs of damage.

8. TROUBLESHOOTING

If you encounter any issues with your Bluefin Fitness Vibration Platform, refer to the common problems and solutions below:

| Problem | Possible Cause | Solution |
|---------------------------------------|---|--|
| Machine does not power on. | Power cord not connected; power switch off; no power from outlet. | Ensure power cord is securely plugged in. Check if the main power switch is on. Test the outlet with another device. |
| Vibrations are weak or inconsistent. | Incorrect speed setting; machine overloaded; uneven surface. | Increase the speed setting. Ensure user weight is within limits. Place the machine on a flat, stable surface. |
| Unusual noise during operation. | Loose components; internal issue. | Check all visible screws and tighten if loose. If noise persists, contact customer support. |
| Control panel display is not working. | Loose connection; power issue. | Ensure all cables are properly connected. Restart the machine. If the problem continues, contact customer support. |

9. PRODUCT SPECIFICATIONS

| Feature | Detail |
|-------------------------------|-------------------------------------|
| Brand | Bluefin Fitness |
| Model Name | Bluefin Fitness Pro Vibration Plate |
| Style | B Bluefin Pro 2023 |
| Maximum Weight Recommendation | 150 Kilograms |
| Controls Type | Push Button |
| Display Type | LCD or LED |

| Feature | Detail |
|-----------------------------------|------------------------------|
| Handle Type | Strap, Fixed |
| Maximum Speed | 180 RPM |
| Number of Programs | 10 |
| Number of Resistance Levels | 1 |
| Operation Mode | Automatic |
| Power Source | Corded Electric |
| Item Package Dimensions L x W x H | 29.13 x 22.83 x 9.84 inches |
| Package Weight | 23 Kilograms |
| Item Dimensions L x W x H | 27.56 x 29.13 x 50.39 inches |
| Item Weight | 20.5 Kilograms |
| Color | Black |
| Material | Plastic |
| Product Dimensions | 26.18"D x 27.95"W x 45.67"H |
| UPC | 620947084163 636339478472 |

10. WARRANTY AND SUPPORT

The Bluefin Fitness Vibration Platform Pro Model comes with a 12-month warranty. The Silent Drive Motor is built to last a lifetime, and Bluefin Fitness offers a lifetime warranty on the motor itself.

For technical support, troubleshooting assistance, or warranty claims, please contact Bluefin Fitness customer support through their official website or the contact information provided in your product packaging.

11. ADDITIONAL RESOURCES

For a comprehensive guide and further details, you can download the official User Manual in PDF format:

[Download User Manual
\(PDF\)](#)

