



[Manuals.plus](#) /

› [MePadKey](#) /

› MePadKey Trackpad Keyboard Case User Manual for Amazon Fire HD 10/10 Plus (10.1 inch, 11th/13th Gen)

MePadKey B0DBKS7L2J

MePadKey Trackpad Keyboard Case User Manual

MODEL: B0DBKS7L2J

For Amazon Fire HD 10/10 Plus (10.1 inch, 11th/13th Gen)

1. INTRODUCTION

This manual provides detailed instructions for the MePadKey Trackpad Keyboard Case. This accessory enhances your tablet experience by offering a physical keyboard with a touchpad, protective casing, and adjustable viewing angles. Please read this manual thoroughly to ensure proper use and maintenance of your device.



Image 1.1: MePadKey Trackpad Keyboard Case

2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- Tablet Case x 1
- 7-color Backlight Touchpad Keyboard x 1
- USB-C Charging Cable x 1
- User Manual x 1

3. COMPATIBILITY

This Trackpad Keyboard Case is specifically designed for the following models:

- Amazon Fire HD 10 (10.1 inch, 11th Generation, 2021 Release)
- Amazon Fire HD 10 Plus (10.1 inch, 11th Generation, 2021 Release)
- Amazon Fire HD 10 (10.1 inch, 13th Generation, 2023 Release)
- Amazon Fire HD 10 Plus (10.1 inch, 13th Generation, 2023 Release)

To confirm your tablet model, navigate to "Settings" on your tablet. This product is not compatible with other tablet models.

! ATTENTION

Only Fit : Fire HD 10 & 10 Plus
13th/11th Gen, 2023/2021 Release



Amazon Kindle Fire HD 10 & HD 10 Plus
13th Generation, 2023 Release
11th Generation, 2021 Release



Amazon Kindle Fire HD 10 & HD 10 Plus
7th Generation, 2017 Release
9th Generation, 2019 Release



Image 3.1: Tablet Compatibility Guide

4. PRODUCT FEATURES

- **7-Color Backlight Keyboard:** The keyboard features seven switchable backlight colors, allowing for comfortable use in various lighting conditions. Backlight modes can also be adjusted.
- **Integrated Touchpad:** The touchpad provides mouse functionality, supporting multi-finger gestures for enhanced navigation and productivity.
- **Type-C Charging Port:** The keyboard is equipped with a Type-C charging port for faster and more convenient recharging of its built-in battery.
- **Detachable Keyboard:** The keyboard is magnetically attached to the case, allowing it to be easily removed for flexible use.
- **Anti-Slip Grooves:** The case includes anti-slip grooves to securely hold the tablet in place and prevent accidental slipping.
- **Multi-Angle Adjustment:** Supports multiple viewing angles for comfortable use in various environments.

- **Precision Cutting:** The case features precise cutouts for all ports, buttons, and cameras, ensuring full accessibility.
- **Honeycomb Design:** The interior of the case features a honeycomb pattern for efficient heat dissipation and enhanced protection against drops and shocks.

Function Introduction



Rechargeable keyboard



Lasting battery life



Built in pen slot



Anti-fingerprint



Image 4.1: Key Features Overview

Smart Touchpad

Sensitive touch and smooth operation



Image 4.2: Smart Touchpad Functionality



7 Colors

Backlight keyboard



Image 4.3: 7-Color Backlight Keyboard

Adjustable Perspective

In various scenarios, use it comfortably



Image 4.4: Adjustable Viewing Angles



HONEYCOMB DESIGN

Safe and fast heat dissipation



Image 4.5: Honeycomb Design for Protection and Heat Dissipation

5. SETUP INSTRUCTIONS

5.1. Tablet Installation

Carefully insert your Amazon Fire HD 10/10 Plus tablet into the protective case. Ensure all edges are securely fitted and that the camera and ports align with the case's cutouts.

Your browser does not support the video tag.

Video 5.1: Demonstrates how to install the tablet into the case and attach the keyboard.

5.2. Charging the Keyboard

Connect the provided USB-C charging cable to the keyboard's Type-C port and the other end to a USB power adapter (not included). The charging indicator light will illuminate during charging and turn off when fully charged.

Your browser does not support the video tag.

Video 5.2: Shows the Type-C charging port and how to connect the charging cable.

5.3. Bluetooth Pairing

1. Ensure the keyboard is charged.
2. Slide the power switch on the keyboard to the "ON" position.
3. On your Amazon Fire tablet, go to **Settings > Connected Devices > Bluetooth**.
4. Toggle Bluetooth to "ON" if it's not already.
5. Select "Pair new device".
6. The tablet will search for available devices. Select "Keyboard" from the list.
7. Confirm the pairing request on your tablet. The keyboard is now connected.

Your browser does not support the video tag.

Video 5.3: Demonstrates the Bluetooth pairing process for the keyboard.

6. OPERATING INSTRUCTIONS

6.1. Keyboard Functions

- **Typing:** Use the keyboard for text input as you would with a standard computer keyboard.
- **Backlight Control:** Press the **Light Bulb** key to cycle through backlight colors and modes.
- **Media Control Keys:** Dedicated keys for volume control, play/pause, previous/next track, and screen lock are available.

6.2. Touchpad Gestures

The touchpad supports various multi-finger gestures:

- **Move Cursor:** Use one finger to move the cursor across the screen.
- **Zoom In/Out:** Use two fingers to pinch in or spread out to zoom.
- **Go to Home:** Use three fingers to swipe up to return to the home screen.
- **Screenshot:** Use three fingers to swipe down to capture a screenshot.
- **Lock/Unlock Touchpad:** Press **FN + Win** key simultaneously to lock or unlock the touchpad.

Your browser does not support the video tag.

Video 6.1: Demonstrates touchpad gestures and keyboard backlight functionality.

7. MAINTENANCE

- Keep the keyboard and case clean by wiping with a soft, dry cloth.
- Avoid exposing the device to extreme temperatures, humidity, or direct sunlight.
- Do not use harsh chemicals or abrasive cleaners.
- Store the keyboard and case in a safe place when not in use to prevent damage.

8. TROUBLESHOOTING

- **Keyboard not connecting via Bluetooth:**
 - Ensure the keyboard is powered on and fully charged.
 - Verify Bluetooth is enabled on your tablet.

- Forget the device in your tablet's Bluetooth settings and attempt to re-pair.
- Restart both the tablet and the keyboard.

- **Keyboard not typing:**

- Check if the keyboard is successfully paired.
- Ensure the keyboard is charged.

- **Touchpad not responding:**

- Ensure the touchpad is not locked (press **FN + Win**).
- Restart the keyboard and tablet.

- **Backlight not working:**

- Press the **Light Bulb** key to activate or change the backlight.
- Ensure the keyboard has sufficient battery charge.

9. SPECIFICATIONS

Product Dimensions	9.84 x 7.48 x 0.94 inches
Item Weight	1.35 pounds
Manufacturer	MePadKey
Batteries	1 Lithium Polymer battery (included)
Compatible Devices	Amazon Fire HD 10/10 Plus 10.1 inch (2021/2023, 11th/13th Gen)
Connectivity Technology	Bluetooth
Keyboard Description	Multi Functional
Special Feature	Rechargeable, Backlight, Touchpad
Material	Acrylonitrile Butadiene Styrene

10. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please refer to the contact information provided on the product packaging or the official MePadKey website. Please retain your proof of purchase for warranty claims.