

MDC1

Generic MDC1 Electric Citrus Juicer User Manual

Model: MDC1

INTRODUCTION

Thank you for choosing the Generic MDC1 Electric Citrus Juicer. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and retain them for future reference.

The MDC1 Electric Citrus Juicer is designed for extracting juice from various citrus fruits and other soft fruits. Its portable, wireless, and USB rechargeable design offers convenience for juicing anytime, anywhere.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not immerse the motor unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Always ensure the juicer is properly assembled before operation.
- Do not attempt to disassemble the motor unit beyond what is described in this manual.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your Electric Citrus Juicer:

- Top Cover
- Reamer/Juicing Cone
- Filter/Pulp Separator

- Juice Container
- Motor Base with Control Button
- USB Charging Port
- Juice Outlet Spout



EASY TO GET DELICIOUS FRUIT OR VEGETABLE JUICE



Image: Overview of the juicer's main parts and its easy-to-clean design.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash all detachable parts (top cover, reamer, filter, juice container) with warm soapy water before first use. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Charge:** Ensure the juicer is fully charged before initial use. Connect the USB charging cable to the charging port on the motor base and to a suitable USB power source. The indicator light will show charging status.



Image: The juicer being charged using a USB cable connected to a power bank.

4. **Assemble:** Place the juice container onto the motor base. Insert the filter/pulp separator into the juice

container, followed by the reamer/juicing cone. Secure the top cover by turning it clockwise until it locks into place.

OPERATING INSTRUCTIONS

Follow these steps to extract juice efficiently:

1. **Prepare Fruit:** Wash the fruit thoroughly. For citrus fruits like oranges, lemons, or grapefruits, cut them in half. For other fruits like apples or pomegranates, cut them into pieces that fit comfortably on the reamer.



Image: Demonstrates cutting an orange in half and examples of orange, pomegranate, and apple juice.

2. **Place Fruit:** Place one half of the prepared fruit onto the reamer.

3. **Start Juicing:** Long press the power button for two seconds to turn on the juicer. Then, click the switch to begin the juicing process. The juicer will rotate 360 degrees to extract juice.
4. **Collect Juice:** The extracted juice will flow into the juice container below, separated from the pulp by the filter.
5. **Serve:** Once juicing is complete, open the juice outlet spout to pour the fresh juice into a glass.





Image: A six-step visual guide showing how to operate the juicer, from pressing the button to collecting juice.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your juicer.

- Disassemble:** Turn off the juicer and carefully disassemble all removable parts: top cover, reamer, filter, and juice container.
- Wash:** Wash these parts immediately after use with warm, soapy water. Use a brush to remove any pulp residue from the filter. Rinse thoroughly.
- Motor Base:** Wipe the motor base with a damp cloth. **Do not immerse the motor base in water or any other liquid.**
- Dry:** Ensure all parts are completely dry before reassembling or storing.
- Storage:** Store the juicer in a clean, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Battery is low or depleted.	Charge the juicer fully using the provided USB cable.
Juicer stops during operation.	Overload protection activated (too much pressure or hard fruit).	Reduce pressure on the fruit. Cut harder fruits into smaller pieces. Allow the motor to cool down for a few minutes before restarting.
Low juice yield.	Fruit not properly cut or too dry.	Ensure fruit is fresh and cut appropriately. Apply gentle, consistent pressure.
Juicer leaks.	Parts not assembled correctly.	Disassemble and reassemble all parts, ensuring they are securely locked in place. Check the juice outlet spout is closed.

SPECIFICATIONS

- Model:** MDC1
- Brand:** Generic

- **Power:** 45 Watts
- **Voltage:** 7.4 Volts
- **Power Source:** Corded Electric (for charging), USB Rechargeable (for operation)
- **Material:** Plastic
- **Color:** White
- **Product Dimensions:** 13.2D x 24W x 11.2H Centimeters
- **Item Weight:** 1 kg 100 g
- **Special Feature:** Portable, Wireless, Hands-Free
- **Manufacturer:** Theorie
- **Manufacture Year:** 2024

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer where the product was purchased or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.

© 2024 Generic. All rights reserved.