Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Slevoo AU-C003

Slevoo Carpet Cleaner Machine User Manual

Model: AU-C003

INTRODUCTION

Thank you for choosing the Slevoo Carpet Cleaner Machine. This portable upholstery and carpet cleaner is designed to provide powerful and efficient cleaning for various surfaces in your home and vehicle. With its strong suction and versatile design, it helps remove tough spots and stains, leaving your carpets and upholstery looking refreshed. Please read this manual thoroughly before operation to ensure safe and optimal performance.



The Slevoo Carpet Cleaner Machine, designed for effective spot and stain removal.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Use only Slevoo cleaning solutions or compatible non-foaming solutions.
- Do not immerse the machine in water or other liquids.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not use without tanks in place.
- Unplug from outlet when not in use and before cleaning or servicing.

- Do not allow to be used as a toy. Close attention is necessary when used by or near children.

Product Components

Familiarize yourself with the parts of your Slevoo Carpet Cleaner Machine:

- Main Unit with Motor
- Clean Water Tank (42.23 oz capacity)
- Dirty Water Tank (1L max capacity)
- Flexible Hose (4.92 ft)
- Cleaning Tool/Nozzle with Brush
- Power Cord (18 ft)
- Slevoo Spot & Stain Remover (Concentrated)





The cleaning tool features both spray and powerful suction capabilities.



The cleaning tool is equipped with a high-precision soft brush for effective scrubbing without damaging fabrics.

Assembly & Setup


Follow these steps to prepare your Slevoo Carpet Cleaner for use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Attach Hose:** Connect the flexible hose securely to the main unit's hose port.
3. **Attach Cleaning Tool:** Connect the cleaning tool to the end of the flexible hose. Ensure it clicks into place.
4. **Fill Clean Water Tank:** Remove the clean water tank from the unit. Fill it with warm tap water (max 140°F/60°C) and the recommended amount of Slevoo Spot & Stain Remover. Do not overfill.



The large 42.23 oz clean water tank minimizes refills during cleaning.

5. **Replace Clean Water Tank:** Place the filled clean water tank back onto the main unit, ensuring it is seated correctly.
6. **Check Dirty Water Tank:** Ensure the dirty water tank is empty and properly secured before starting.



The visible dirty water tank has a 1L maximum capacity and is easy to monitor.

Operating Instructions

Follow these steps for effective cleaning:

1. **Plug In:** Plug the power cord into a grounded electrical outlet.
2. **Power On:** Press the power button on the main unit to turn on the machine.
3. **Pre-treat (Optional):** For heavily soiled areas, you may pre-treat the stain with the cleaning solution by spraying it directly onto the spot without suctioning. Allow it to sit for a few minutes.
4. **Spray and Scrub:** Hold the cleaning tool firmly against the stained surface. Press the spray trigger to release the cleaning solution while moving the tool slowly over the area. Use the brush to gently scrub the stain.




The deep cleaning process involves three steps: spray, scrub, and powerful suction.

5. **Suction:** Release the spray trigger and continue to move the cleaning tool over the wet area to suction up the dirty water. Make several passes until the water being extracted appears clean.
6. **Repeat:** For stubborn stains, repeat steps 4 and 5 as needed.
7. **Versatile Cleaning:** The Slevoo cleaner is suitable for carpets, rugs, upholstery, car interiors, stairs, and more.

Easily deal with all kinds of stains that may appear in life

Like Mud, Wine, Oil, Pet accidents and more



The machine is versatile, effectively cleaning various surfaces including carpets, car seats, sofas, and more.



Ideal for pet owners, this cleaner effectively removes pet stains and odors from various fabrics.



Demonstration of the cleaner solving pet mess problems on stairs, showing effective stain removal.



The extended hose and power cord provide excellent reach for cleaning large areas and various furniture.

Care & Maintenance

Proper maintenance ensures the longevity and performance of your cleaner:

1. **Empty Dirty Water Tank:** After each use, or when the dirty water tank reaches its MAX fill line, turn off the machine and empty the dirty water tank. Rinse it thoroughly with clean water.
2. **Rinse Clean Water Tank:** Empty any remaining solution from the clean water tank and rinse it.
3. **Clean Cleaning Tool:** Detach the cleaning tool and rinse it under running water to remove any debris or residue.



The detachable cleaning head allows for easy rinsing and maintenance.

4. **Wipe Down Unit:** Wipe the exterior of the main unit with a soft, damp cloth.
5. **Air Dry:** Allow all components to air dry completely before reassembling and storing.
6. **Storage:** Store the cleaner in a dry, cool place. The compact design (8.5 lbs) makes it easy to store anywhere.



The lightweight and portable design allows for easy transport and storage.

Troubleshooting

If you encounter issues, refer to this table for common problems and solutions:

Problem	Possible Cause	Solution
No Power	Not plugged in; Power outlet issue; Machine fault.	Ensure plug is fully inserted; Test outlet with another device; Contact customer service.
No Suction	Dirty water tank full; Hose or nozzle clogged; Tank not properly seated.	Empty dirty water tank; Clear any blockages; Re-seat tanks securely.

Problem	Possible Cause	Solution
No Spray	Clean water tank empty; Tank not properly seated; Spray nozzle clogged.	Refill clean water tank; Re-seat tank; Clean spray nozzle.
Machine shuts off with beep alarm	Dirty water tank full; Clean water tank empty; Exception alarm.	Empty dirty water tank; Refill clean water tank; Refer to indicator lights for specific alarm (Flashing Red with Beep Alarm = Exception Alarm).

Specifications

Feature	Detail
Brand	Slevoo
Model Name	AU-C003
Motor Power	450W
Suction Power	11Kpa
Clean Water Tank Capacity	42.23 oz (approx. 1.25 L)
Dirty Water Tank Capacity	1L (MAX)
Hose Length	4.92 ft
Power Cord Length	18 ft
Item Weight	8.5 lbs (approx. 4.78 kg)
Package Dimensions	16.85 x 13.66 x 7.8 inches
Color	Black

Warranty & Customer Support

Slevoo is committed to providing exceptional customer service. The manufacturing of every Slevoo product strictly adheres to high-quality standards.

- For any inquiries or assistance, please feel free to reach out to Slevoo Professional Customer Service.
- Email inquiries are typically responded to within 24 hours.
- For the most up-to-date warranty information and support, please refer to the official Slevoo website or your purchase documentation.
- An official user manual in PDF format can be found here.

© 2024 Slevoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DBLCLTRY

More documents and user manuals: **https://manuals.plus/**