
[Manuals.plus](#) /

› [DREAME](#) /

› DREAME Gleam Hair Dryer Instruction Manual

DREAME Gleam Hair Dryer

DREAME Gleam Hair Dryer Instruction Manual

Model: Gleam Hair Dryer

INTRODUCTION

Thank you for choosing the DREAME Gleam Hair Dryer. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new hair dryer. Please read these instructions thoroughly before first use and keep them for future reference.



Image: The DREAME Gleam Hair Dryer, showcasing its compact design and rose color.

IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of electric shock, fire, or injury, always follow basic safety precautions when using electrical appliances.

- Read all instructions before using this appliance.
- Keep away from water. Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- Always unplug this appliance immediately after using.
- Unplug this appliance before cleaning.
- Do not use with a voltage converter.

- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- Attachments may be hot during use. Allow them to cool before handling.
- Do not place appliance on any surface while it is operating.
- While using the appliance, keep your hair away from the air inlets.
- This appliance is intended for household use only.

PRODUCT OVERVIEW

The DREAME Gleam Hair Dryer is engineered for fast and efficient hair drying with advanced features to protect hair health.

- **High-Speed Motor:** Equipped with a brushless motor operating at 110,000 RPM and 1600W for powerful airflow.
- **Intelligent Temperature Control:** Maintains a safe 57°C constant temperature to prevent heat damage.
- **Negative Ion Generator:** Releases 200 million negative ions to reduce frizz and enhance hair smoothness.
- **Lightweight Design:** Weighs approximately 330g (excluding power cord and nozzle) for comfortable handling.
- **Quiet Operation:** Advanced air channel system reduces noise to 59 dB.
- **Adjustable Settings:** Features 2 airflow speeds and 4 temperature levels.

110,000RPM



*110,000RPM: Data from Dreame Labs. Under the standard laboratory environment (23±2°C).

110,000RPM High-Speed Brushless Motor

Image: Internal view highlighting the 110,000 RPM high-speed brushless motor.

57°C

Intelligent Constant Temperature*



*57 °C : Data from Dreame Labs.




Image: Illustration of the 57°C Intelligent Constant Temperature technology.



Built-in Negative Ion Generator Releasing 200 million Negative Ions*

Image: The built-in negative ion generator releasing 200 million negative ions for smoother hair.

SETUP

1. **Unpack:** Carefully remove the hair dryer and all accessories from the packaging.
2. **Inspect:** Check the appliance for any signs of damage. Do not use if damaged.
3. **Attach Nozzle:** The magnetic styling nozzle can be easily attached to the front of the hair dryer. Ensure it clicks securely into place. The nozzle can rotate 360 degrees for versatile styling.



Image: Attaching the 360° magnetic nozzle to the hair dryer.

4. **Power Connection:** The DREAME Gleam Hair Dryer is equipped with a 16 Amp plug. If your home sockets are 6 Amp, you will need a compatible converter.

All Dreame Grooming Products come with a standard 16 Ampere plug. If you wish to use it with a 6 Ampere socket at home, you can easily use a converter.

To claim your FREE CONVERTER, simply contact us at our toll-free number: [18003093942](tel:18003093942) or via email: Support.in@dreame.tech.

Customer Support Hours:
Monday to Saturday: 10 AM to 6 PM. Sunday: 10 AM to 4 PM



Image: The 16 Amp plug of the hair dryer and an example of a 6 Amp converter.

Important: Ensure the converter is suitable for the wattage of the hair dryer (1600W) to avoid electrical hazards.

5. **Plug In:** Insert the plug into a suitable electrical outlet.

The DREAME Gleam Hair Dryer features intuitive controls for airflow speed and temperature.



Image: Control panel for airflow speeds and temperature levels.

1. **Power On/Off:** Locate the power button, typically on the handle. Press once to turn on, and again to turn off.
2. **Adjust Airflow Speed:** Use the speed control button to switch between 2 airflow speeds:
 - **High-Speed Airflow**
 - **Low-Speed Airflow**
3. **Select Temperature Level:** Use the temperature control button to cycle through 4 temperature levels:
 - **Cool Air (25°C/77°F):** Ideal for setting styles and reducing frizz.
 - **Warm Air (57°C/134.6°F):** The intelligent constant temperature for gentle drying and hair protection.
 - **Hot Air (85°C/185°F):** For faster drying.

- **Natural & Hot Circulation:** Alternates between hot and cool air to prevent overheating and add shine.

4. Drying Technique:

- For best results, towel-dry hair before using.
- Hold the dryer approximately 15-20 cm away from your hair.
- Move the dryer continuously to avoid concentrating heat in one area.
- Use the cool shot function to set your style once hair is dry.

MAINTENANCE AND CARE

Regular cleaning ensures optimal performance and extends the lifespan of your DREAME Gleam Hair Dryer.

1. **Unplug Before Cleaning:** Always ensure the hair dryer is unplugged from the power outlet and has cooled down before cleaning.
2. **Clean Air Inlet Filter:** The rear air inlet filter should be cleaned regularly to prevent dust and hair buildup, which can affect performance.
 - Gently twist or pull off the rear filter cover (refer to product diagram if available).
 - Use a soft brush or cloth to remove any accumulated dust or lint.
 - Do not use water or harsh chemicals.
 - Reattach the filter cover securely.



Image: Illustration of cleaning the air inlet filter.

3. **Clean Exterior:** Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
4. **Storage:** Store the hair dryer in a dry place, away from moisture and direct sunlight. Do not wrap the power cord tightly around the appliance.

TROUBLESHOOTING

If you encounter any issues with your DREAME Gleam Hair Dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hair dryer does not turn on.	Not plugged in correctly; power outlet issue; appliance fault.	Ensure the plug is fully inserted. Test the outlet with another appliance. If still not working, contact customer support.
Weak airflow or overheating.	Blocked air inlet filter.	Unplug the dryer and allow it to cool. Clean the air inlet filter as described in the Maintenance section.

Problem	Possible Cause	Solution
Unusual noise or smell.	Internal component issue; foreign object inside.	Immediately unplug the dryer. Do not attempt to repair. Contact customer support.
Hair feels frizzy after drying.	Negative ion generator not functioning optimally; incorrect temperature setting.	Ensure the negative ion feature is active (it operates automatically). Try using the Cool Air or Warm Air (57°C) settings.

SPECIFICATIONS

Feature	Detail
Model Name	Gleam Hair Dryer
Product Dimensions (LxWxH)	37 x 17 x 8 cm
Item Weight	330g (dryer body only), 500g (with packaging)
Wattage	1600 Watts
Power Source	Corded Electric
Motor Speed	110,000 RPM
Negative Ions	200 Million
Constant Temperature	57°C
Airflow Speeds	2
Temperature Settings	4 (Cool, Warm, Hot, Natural & Hot Circulation)
Noise Level	59 dB
Hair Type Compatibility	Frizzy (optimized for)
UPC	850062802179
GTIN	850062802179

WARRANTY AND SUPPORT

Your DREAME Gleam Hair Dryer comes with a comprehensive**2-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product performs as expected under normal use. For warranty claims, technical assistance, or any product-related inquiries, please contact DREAME customer support:

- **Toll-Free Number:** 18003093942
- **Email:** Support.in@dreame.tech
- **Customer Support Hours:**
 - Monday to Saturday: 10 AM to 6 PM
 - Sunday: 10 AM to 4 PM

Please have your purchase receipt and product model information ready when contacting support.



Image: DREAME After-Sales Service representation.