



Manuals.plus /

› Forc /

› Forc 21.5 Inch WiFi Digital Picture Frame User Manual

Forc Forc-DW215

Forc 21.5 Inch WiFi Digital Picture Frame

Model: Forc-DW215

User Instruction Manual

Setup

Operation

Maintenance

Troubleshooting

Specifications

Support & Warranty

PRODUCT OVERVIEW

The Forc 21.5 Inch WiFi Digital Picture Frame provides a vibrant display for your cherished photos and videos. With its large IPS screen and ample storage, it offers an easy way to share and relive memories with family and friends, even from a distance.

21.5 Inch Large Digital Frame with Remote

21.5 Inch
Large Screen

16:9
Aspect Ratio

1920*1080
Resolution

FHD IPS
Screen



Image: The Forc 21.5 Inch Digital Picture Frame, showcasing its large display and accompanying remote control.



Image: A Forc 21.5 Inch Digital Picture Frame displaying a scenic landscape, highlighting its large screen and 1080P FHD resolution.

SETUP GUIDE

Follow these steps to set up your Forc Digital Picture Frame and begin sharing memories.

1. Unboxing and Initial Power On

- Carefully remove the frame and all accessories from the packaging.
- Connect the power adapter to the frame's power port and plug it into a wall outlet.
- The frame will automatically power on.

2. Network Connection

The frame requires a 2.4 GHz Wi-Fi connection for app-based sharing and online features.

1. On the frame's screen, navigate to the Wi-Fi settings.
2. Select your 2.4 GHz Wi-Fi network (visible or hidden).
3. Enter your Wi-Fi password and connect.

3. App Download and Pairing

The Uhale APP is essential for remote photo and video sharing.

1. Download the *Uhale APP* from the App Store (for iOS) or Google Play Store (for Android).
2. Open the Uhale APP and create an account or log in.
3. On the frame, locate the unique pairing code.
4. In the Uhale APP, enter the pairing code to link your smartphone with the digital picture frame.




Image: A visual guide demonstrating the effortless setup process, including connecting to Wi-Fi, downloading the app, pairing, and sharing photos and videos.

4. Uploading Photos and Videos

You have multiple options for adding content to your frame:

- **Uhale APP:** Send photos or small videos (max. 30 seconds) directly from your smartphone.
- **USB Drive/SD/MMC Card:** Insert a compatible memory card or USB drive into the frame's designated slot to display content directly or transfer to internal storage.
- **USB Cable/Website:** Connect the frame to a PC via USB cable or use the provided website interface to upload bulk photos.

Upload photos and videos in multiple ways



App



USB



SD/MMC



Image: Illustration showing various methods to upload photos and videos to the digital frame: via the Uhaul App, USB drive, or SD/MMC card.




Image: A diagram illustrating the multiple options for uploading content to the frame (App, SD/MMC Card, USB Drive, Computer) and exporting content (USB Drive, SD/MMC Card).

OPERATING INSTRUCTIONS

Display and Content Playback

- **Vivid Photo Quality:** The 21.5-inch FHD IPS screen with 1920*1080 resolution provides clear and vibrant visuals from various viewing angles.
- **Automatic Rotation:** The frame automatically adjusts picture orientation based on its physical placement (portrait or landscape).
- **Slideshow:** Content will play in a continuous slideshow. You can adjust the slideshow time interval in the settings.

Fits Perfectly in Any Décor

Wall Mountable
Auto-Rotate Pictures



Image: The digital picture frame shown in both landscape and portrait orientations, demonstrating its wall-mountable design and auto-rotate feature.

Storage Management

- **Internal Storage:** The frame comes with 32GB of built-in storage, capable of holding over 80,000 photos.
- **External Storage:** You can expand storage or play content directly from a micro SD card (up to 32GB) or a USB drive.

Built-in 32GB large internal storage

Can store up to 80,000 pictures



Image: A stack of digital photos appearing to be stored within the frame, illustrating the built-in 32GB internal storage capacity.

Sharing and Connectivity

- **Uhale APP Sharing:** Share photos and videos instantly from your smartphone to the frame, regardless of your location, as long as the frame is connected to Wi-Fi.
- **Multi-User Sharing:** Invite friends and family to share their moments to your frame via the Uhale APP.

Remote Control and Settings

Use the included remote control to navigate menus and adjust settings. The frame also offers various customizable features:

- **Sleep Mode:** Set specific times for the frame to automatically turn off and on.
- **Show/Hide Picture:** Manage visibility of specific content.
- **Weather and Time Display:** Enable display of current weather and time.
- **Favorite Photo:** Mark photos as favorites for easy access.
- **Single Repeat:** Loop a single photo or video.
- **Full Screen:** Adjust display mode for full-screen viewing.

- **Adjustable Slideshow Time:** Customize the duration each picture is displayed.
- **Instant/Timed Wishes:** Send special messages for specific days via the app.



Image: The Forc Digital Picture Frame displaying a family photo, surrounded by icons representing its features: Photo, Video, Free App, Built-in 32GB, Clock, Weather, Sleep Mode, and Photo playback via USB/SD card.

MAINTENANCE

Proper care ensures the longevity and optimal performance of your digital picture frame.

Cleaning

- **Screen:** Use a soft, lint-free cloth specifically designed for electronics screens. Do not use abrasive cleaners or sprays directly on the screen. Lightly dampen the cloth with water if necessary.
- **Frame Body:** Wipe with a dry, soft cloth. Avoid using harsh chemicals.

Software Updates

- The frame may receive periodic software updates to improve performance and add features.

- It is recommended to keep the frame connected to Wi-Fi to receive updates.
- If you experience storage issues, consider disabling 'automatic updates' in the settings and manually restarting the frame periodically to clear temporary system files.

Storage Management

- Regularly review content on your frame. Delete unwanted photos or videos to free up space.
- If internal storage appears to be consumed rapidly by 'system' files, a simple restart of the frame can often resolve this by clearing cached data.

TROUBLESHOOTING

This section addresses common issues you might encounter with your Forc Digital Picture Frame.

Problem	Possible Cause	Solution
Frame not connecting to Wi-Fi.	Incorrect password, out of range, network interference, temporary glitch.	<ol style="list-style-type: none"> 1. Double-check Wi-Fi password. 2. Ensure frame is within range of your 2.4 GHz router. 3. Restart the frame and your Wi-Fi router.
Cannot upload photos/videos via App.	Frame not connected to Wi-Fi, App not paired, file format/size issues.	<ol style="list-style-type: none"> 1. Verify frame's Wi-Fi connection. 2. Confirm the App is correctly paired with the frame. 3. Check if video length exceeds 30 seconds. 4. Restart the frame and the Uhale App.
Internal storage is full quickly.	Large number of files, system file accumulation.	<ol style="list-style-type: none"> 1. Delete old or unwanted content from the frame. 2. Restart the frame; this can often reduce the size of temporary system files. 3. Utilize external SD cards or USB drives for additional storage.
Frame is unresponsive.	Temporary software glitch.	<ol style="list-style-type: none"> 1. Unplug the power adapter, wait 10 seconds, then plug it back in to restart the frame.

If the issue persists after trying these solutions, please refer to the Support section for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	Forc-DW215
Screen Size	21.5 Inches
Resolution	1920 x 1080 (FHD)
Display Type	IPS Screen
Internal Storage	32GB
External Storage Support	Micro SD Card (up to 32GB), USB Drive
Connectivity	Wi-Fi (2.4 GHz)
Compatible Devices	Smartphone (via Uhale APP)
Product Dimensions	12 x 22 x 0.99 inches
Item Weight	7.8 pounds
Mounting Type	Wall-Mounted, Tabletop

SUPPORT & WARRANTY

Customer Support

For any questions, technical assistance, or issues not covered in this manual, please contact Forc customer support. Refer to the contact information provided with your product packaging or visit the official Forc website. You can also visit the Forc Store on Amazon for additional product information and resources.

Warranty Information

Specific warranty terms and conditions for the Forc Digital Picture Frame may vary. Please refer to the warranty card included with your product or contact Forc customer support for detailed information regarding warranty coverage, duration, and claims procedures.