## weeonekids EV-G

# weeonekids EV-G 24V Ride-On Electric Go-Kart Instruction Manual

Model: EV-G

## Introduction

Thank you for choosing the weeonekids EV-G 24V Ride-On Electric Go-Kart. This manual provides essential information for the safe assembly, operation, and maintenance of your new electric vehicle. Please read all instructions carefully before use and retain this manual for future reference.

### Safety Warnings

- Adult supervision is required at all times.
- Ensure all components are securely fastened before operation.
- Do not operate near roads, motor vehicles, steep inclines, or swimming pools.
- Always wear appropriate safety gear, including a helmet.
- Maximum weight capacity: 150 lbs.
- Recommended age: 3-12 years.

## What's in the Box

Your weeonekids EV-G package includes all necessary components for assembly and operation, except for the child. Please verify all parts are present upon unboxing.

- Main vehicle body
- 4 wheels
- Adjustable seat
- Steering wheel
- Remote control
- 24V 7AH battery
- Charger

- Assembly tools (if required)
- Instruction manual

## Setup and Assembly

Follow these steps to assemble your ride-on toy. It is recommended to have two adults for certain steps.

1. **Unboxing:** Carefully open the package. Remove all components and protective packaging.
2. **Connect Battery:** Locate the battery compartment and connect the battery terminals as instructed.
3. **Install Wheels:** Attach the wheels to the axles, ensuring all washers and nuts are securely fastened.
4. **Attach Steering Wheel:** Connect the steering wheel to the steering column, ensuring all wires are properly connected and secured.
5. **Install Seat:** Secure the adjustable seat into the vehicle body.
6. **First Charge:** Before initial use, charge the battery for 8-12 hours. Do not exceed 20 hours to prevent battery damage.

### Assembly Video Guide

Text Description: This video provides a detailed step-by-step guide on how to assemble the Children's Electric Car, covering all major components and connections.

Text Description: A complete guide demonstrating the assembly process for the Hikiddo 24V 4WD Kids ATV, which shares similar assembly principles.

### Visual Assembly Steps




Text Description: An overview of the 24V Ride on Toy for Big Children, showcasing its robust design and large wheels.




Text Description: Close-up of the simulation dashboard, highlighting the music player, low/high speed, and forward/backward controls.

## Operating Instructions

Familiarize yourself with the controls and features for a safe and enjoyable riding experience.

### Controls and Features

- **Power Button:** Press to turn the vehicle ON/OFF.
- **Speed Selection:** Toggle between Low Speed (2WD) and High Speed (4WD) using the dashboard switches.
- **Forward/Reverse:** Use the gear switch to select forward or reverse motion.
- **Foot Pedal:** Press the foot pedal to accelerate. Release to brake.
- **Remote Control:** Parents can control the vehicle with the included remote control, offering emergency brake and variable speed options (max 2.5 mph under remote control).
- **Music & Bluetooth:** Connect your mobile device via Bluetooth to play music through the integrated speaker. Use dashboard

controls to skip tracks or adjust volume.

- **Adjustable Seat:** The seat can be adjusted to three different positions for optimal comfort and legroom.

## Operation in Action

Text Description: A child enjoying the EV-G ride-on toy, demonstrating its movement and features in an outdoor setting.

Text Description: This video showcases the 24V 4x4 ride-on UTV in action, highlighting its ability to explore various terrains and its variable speed options.




Text Description: Image illustrating the remote control, showing buttons for emergency brake and variable speeds, allowing parents to manage the ride-on toy.




Text Description: Close-up of the wide and adjustable seat, demonstrating its suitability for various child sizes and the 130 lbs weight capacity.

## Maintenance

Proper maintenance ensures the longevity and safe operation of your ride-on toy.

### Charging the Battery

- Always use the provided 24V charger.
- Plug the charger into the designated charging port on the vehicle.
- Charge for 8-12 hours for a full charge. Do not charge for more than 20 hours.
- Charge the battery regularly, even if the vehicle is not in use, to maintain battery health.

### General Care

- Keep the vehicle clean by wiping with a damp cloth. Avoid using harsh chemicals.

- Store the vehicle in a dry place away from direct sunlight and extreme temperatures.
- Regularly inspect wheels, steering, and electrical connections for any signs of wear or damage.

## Troubleshooting

If you encounter issues, refer to these common solutions:

- **Vehicle not moving:** Ensure the battery is fully charged and properly connected. Check all electrical connections.
- **Reduced power/short battery life:** The battery may need a full charge or could be nearing the end of its lifespan. Avoid overcharging.
- **Music/Bluetooth not working:** Verify all internal wiring connections to the music board. Ensure Bluetooth is correctly paired with your device.
- **Remote control not responding:** Check battery in the remote control. Ensure the vehicle is not in manual mode if remote control is desired.

## Specifications

| | |
|---|---|
| **Brand Name** | weeonekids |
| **Model Number** | EV-G |
| **Power** | 24V (4x75W motors, Total 300W) |
| **Battery** | 24V 7AH |
| **Max Speed** | 5 Miles (approx. 8 km/h) |
| **Max Load Capacity** | 150 lbs |
| **Age Range** | 3-12 years (Manufacturer Minimum Age: 36 months) |
| **Dimensions (L x W x H)** | 47.25" x 31.5" x 29.15" |
| **Item Weight** | 70 Pounds |
| **Material Type** | Alloy Steel |
| **Drive Modes** | 2WD / 4WD selectable |
| **Special Features** | Bluetooth Speaker, Adjustable Seat, Metal Frame (80CRV2), 4 Big Shock Absorbers, 14" Wear-Resistant Wheels |

## Warranty and Support

For warranty information, technical support, or replacement parts, please contact weeonekids customer service. Keep your purchase

receipt and model number (EV-G) handy for faster service.
Visit the weeonekids Store for more products and support.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question