HONOR FCP-N49

Honor Magic V3 5G FCP-N49 User Manual

Model: FCP-N49 | Brand: HONOR

Introduction

This manual provides essential information for the safe and efficient use of your Honor Magic V3 5G FCP-N49 smartphone. This device features a 7.92-inch folding screen, 512GB storage, 12GB RAM, and supports Dual-SIM functionality. It operates on Android 14 and is designed for international GSM networks. Please read this manual thoroughly before using your device.

1. Setup

1.1 Unboxing and Initial Inspection

Carefully remove all components from the packaging. Verify that all items are present: the Honor Magic V3 5G smartphone, a charging cable, and any included documentation. Inspect the device for any visible damage.



Image: The Honor Magic V3 5G smartphone in its folded configuration, showcasing its compact form factor and a vibrant display.

1.2 SIM Card Installation

The Honor Magic V3 5G supports Dual-SIM functionality.

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray and press firmly until the tray pops out.
3. Place your Nano-SIM cards into the designated slots on the tray, ensuring the gold contacts face downwards.
4. Carefully reinsert the SIM card tray into the device until it clicks into place.

1.3 Battery Charging

Your device is equipped with two Lithium Polymer batteries. Before first use, it is recommended to fully charge the device.

- Connect the charging cable to the USB-C port at the bottom of the phone.

- Connect the other end of the cable to a compatible power adapter and plug it into a wall outlet.
- The charging indicator will appear on the screen.

1.4 Initial Power On and Setup Wizard

Press and hold the Power button (located on the side) until the Honor logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, Google account login, and security settings.

2. Operating Your Device

2.1 Folding Screen Operation

The Honor Magic V3 features an innovative folding screen design, allowing for both a compact form factor and an expansive display.

- **Unfolding:** Gently open the device from its folded state until the main inner screen is fully extended. Avoid applying excessive force.
- **Folding:** Close the device by bringing the two halves together until they meet. Ensure no objects are caught between the screens when folding.



Image: The Honor Magic V3 5G smartphone fully unfolded, showcasing its large internal display.



Image: The Honor Magic V3 5G smartphone in a partially unfolded position, demonstrating its flexible hinge mechanism.

2.2 Basic Navigation (Android 14)

Your device runs on Android 14. Navigation is primarily touch-based.

- **Home Screen:** Swipe up from the bottom to access the app drawer.
- **Notifications & Quick Settings:** Swipe down from the top of the screen.
- **Back:** Swipe from the left or right edge of the screen.
- **Recent Apps:** Swipe up from the bottom and hold.

2.3 Connectivity

The device supports various connectivity options:

- **5G/GSM:** For cellular data and calls. Ensure your SIM card is active and has a suitable plan.
- **Wi-Fi:** Connect to wireless networks for internet access. Go to Settings > Network & internet > Wi-Fi.
- **Bluetooth:** Pair with wireless headphones, speakers, and other devices. Go to Settings > Connected devices > Bluetooth.
- **NFC:** For contactless payments and quick pairing with compatible devices.
- **GPS:** For location services and navigation.

2.4 Camera Usage

The Honor Magic V3 5G is equipped with a rear camera system for photography and videography.

1. Open the Camera application from your home screen or app drawer.
2. Select your desired mode (Photo, Video, Portrait, etc.).
3. Tap the shutter button to capture an image or start/stop recording a video.
4. Adjust settings like zoom, flash, and filters as needed.



Image: The rear of the Honor Magic V3 5G, showing the prominent circular camera array and the HONOR branding.

2.5 Display and Stylus Support

The device features an OLED display with high resolution. It also supports stylus input for enhanced productivity and creativity.

- **Inner Screen:** 2344 x 2156 pixels.

- **Outer Screen:** 2376 x 1060 pixels.
- Use a compatible stylus (sold separately) for precise input, drawing, and note-taking.

3. Maintenance

3.1 Cleaning Your Device

To maintain the appearance and functionality of your Honor Magic V3 5G:

- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics.

3.2 Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements.

- Go to Settings > System & updates > Software update.
- Connect to a stable Wi-Fi network and ensure your battery is sufficiently charged before starting an update.

3.3 Battery Care

To prolong the lifespan of your device's battery:

- Avoid extreme temperatures.
- Do not let the battery completely drain frequently.
- Use the original charging accessories or certified compatible ones.

4. Troubleshooting

If you encounter issues with your device, try the following basic troubleshooting steps:

- **Device unresponsive:** Press and hold the Power button for about 10 seconds to force a restart.
- **Network issues:** Check if your SIM card is properly inserted. Try toggling Airplane Mode on and off. Restart the device.
- **Wi-Fi connection problems:** Ensure Wi-Fi is enabled. Forget the network and reconnect. Restart your router.
- **App crashing:** Clear the app's cache and data in Settings > Apps. If the problem persists, uninstall and reinstall the app.
- **Battery draining quickly:** Check battery usage in Settings to identify power-hungry apps. Reduce screen brightness and disable unnecessary features like GPS or Bluetooth when not in use.

For more complex issues, refer to the official Honor support website or contact customer service.

5. Specifications

Feature	Detail
Model Name	Magic V3 (FCP-N49)
Brand	Honor

Feature	Detail
Operating System	Android 14
CPU Model	Snapdragon
CPU Speed	3 GHz
RAM Memory Installed Size	12 GB
Memory Storage Capacity	512 GB
Display Technology	OLED
Inner Screen Resolution	2344 x 2156 pixels
Outer Screen Resolution	2376 x 1060 pixels
Screen Size (Standing)	7.92 inches
Form Factor	Foldable
Wireless Communication Technologies	Bluetooth, Cellular, NFC, Wi-Fi
Connectivity Technologies	5G, GSM, Wi-Fi
GPS	True
Human Interface Input	Microphone, Touchscreen with Stylus Support
Other Camera Features	Rear
Color	Reddish Brown
Product Dimensions	6.17 x 2.91 x 0.37 inches
Item Weight	8.1 ounces (230 Grams)
Battery Capacity	5150 mAh
Phone Talk Time	51 Hours
Wireless Carrier	Unlocked for All Carriers

Note: The 7.92-inch display size from the product title is used, as the 'Standing screen display size' of '64 Inches' in the raw specifications appears to be an error for a smartphone.

6. Warranty and Support

For information regarding the warranty of your Honor Magic V3 5G FCP-N49, please refer to the warranty card included in your product packaging or visit the official HONOR website.
For technical support, software updates, or service inquiries, please contact HONOR customer support through their official channels. Keep your proof of purchase and device serial number readily available when seeking support.

© 2025 HONOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question