**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**WISCENT WTB-779**

# WISCENT Hi-Fi Stereo Shelf System User Manual

Model: WTB-779

Overview What's in the Box Features Setup Operation Maintenance Troubleshooting Specifications Support

## 1. Product Overview

The WISCENT Hi-Fi Stereo Shelf System (Model WTB-779) is a versatile audio solution designed for home use. It integrates multiple playback options including a CD player, DVD player, Bluetooth connectivity, FM radio, USB input, and Aux-in. This compact system delivers 30W of clear, dynamic sound through its high-performance speakers, making it suitable for various room sizes and audio preferences.

Image 1.1: The WISCENT Hi-Fi Stereo Shelf System, showcasing the central unit and two accompanying speakers.

## 2. What's in the Box

Upon opening the package, verify that all components are present:

- Micro Hifi CD Player with Bluetooth (Main Unit)
- Two Stereo Speakers
- Remote Control
- RCA AV Cable
- Instruction Manual

Image 2.1: Packaging contents, showing the main unit, speakers, remote, cables, and manual.

## 3. Key Features

- **Versatile Audio System:** Combines CD player, DVD player, Bluetooth, FM Radio, USB, and Aux-in.
- **Compact Design:** Space-saving micro hi-fi system with stylish wooden sound system components.
- **CD/DVD Playback:** Supports CD/CD-R/CD-RW/MP3/WMA and standard DVDs. Note: RCA output only, no HDMI. Does not support Blu-ray discs.

- **Bluetooth Streaming:** Wirelessly connect smartphones, tablets, and other compatible devices.
- **Powerful Speakers:** 30W (15W+15W) speakers deliver clear and detailed stereo sound.

Image 3.1: Visual representation of the system's core functionalities.

## 4. Setup Guide

### 4.1 Unpacking and Placement

1. Carefully remove all components from the packaging.
2. Place the main unit and speakers on a stable, flat surface. Ensure adequate ventilation around the unit.
3. Position the speakers to the left and right of the main unit for optimal stereo separation.

### 4.2 Connecting the Speakers

Connect the speaker wires from each speaker to the corresponding speaker terminals on the rear of the main unit. Ensure

correct polarity (positive to positive, negative to negative) for optimal sound quality.

### 4.3 Power Connection

Plug the power cord into the AC inlet on the back of the main unit, then plug the other end into a standard wall outlet.

### 4.4 External Device Connections (Optional)

- **AUX-IN:** Connect external audio devices (e.g., smartphone, MP3 player) using a 3.5mm audio cable to the AUX-IN port on the front panel.
- **RCA Output to TV:** For DVD video playback, connect the RCA video output (yellow) from the main unit to the video input on your TV. Connect the red and white RCA audio outputs to the corresponding audio inputs on your TV or another audio receiver.

Image 4.1: Rear panel connections for speakers, AUX-IN, and RCA output to TV.

## 5. Operating Instructions

### 5.1 Power On/Off

Press the **POWER** button on the front panel or remote control to turn the system on or off.

### 5.2 Mode Selection

Press the **MODE** button on the front panel or remote control to cycle through available input sources: CD/DVD, Bluetooth, FM Radio, USB, AUX.

### 5.3 CD/DVD Playback

1. Select **CD/DVD** mode.
2. Insert a CD or DVD into the disc slot on the front of the main unit. The disc will load automatically.
3. Use the **PLAY/PAUSE**, **STOP**, **SKIP**, and **FAST FORWARD/REWIND** buttons on the unit or remote to control playback.

Image 5.1: Inserting a disc into the front-loading CD/DVD player.

## 5.4 Bluetooth Streaming

1. Select **Bluetooth** mode. The display will show "BT" or "PAIRING".
2. On your smartphone or tablet, enable Bluetooth and search for available devices.
3. Select "WTB-779" (or similar name) from the list to pair. Once connected, you will hear a confirmation tone.
4. Play audio from your device. You can control volume and track selection from your device or the system's remote.

Image 5.2: Bluetooth pairing process with a mobile device.

## 5.5 FM Radio

1. Select **FM Radio** mode.
2. Press the **SCAN** button (if available) to automatically search and save available stations.
3. Use the **TUNE +/-** buttons to manually tune to a station or select a preset.

### 5.6 USB Playback

1. Insert a USB flash drive into the USB port on the front panel.
2. Select **USB** mode. The system will automatically detect and begin playing compatible audio files (e.g., MP3, WMA).
3. Use the playback controls to navigate tracks.

### 5.7 AUX-IN Playback

1. Connect your external audio device to the AUX-IN port using a 3.5mm audio cable.
2. Select **AUX** mode.
3. Control playback directly from your connected external device.

## 6. Maintenance and Care

- **Cleaning:** Use a soft, dry cloth to clean the exterior surfaces of the unit and speakers. Do not use liquid cleaners or abrasive materials.
- **Disc Care:** Handle CDs and DVDs by their edges. Store them in their cases to prevent scratches. Clean discs with a soft, lint-free cloth, wiping from the center outwards.
- **Ventilation:** Ensure that the ventilation openings on the unit are not blocked to prevent overheating.
- **Power:** Unplug the system from the power outlet during lightning storms or when it will be unused for extended periods.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| No power | Power cord not connected; Power outlet faulty | Ensure power cord is securely plugged in; Try a different outlet |
| No sound | Volume too low; Speakers not connected; Incorrect input mode | Increase volume; Check speaker connections; Select correct input mode |
| CD/DVD not playing | Disc inserted incorrectly; Disc is dirty or scratched; Disc format not supported | Reinsert disc correctly; Clean or replace disc; Ensure disc is CD/DVD format (not Blu-ray) |
| Bluetooth pairing fails | Device too far; Bluetooth not enabled on device; System not in pairing mode | Move device closer; Enable Bluetooth on your device; Ensure system is in Bluetooth mode and ready to pair |
| Poor FM reception | Antenna not extended or positioned correctly; Weak signal | Extend and adjust the FM antenna; Try repositioning the unit |

## 8. Product Specifications

- **Model:** WTB-779
- **Brand:** WISCENT
- **Product Dimensions (L x W x H):**9.06 x 9.06 x 18.11 inches (Main unit and speakers combined)
- **Item Weight:** 10.34 pounds
- **Connectivity Technology:** Auxiliary, Bluetooth, USB
- **Color:** Black

- **Speaker Type:** Surround (Stereo)
- **Output Power:** 30W (15W + 15W)
- **Disc Compatibility:** CD, CD-R, CD-RW, MP3, WMA, DVD, DVD-R, DVD+R, DVD-RW, DVD+RW
- **Manufacturer:** WISCENT
- **ASIN:** B0DBLQZD6K




Image 8.1: System dimensions for placement reference.

## 9. Warranty and Support

WISCENT products are designed for reliability and performance. For specific warranty details, please refer to the warranty card included in your product packaging or visit the official WISCENT website. If you encounter any issues or require technical assistance, please contact WISCENT customer support through their official channels. Keep your purchase receipt as proof of purchase for warranty claims.

For further information and support, you may visit the **WISCENT Store on Amazon**.

© 2024 WISCENT. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0DBLQZD6K**

More documents and user manuals: **https://manuals.plus/**