

[manuals.plus](#) /› [SMALLRIG](#) /› [SmallRig L-Shape Handgrip 4797 for Sony Alpha 7C II / Alpha 7CR Instruction Manual](#)

SMALLRIG 4797-SR

SmallRig L-Shape Handgrip 4797 Instruction Manual

Model: 4797-SR | Brand: SMALLRIG

INTRODUCTION

This manual provides instructions for the installation and use of the SmallRig L-Shape Handgrip 4797. This accessory is specifically designed to enhance the ergonomics and functionality of your Sony Alpha 7C II or Alpha 7CR camera, offering improved grip, stability, and versatile mounting options.

The handgrip integrates seamlessly with the camera body, maintaining access to essential functions such as the battery compartment, and features a built-in Arca-Swiss quick release plate for efficient transitions between handheld and tripod shooting.

WHAT'S IN THE Box

- L-Shape Mount Plate x 1

The package includes one L-Shape Mount Plate. Please ensure all components are present upon unboxing.

In the Box

L-Shape Mount Plate × 1



Specifications

Product Dimensions:

125.4 × 69 × 60.1mm / 4.9 × 2.7 × 2.4in

Product Weight:

68 ± 5.0g / 2.4 ± 0.2oz

Material(s):

Aluminum Alloy, Silicone

Compatibility:

For Sony Alpha 7C II / Alpha 7CR

Image: The L-Shape Mount Plate with its dimensions and a list of package contents.

SETUP: ATTACHING THE HANDGRIP

- Prepare the Camera:** Ensure your Sony Alpha 7C II or Alpha 7CR camera is powered off.
- Align the Grip:** Position the SmallRig L-Shape Handgrip against the bottom of your camera, aligning the 1/4" screw hole on the grip with the tripod socket on the camera.
- Secure the Screw:** Use the included flat screwdriver to tighten the 1/4" screw, securing the handgrip to the camera. An anti-twist pin is integrated to prevent rotation.
- Check for Fit:** Verify that the handgrip is firmly attached and does not obstruct the battery compartment or other camera functions. The integrated rubber pad protects the camera from scratches.

Secure & Snug Fit



Image: Detailed view of the secure mounting mechanism, including the 1/4" screw, protective pads, and the flat screwdriver for installation.

OPERATING THE HANDGRIP

Ergonomic Handling

The handgrip features an ergonomic silicone handle designed to improve grip comfort and stability during prolonged shooting sessions. Its contoured shape reduces hand fatigue.

Integrated Silicone Handle

Comfortable ergonomic grip



Image: Close-up of the integrated silicone handle, highlighting its ergonomic design and texture.

Versatile Mounting Options

- Arca-Swiss Quick Release Plate:** The base of the handgrip is equipped with a built-in Arca-Swiss quick release plate, allowing for rapid attachment and detachment from compatible tripods and support systems.
- 1/4"-20 Threaded Hole:** Additional 1/4"-20 threaded holes are available for attaching various accessories.
- Strap Slot:** A dedicated strap slot is included for attaching a wrist strap or neck strap, enhancing security and portability.

Multiple Mounting Options



Quick Release Plate
for Arca-Swiss



1/4"-20
Threaded Hole



Strap Slot



Hassle-free mounting
on Arca-type tripods

Secure with a wrist strap for creative mobility
*Wrist strap sold separately

Image: The handgrip in use, showing its compatibility with Arca-type tripods and the strap slot for secure handling.

MAINTENANCE

- Cleaning:** Wipe the handgrip with a soft, dry cloth to remove dust and fingerprints. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive materials.
- Storage:** Store the handgrip in a clean, dry environment away from extreme temperatures and direct sunlight when not in use.
- Inspection:** Periodically check the mounting screw for tightness to ensure the grip remains securely attached to your camera.

TROUBLESHOOTING

- Grip feels loose:** Ensure the 1/4" mounting screw is fully tightened using the provided flat screwdriver.
- Battery compartment obstructed:** Re-check the alignment during installation. The grip is designed to allow full access to the battery compartment. If obstruction occurs, detach and re-attach carefully.
- Camera scratches:** The handgrip includes a rubber pad to prevent scratches. Ensure this pad is clean and properly positioned during installation. If scratches occur, verify correct installation and contact

support if issues persist.

SPECIFICATIONS

Model Number	4797-SR
Compatibility	Sony Alpha 7C II, Sony Alpha 7CR
Product Dimensions	125.4 x 69 x 60.1 mm (4.9 x 2.7 x 2.4 inches)
Item Weight	68 grams (2.4 ounces)
Materials	Aluminum Alloy, Silicone



Image: The handgrip showcasing its lightweight yet robust aluminum alloy construction.

WARRANTY AND SUPPORT

SmallRig products typically come with a limited warranty against manufacturing defects. For specific warranty details, product support, or to report any issues, please refer to the official SmallRig website or contact their customer service directly. Keep your purchase receipt for warranty claims.

