

Claiks Electric Standing Desk 120x60cm

Claiks Electric Standing Desk User Manual

Model: 120x60cm, Black

1. INTRODUCTION

Thank you for choosing the Claiks Electric Standing Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new adjustable height desk. Please read these instructions carefully before use and retain them for future reference.

2. SAFETY INSTRUCTIONS

- Ensure all components are present and undamaged before assembly.
- Keep children and pets away from the desk during operation to prevent injury.
- Do not overload the desk. Refer to the specifications section for maximum weight capacity.
- Avoid placing liquids directly on the control panel or near electrical components.
- Ensure the power cord is not pinched or damaged.
- If any unusual noise, smell, or malfunction occurs, immediately unplug the desk and contact customer support.
- Assembly may require two people due to the weight of some components.

3. PACKAGE CONTENTS

Please verify that all the following parts are included in your package:

- Desk tabletop (black, 120cm x 60cm)
- Desk frame (black)
- Lifting columns (2 units)
- Control panel with memory presets
- Power adapter and cable
- Assembly hardware (screws, bolts, Allen wrench)
- Instruction manual

Note: A screwdriver (not included) is recommended for assembly, although pre-drilled holes may allow for use with a regular screwdriver.

4. SETUP AND ASSEMBLY

Follow these steps for assembling your Claiks Electric Standing Desk. Clear instructions are provided in the included manual.



Image: A screwdriver and the instruction manual, illustrating the assembly process.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame:** Attach the lifting columns to the desk feet using the provided hardware.
3. **Attach Crossbar:** Connect the crossbar between the two lifting columns.
4. **Mount Control Box:** Secure the control box to the designated area on the frame.
5. **Attach Tabletop:** Carefully place the tabletop onto the assembled frame. Align the pre-drilled holes and secure the tabletop with the screws.
6. **Connect Control Panel:** Attach the control panel to the underside of the desk and connect its cable to the control box.
7. **Connect Power:** Plug the power adapter into the control box and then into a wall outlet.



Image: A visual guide depicting the step-by-step assembly process of the desk frame and tabletop.

5. OPERATING INSTRUCTIONS

Your Claiks Electric Standing Desk offers smooth and quiet height adjustment with memory presets.



Image: A close-up view of the desk's control panel, showing the digital height display and buttons for up, down, and memory presets (1, 2, 3).

5.1. Adjusting Height

- Use the **Up (▲)** and **Down (▼)** buttons on the control panel to manually adjust the desk height. The current height will be displayed on the digital screen.
- The desk can be adjusted between 72cm and 118cm.

5.2. Memory Presets

The desk allows you to save up to three preferred heights for quick adjustment.

1. Adjust the desk to your desired height using the Up/Down buttons.
2. Press the "M" button (or similar memory button) followed by one of the numbered preset buttons **1, 2, or 3**. The display will confirm the height has been saved.
3. To recall a saved height, simply press the corresponding numbered preset button **1, 2, or 3**. The desk will automatically move to that height.



Image: A person's hand interacting with the desk's control panel, adjusting the height. The digital display shows '072'.

5.3. Quiet Operation

The Claiks Electric Standing Desk is designed for quiet operation, ensuring minimal disturbance in your workspace.



Image: A graphic representation showing the desk's noise level at approximately 45dB, significantly lower than typical office noise (60dB).

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your desk.

- **Cleaning the Tabletop:** The tabletop is made with melamine resin, which is resistant to water, heat, and dirt. Clean with a soft, damp cloth and mild detergent. Avoid abrasive cleaners.
- **Frame Maintenance:** Periodically check all screws and bolts to ensure they are tight. Retighten if necessary.
- **Electrical Components:** Keep the control panel and power adapter dry and free from dust. Do not attempt to open or repair electrical components yourself.

7. TROUBLESHOOTING

If you encounter any issues with your Claiks Electric Standing Desk, please refer to the following common solutions:

- **Desk Not Moving:** Ensure the power cable is securely plugged into both the desk and the wall outlet. Check if the outlet is functional.
- **Uneven Movement:** Unplug the desk for 30 seconds, then plug it back in. This may reset the system. If the issue persists, ensure the desk is on a level surface and that no objects are obstructing the lifting columns.
- **Error Code on Display:** Note down any error codes displayed and refer to the full troubleshooting guide (if available) or contact customer support.
- **Noise During Operation:** A slight hum is normal. If you hear loud or unusual noises, stop operation and inspect the desk for any loose parts or obstructions.

If these steps do not resolve the issue, please contact Claiks customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Brand	Claiks
Model	Electric Standing Desk
Dimensions (W x D x H)	120 cm x 60 cm x 72-118 cm
Height Adjustment Range	72 cm to 118 cm
Lifting Speed	20 mm/s
Color	Black (Frame and Tabletop)
Tabletop Material	Melamine Resin
Memory Presets	3 programmable heights
Assembly Required	Yes

Package Dimensions	125 x 33 x 16 cm
Package Weight	20 kg







Image: A diagram illustrating the dimensions of the Claiks Electric Standing Desk, including its width (120cm), depth (60.9cm), and adjustable height range (72cm to 118cm).

9. WARRANTY AND SUPPORT

Claiks is committed to providing high-quality products and excellent customer service.

- **Manufacturer's Warranty:** All Claiks products come with a **1-year manufacturer's warranty**. During this period, free repair or replacement services are provided for any manufacturing defects.
- **Customer Support:** Our customer support team is available to assist you with any questions or issues. We offer support in multiple languages, including English and Japanese. Please feel free to contact us at any time.

For warranty claims or support inquiries, please refer to the contact information provided on your purchase receipt or the official Claiks website.

	<p>Claiks 48-inch Electric Standing Desk Installation Guide</p> <p>Detailed installation guide for the Claiks 48-inch (120cm) electric standing desk. Includes assembly steps, component lists, hardware details, controller operation, and troubleshooting for your height-adjustable desk.</p>
	<p>CLAIKS E9 Standing Desk with Drawers Installation Guide</p> <p>Comprehensive installation guide for the CLAIKS E9 Standing Desk with Drawers, including safety precautions, specifications, component list, step-by-step assembly instructions, and controller operation details. Learn how to set up and use your adjustable height desk.</p>
	<p>Claiks 48-inch Standing Desk with Drawers Assembly and User Manual</p> <p>Comprehensive assembly and user manual for the Claiks 48-inch Standing Desk with Drawers (Model P1.01.002). Includes safety cautions, specifications, step-by-step installation instructions, controller operation guide, and troubleshooting error codes.</p>
	<p>Claiks Glass Standing Desk Installation Guide</p> <p>Comprehensive installation guide for the Claiks Glass Standing Desk (48-inch/120cm), covering setup, cable management, and controller operation with multilingual instructions.</p>