

[Manuals.plus](#) /

> [Nautica](#) /

> Nautica Men's NCT Windrose 46mm Watch (Model NAPWRF407) Instruction Manual

## Nautica NAPWRF407

# Nautica Men's NCT Windrose 46mm Watch Instruction Manual

Model: NAPWRF407

## INTRODUCTION

---

Thank you for choosing the Nautica Men's NCT Windrose 46mm Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

## PRODUCT OVERVIEW

---

The Nautica NCT Windrose watch features a robust design with multifunction capabilities, housed in a recycled stainless steel case. Key features include:

- Silver tone 46mm recycled (90%) stainless steel case with mineral glass crystal.
- Black dial with multifunction movement, including day, date, and 24-hour subdials.
- Hands with luminous infill for visibility in low light.
- Adjustable and recycled (90%) stainless steel bracelet, fitting up to an 8-inch wrist circumference.
- Screw-down case back and screw-down crown for enhanced water resistance.
- Water-resistant to 100 meters (330 feet).



Figure 1: Front view of the Nautica Men's NCT Windrose 46mm Watch, showcasing the black dial, silver-tone case, and stainless steel bracelet.



Figure 2: Side view of the Nautica Men's NCT Windrose 46mm Watch, highlighting the crown and case profile.



**Figure 3:** Back view of the Nautica Men's NCT Windrose 46mm Watch, showing the screw-down case back with Nautica logo and model information.

## SETUP

### Setting the Time

1. Unscrew the crown by turning it counter-clockwise until it is loose.
2. Pull the crown out to the second click position.
3. Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
4. Push the crown back in to the first click position.
5. Screw the crown back in tightly by turning it clockwise until it is secure. This ensures water resistance.

## Setting the Date and Day (Multifunction Dials)

1. Unscrew the crown by turning it counter-clockwise until it is loose.
2. Pull the crown out to the first click position.
3. Turn the crown clockwise to adjust the date subdial.
4. Turn the crown counter-clockwise to adjust the day subdial.
5. The 24-hour subdial automatically synchronizes with the main time setting.
6. Once the date and day are set, push the crown back in completely.
7. Screw the crown back in tightly by turning it clockwise until it is secure to maintain water resistance.

## Adjusting the Bracelet

The stainless steel bracelet is adjustable. If the watch bracelet is too loose or too tight, links may need to be added or removed. It is recommended to have this adjustment performed by a qualified jeweler or watch technician to prevent damage to the bracelet or watch.

## OPERATING YOUR WATCH

---

### Water Resistance

Your Nautica NCT Windrose watch is water-resistant to 100 meters (330 feet). This means it is suitable for swimming, snorkeling, and showering. However, it is crucial to ensure the crown is always screwed down tightly before any contact with water. Do not operate the crown or pushers while the watch is wet or submerged, as this can compromise the water resistance and lead to internal damage.

### Multifunction Dials

The watch features three subdials:

- **Day Subdial:** Indicates the current day of the week (e.g., MON, TUE).
- **Date Subdial:** Displays the current date (1-31).
- **24-Hour Subdial:** Shows the current time in a 24-hour format, synchronized with the main time display.

## MAINTENANCE

---

### Cleaning Your Watch

To maintain the appearance of your watch, regularly wipe the case and bracelet with a soft, dry cloth. For stainless steel, a slightly damp cloth can be used, followed by drying thoroughly. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and seals.

### Battery Replacement

The watch is powered by a quartz movement requiring a battery. When the watch stops running, it indicates the battery needs replacement. It is strongly recommended to have the battery replaced by an authorized service center or a professional watchmaker. This ensures the correct battery type is used and the water resistance is maintained by properly resealing the case back.

## Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. Keeping it in its original box or a watch case can help protect it from dust and scratches.

## TROUBLESHOOTING

---

### Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed in and screwed down. If it's pulled out, the watch will not run.
- **Battery:** If the watch has stopped completely, the battery may need to be replaced. Refer to the "Battery Replacement" section.

### Incorrect Time or Date

- **Reset Time/Date:** Follow the instructions in the "Setting the Time" and "Setting the Date and Day" sections to reset.
- **Daylight Saving Time:** Remember to adjust your watch manually for daylight saving time changes.

## SPECIFICATIONS

---

<b>Model Number</b>	NAPWRF407
<b>Case Diameter</b>	46mm
<b>Case Material</b>	Recycled (90%) Stainless Steel
<b>Crystal Material</b>	Mineral Glass
<b>Movement Type</b>	Multifunction Quartz
<b>Water Resistance</b>	100 meters (330 feet)
<b>Bracelet Material</b>	Recycled (90%) Stainless Steel
<b>Bracelet Circumference</b>	Up to 8 inches
<b>Battery Type</b>	1 A battery (included)
<b>Manufacturer</b>	Timex

## WARRANTY AND SUPPORT

---

Your Nautica watch is covered by a manufacturer's warranty against defects in materials and workmanship.

For specific warranty terms, conditions, and duration, please refer to the warranty card included with your purchase or visit the official Nautica website. For service, repairs, or technical support, please contact Nautica customer service or an authorized service center.

Consider purchasing an extended protection plan for additional coverage beyond the manufacturer's warranty. Details on available protection plans can often be found at the point of purchase or through authorized retailers.

For further assistance, please visit the official Nautica website: [www.nautica.com](http://www.nautica.com)