Warner Home Video B0DBMQY182

86 Eighty-Six The Complete First Season Blu-ray User Manual

1. Product Overview

The 86 Eighty-Six The Complete First Season Blu-ray set brings the acclaimed animated series to your home. This collection features the full first season, detailing the conflict between the Republic of San Magnolia and the Empire of Giad, where the 'Eighty-sixers' pilot the 'Juggernaut' combat drones. The set includes 23 episodes across three Blu-ray discs, offering high-definition video and audio.



Image 1.1: Front cover of the 86 Eighty-Six Blu-ray set.



Image 1.2: Back cover of the 86 Eighty-Six Blu-ray set, detailing contents and synopsis.

2. Setup

2.1 Disc Handling

Always handle Blu-ray discs by their edges to avoid fingerprints and scratches on the playback surface. Store discs in their original case when not in use to protect them from dust and damage.

2.2 Player Compatibility

This Blu-ray set is designed for playback on standard Blu-ray players, PlayStation consoles (PS3, PS4, PS5), Xbox consoles (Xbox One, Xbox Series X), and Blu-ray compatible PC drives. Ensure your player is updated with the latest firmware for optimal performance.

3. Operating Instructions

3.1 Playback

1. Insert the desired Blu-ray disc into your Blu-ray player.
2. The player should automatically load the disc and display the main menu. If not, select the 'Disc' or 'Blu-ray' input on your player's remote.
3. From the main menu, select 'Play All' to watch all episodes on the disc consecutively, or choose individual episodes from the 'Episode Selection' menu.

3.2 Menu Navigation

Use the directional buttons on your remote control to navigate through the menu options. Press 'Enter' or 'OK' to confirm your selection. The 'Pop-Up Menu' button on your remote may allow access to disc features during playback without interrupting the video.

3.3 Audio and Subtitles

To change audio tracks or subtitle options, access the 'Audio' or 'Subtitles' menu from the main menu or the pop-up menu during playback. The primary audio track is Japanese, with English subtitles available. Some players may have dedicated 'Audio' and 'Subtitle' buttons on the remote for quick access.

4. Maintenance

- **Cleaning Discs:** If a disc becomes dirty, gently wipe it from the center outwards with a soft, lint-free cloth. Do not use abrasive materials or harsh chemical cleaners.
- **Storage:** Store discs vertically in their original case, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Scratches:** Do not stack discs without their cases. Avoid touching the playback surface of the disc.

5. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Disc does not play or load.	Disc is dirty or scratched; Player firmware is outdated; Disc inserted incorrectly.	Clean the disc; Check for scratches; Update player firmware; Re-insert disc correctly.
No audio or incorrect audio track.	Wrong audio track selected; Player audio settings incorrect; TV/receiver volume low.	Select correct audio track from disc menu; Check player's audio output settings; Increase volume on TV/receiver.
Subtitles not appearing or wrong language.	Subtitles turned off; Incorrect subtitle language selected.	Enable subtitles from disc menu; Select desired subtitle language (English).
Video playback is choppy or freezes.	Disc is dirty or damaged; Player issue.	Clean the disc; Try the disc in another player to isolate the issue.

6. Specifications

Title: 86 Eighty-Six The Complete First Season

Format: Blu-ray, Subtitled

Number of Discs: 3

Run Time: Approximately 8 hours and 50 minutes

Language: Japanese (Original), English Subtitles

Genre: Animation

MPAA Rating: NR (Not Rated)

Release Date: November 5, 2024

Product Dimensions: 0.54 x 6.71 x 5.36 inches; 4.64 ounces

ASIN: B0DBMQY182

UPC: 0782009248415

Studio: Warner Home Video

7. Warranty and Support

For information regarding product warranty or technical support, please refer to the official website of the distributor, Warner Home Video, or contact their customer service department. Specific warranty details are typically provided with the product packaging or on the distributor's official channels.

© 2024 Warner Home Video. All rights reserved.