

[manuals.plus](#) /› [HONOR](#) /› [HONOR 200 5G Smartphone User Manual](#)

HONOR HONOR 200

HONOR 200 5G Smartphone User Manual

Model: HONOR 200

INTRODUCTION

This manual provides essential instructions for setting up, operating, maintaining, and troubleshooting your HONOR 200 5G smartphone. Please read this manual thoroughly to ensure proper use and to maximize the device's performance.

1. SETUP

1.1 Unboxing and Package Contents

Upon opening the package, verify that all items are present:

- HONOR 200 5G Smartphone
- USB Cable
- Quick Start Guide (may vary by region)
- SIM Ejector Tool (may vary by region)



Figure 1: Front view of the HONOR 200 smartphone.

1.2 SIM Card Installation

The HONOR 200 supports Dual SIM functionality. To install your SIM card(s):

1. Locate the SIM card tray on the side of the device.
2. Insert the SIM ejector tool into the small hole next to the tray and press firmly until the tray pops out.
3. Place your Nano-SIM card(s) into the designated slots on the tray, ensuring the gold contacts face downwards.
4. Carefully reinsert the SIM tray into the phone.

Important: Before purchasing, verify network compatibility with your service provider. This device supports 2G GSM, 3G HSDPA, 4G LTE, and 5G SA/NSA frequencies, including eSIM functionality.



Figure 2: Side view of the HONOR 200, indicating SIM tray location.

1.3 Initial Power On and Setup

Press and hold the Power button (located on the right side) until the HONOR logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.

1.4 Charging the Device

Connect the provided USB cable to the phone's charging port and the other end to a compatible power adapter (sold separately) or a computer's USB port. The device features a 5200mAh non-removable battery. A full charge typically takes approximately 3 hours.

2. OPERATING YOUR HONOR 200

2.1 Basic Navigation

The HONOR 200 operates on Android 14 with a responsive touchscreen interface. Use gestures such as tapping, swiping, pinching, and spreading to navigate menus, open applications, and interact with content.

2.2 Display Features

Your device features a 6.7-inch OLED display with 1B colors and a resolution of 1200 x 2664 pixels, offering a 120Hz refresh rate for smooth visuals.

2.3 Camera Usage

The HONOR 200 is equipped with a versatile camera system:

- **Rear Cameras:** 50 MP main, 50 MP secondary, and 12 MP tertiary lenses.
- **Front Camera:** 50 MP for high-quality selfies and video calls.

Open the Camera app from your home screen or app drawer to access various shooting modes and settings.



Figure 3: Back view of the HONOR 200, highlighting the camera system.

2.4 Connectivity

Your device supports multiple connectivity options:

- **Cellular:** GSM, LTE, and 5G networks.
- **Wi-Fi:** Connect to wireless internet networks.
- **Bluetooth:** Pair with wireless accessories.
- **USB:** For charging and data transfer.

Manage these settings via the 'Settings' application.

3. MAINTENANCE

3.1 Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Use the provided USB cable for charging.
- Avoid fully discharging the battery frequently.
- Optimize power settings in the device's 'Settings' menu.

3.2 Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. You can find update options in 'Settings' > 'System & updates' > 'Software update'.

3.3 Cleaning the Device

Use a soft, lint-free cloth to clean the screen and body of your smartphone. Avoid using harsh chemicals or abrasive materials.

3.4 Storage Management

Your device comes with 512GB of internal storage. Regularly review and manage your files, applications, and media to optimize performance. You can check storage usage in 'Settings' > 'Storage'.

4. TROUBLESHOOTING

4.1 Common Issues and Solutions

- **Device not powering on:** Ensure the battery is charged. Connect to a charger for at least 15 minutes, then try powering on again.
- **Network connectivity issues:** Check if your SIM card is properly inserted. Verify mobile data is enabled in settings. Restart the device.
- **Apps crashing or freezing:** Close and reopen the app. Clear the app's cache in 'Settings' > 'Apps'. If the issue persists, uninstall and reinstall the app.
- **Charging problems:** Ensure the USB cable and charger are undamaged and properly connected. Try a different cable or power source.

4.2 Factory Reset

If persistent issues occur, a factory reset may resolve them. **Warning:** A factory reset will erase all data on your device. Back up important data before proceeding. Navigate to 'Settings' > 'System & updates' > 'Reset' > 'Reset phone'.

5. SPECIFICATIONS

Feature	Detail
Model Name	HONOR 200
Operating System	Android 14
Processor	Qualcomm SM7550-AB Snapdragon 7 Gen 3 (4 nm), Octa-core (1x2.63 GHz Cortex-A715 & 4x2.4 GHz Cortex-A715 & 3x1.8 GHz Cortex-A510)
RAM	12 GB
Internal Storage	512 GB (non-expandable)
Display	6.7-inch OLED, 1B colors, 1200 x 2664 pixels resolution, 120 Hz refresh rate
Rear Camera	50 MP, 50 MP, 12 MP
Front Camera	50 MP
Battery	5200 mAh (non-removable), approx. 3 hours charging time, up to 120 hours talk time
Dimensions (H x W x D)	161.5 x 74.6 x 7.7 mm (6.36 x 2.94 x 0.30 in)
Weight	187 g (6.60 oz) / 0.5 kg (1.1 lbs)
Connectivity	GSM, HSDPA, LTE, 5G (SA/NSA), Wi-Fi, Bluetooth
SIM Support	Dual SIM, eSIM
Audio Jack	No 3.5mm headphone jack
Color	Black
Included in Box	USB Cable

6. WARRANTY INFORMATION

For detailed warranty terms and conditions, please refer to the warranty card included with your product or visit the official HONOR website. Keep your proof of purchase for warranty claims.

7. SUPPORT

If you encounter issues not covered in this manual or require further assistance, please contact HONOR customer support. You can find contact information on the official HONOR website or through the support section within your device's settings.